

ASSEMBLY OF TRANSMISSION




Fig. 7-61. Installing forward planetary carrier assembly and attached parts (TRT-3 overdrive)

(3) Install ring gear 1 (foldout 10,B) onto carrier assembly 3. Retain it with snap-ring 11. Install ring gear 14, longer ends of external splines first, onto carrier assembly 3.

(4) Install retainer 21, flat side first, onto the rear of carrier assembly 3. Install bearing assembly 22 against the shoulder at the rear of carrier assembly 3.

(5) Install the thrust washer into the forward planetary carrier assembly, using oil-soluble grease to retain it (fig. 7-61).

(6) Install the forward carrier assembly and attached parts (fig. 7-61). Rotate the carrier and ring gears until all gear teeth and clutch plate splines are engaged.

(7) Install another internal-splined, and another external-tanged clutch plate onto the forward ring gear, above the positioning ring (fig. 7-62).

(8) Install twelve clutch piston return springs and pins (fig. 7-62). Install the adapter gasket.




Fig. 7-62. Installing rear housing adapter assembly (TRT-3 underdrive)


(9) Install headless guide bolts into the retainer and transmission housing as shown in figure 7-62.

(10) Install the forward clutch piston, with sealrings, flat side first, into the adapter assembly (fig. 7-62).

(11) Install the adapter assembly, aligning the oil ports in the retainer and adapter (fig. 7-62).

(12) Install two 3/8-16 x 2-3/4-inch bolts at opposite sides of the adapter assembly to pull the adapter down against the clutch piston return springs. Install the two 3/8-16 x 1-3/4-inch, 12-point-head bolts (fig. 7-63). Tighten the bolts to 36-43 lb ft (49-58 N·m).

(13) Remove the two outer guide bolts and 3/8-16 x 2-3/4-inch pulldown bolts which were temporarily installed in step (12). Install the six 3/8-24 x 1-1/4-inch, self-locking bolts 28 (foldout 10,B) into the inner bolt circle. (Remove the inner guide bolts to install the last two self-locking bolts.) Tighten the bolts to 41-49 lb ft (56-66 N·m).



S1430

Fig. 7-63. Installing high-range clutch drum assembly (TRT-3 underdrive)

f. High-Range Clutch, Low-Range Planetary (TRT 2221-3, 2421-3 underdrive models)

NOTE

New Teflon sealrings may require forming by hand to help retain their proper circular shape. Wrap them in a circle around an object about two-thirds the diameter of the groove they fit.

(1) Install two step-joint sealrings 1 (foldout 13,A) into the grooves in the hub of the high-range clutch drum assembly (fig. 7-63). Use oil-soluble grease to retain the sealrings.

(2) Install the high-range clutch drum assembly onto the forward planetary carrier (fig. 7-63).


(3) Install the snapping which retains the high-range clutch drum on the forward planetary carrier.

(4) Install low-range planetary sun gear assembly 1 (foldout 13,B), thrust washer 3 upward, onto the forward planetary carrier.

(5) Install one internal-splined clutch plate (fig. 7-64). Install the low-range planetary carrier assembly.


(6) Install the low-range ring gear, positioning ring first, into the clutch plate installed in step (5) (fig. 7-65).

(7) Install two external-splined and two internal-splined, low-range clutch plates, stacked alternately as shown in figure 7-65.



S1490

Fig. 7-64. Installing low-range planetary carrier assembly (TRT-3 underdrive)



S1491

Fig. 7-65. Installing high-range clutch plates (TRT-3 underdrive)

ASSEMBLY OF TRANSMISSION

(8) Install high-range clutch back-plate 17 (foldout 13,A), flat side first. Retain it with large internal snapping 18.

g. Low-Range Clutch, Rear Housing Assembly (TRT 2221-3, 2421-3 underdrive models)

(1) Install the clutch anchor pin into the rear housing (as rebuilt in paragraph 6-11). Leave the flat-milled end of the pin extending at the inside of the housing (fig. 7-66).

(2) Beginning with an external-tanged clutch plate, alternately stack five external-tanged and five internal-splined plates on the face of the low-range clutch piston in the housing (fig. 7-66).

(3) Install the low-range clutch anchor assembly, engaging the anchor pins with the slots in the external-tanged clutch plates, and the slot in the anchor with the anchor pin in the rear housing (fig. 7-66).

(4) Install the heavy internal snapping which retains the low-range clutch anchor assembly. Note the relation of the ends of the snapping to the two anchor pins which extend

slightly above the anchor surface (refer to fig. 7-59).

(5) Suspend the assembled housing on a hoist and install the rear housing gasket. Use oil-soluble grease to retain the gasket (fig. 7-67).


(6) Install the rear housing assembly onto the adapter assembly (fig. 7-67). To align gear teeth and clutch plate splines, rotate the output shaft while lowering the assembly.

(7) Install fifteen 3/8-16 x 2-3/4-inch bolts 4 (foldout 16,B) and lockwashers 3 to retain the rear housing and adapter. Tighten the bolts to 26-32 lb ft (36-43 N·m).

(8) Proceed to paragraph 7-10.


h. Forward Planetary, Clutch, Rear Housing (TRT 2211-3, 2411-3)

(1) Beginning with an internal-splined forward clutch plate, alternately install two internal-splined plates and two external-tanged plates onto the forward-and-reverse clutch anchor assembly (fig. 7-68).



S1492

Fig. 7-66. Installing low-range clutch anchor assembly (TRT-3 underdrive)



S1493

Fig. 7-67. Installing rear housing assembly (TRT-3 underdrive)




Fig. 7-68. Installing forward-and-reverse sun gear (TRT 2211-3, 2411-3)

(2) Install the forward-and-reverse sun gear into the reverse planetary carrier assembly (fig. 7-68).

(3) Install reverse ring gear 1 (foldout 11,A) onto carrier assembly 3. Retain it with snapping 10.

(4) Install bearing 11 onto the rear of carrier assembly 3, pressing it to seat on the shoulder of the carrier.

(5) Install bearing spacer 12 against bearing 11.

(6) Install thrust washer 2 into the front of carrier assembly 3, retaining it with oil-soluble grease. Install forward ring gear 15, longer splines first, onto the carrier assembly.

(7) Install the carrier assembly, as assembled in steps (3) through (6) into the transmission. Rotate the carrier shaft and forward ring gear to mesh gears and clutch plate splines.

(8) Install one internal-splined clutch plate 16 and then one external-tanged clutch plate 17 onto those previously installed.

(9) Install twelve piston return springs 22 (foldout 9,B) and twelve pins 23 into the circle of holes in the forward-and-reverse clutch anchor assembly.

(10) Install forward clutch piston 18 (foldout 11,A), with sealrings 19, 20, and 21, into housing 9 (foldout 16,C).

(11) Install gasket 1 onto the front flange of housing 9.

(12) Install housing assembly 5 onto the transmission and retain it with eighteen 3/8-16 x 1-3/4-inch bolts 4 and lockwashers 3. Tighten the bolts to 26-32 lb ft (36-43 N·m).

7-10. INSTALLATION OF TURBINE GEARING, OIL SUCTION TUBE, AND STRAINER

a. Accessory Drive Shaft Assembly

(1) If removed, install bearing 9 (foldout 7,B) onto drive shaft 8 and seat the bearing firmly against the shaft shoulder. Apply Molykote Type G or equivalent into the drive splines of the shaft.

(2) Install the accessory drive shaft and bearing into the transmission housing (fig. 7-69).

b. Turbine Gears, Freewheel Clutch

(1) If the transmission is equipped with a standard-speed, low-gear ratio, proceed to step (2). If the transmission is equipped with a high-speed, forward-gear ratio, proceed to step (3).

(2) Install the forward-and-reverse sun gear, as shown in figure 7-69. Proceed to step (5).

(3) Install the spacer into the sun gear cavity in the housing wall, as shown in figure 7-70.

(4) After installation, the end of the spacer (fig. 7-70) should be flush with the bearing bore seat (shoulder) in the transmission housing. If the spacer is above the shoulder, this indicates the forward-and-reverse sun gear thrust washer is not seated properly. To reseat the thrust washer, remove the spacer and use a suitable probe through the forward-and-reverse sun gear to relocate

ASSEMBLY OF TRANSMISSION




Fig. 7-69. Installing forward-and-reverse sun gear (-1 models)




Fig. 7-71. Installing first-turbine drive gear components




Fig. 7-70. Installing forward-and-reverse sun gear spacer (-1 models)

(center) the thrust washer. Reinstall the spacer.

(5) Install the first-turbine drive gear and bearing (as assembled in para 6-10) (fig. 7-71). Install the step-joint sealring into the groove in the drive gear hub. Use oil-soluble grease to retain the sealring in its groove. Install the rear thrust bearing race (flat) and the needle roller bearing onto the drive gear.

(6) Install the turbine-driven gears and freewheel clutch assembly (as assembled in para 6-9) (fig. 7-72). Rotate the assembly to engage the second-turbine driven gear splines with those of the forward-and-reverse sun gear (fig. 7-71).




Fig. 7-72. Installing oil suction tube

c. Oil Suction Tube, Oil Strainer

(1) Generously lubricate the oil suction tube compression sealring with transmission fluid (fig. 7-72). Using the fabricated wrench, install the 1-3/4-14 male nut and compression sealring onto the pump end of the oil suction tube. Insert the suction end of the tube into the sump area, and the pump end into the threaded hole at the pump in-

take. Make sure the sealing is squarely seated in the intake boss. Install the nut into the boss but do not tighten at this time.

NOTE


For -1 models, proceed to step (2). For -3 models, proceed to step (3).

(2) -1 Models. Install one 3/8-16 x 5/8-inch self-locking bolt to secure the suction tube to the housing but do not tighten at this time (fig. 7-73). Install the oil strainer and gasket (fig. 7-74). Secure the oil strainer with six 3/8-16 x 7/8-inch bolts 20 (foldout

8,B) and lockwashers 21. Tighten the bolts to 26-32 lb ft (36-43 N·m). Install the oil drain plug (fig. 7-74) and tighten it to 33-37 lb ft (45-50 N·m). Then, while holding the suction tube flush with the oil pump mounting surface and using a fabricated wrench, tighten the male nut to 120-150 lb ft (163-204 N·m). Tighten the self-locking bolt, which holds the oil suction tube, to 36-43 lb ft (49-58 N·m). Proceed to step (4).


(3) -3 Models. Install one 5/16-18 x 5/8-inch self-locking bolt to secure the suction tube to the housing but do not tighten at this time (refer to fig. 7-73). Install the oil strainer (fig. 7-75). Install the O-ring gasket onto the strainer cover and install the cover. Secure the cover with two 3/8-16 x 3/4-inch bolts and lockwashers. Tighten the bolts to 26-32 lb ft (36-43 N·m). Install the oil drain plug and tighten it to 33-37 lb ft (45-50 N·m). Then, while holding the suction tube flush with the oil pump mounting surface and using a fabricated wrench, tighten the male nut to 120-150 lb ft (163-204 N·m). Tighten the self-locking bolt, which holds the oil suction tube, to 17-20 lb ft (23-27 N·m). Install baffle plate 29 (foldout 9,A) and retain it with three 5/16-18 x 5/8-inch, self-locking bolts 30. Leave bolt hole for the suction tube bracket. Tighten bolts 30 to 17-20 lb ft (23-27 N·m).

(4) If the ball bearing was removed from the second-turbine drive gear, install a




S2613

Fig. 7-73. Installing second-turbine drive gear



S2534

Fig. 7-74. Installing oil strainer and gasket (-1 models)



S1395

Fig. 7-75. Installing oil strainer and O-ring gasket (-3 models)

ASSEMBLY OF TRANSMISSION

new bearing (fig. 7-73). Install the step-joint sealing into its groove near the bearing. Install the front race of the thrust bearing, flange first, onto the bottom (rear) of the drive gear. Use oil-soluble grease to retain the bearing race on the drive gear. Install the second-turbine drive gear and assembled parts onto the first-turbine drive gear (fig. 7-73).

7-11. INSTALLATION OF CONVERTER HOUSING, CONVERTER COMPONENTS

a. Converter Housing

(1) If roller bearing 45 (foldout 7,B) is used with the accessory-driven gear, install the outer race, lip toward the rear, into the main housing bore. It may be necessary to temporarily install the charging pump to maintain bearing race alignment. Install the gasket onto the converter housing splitline (fig. 7-76). Use oil-soluble grease to retain the gasket during installation of the housing. Attach a sling to the converter housing front flange and, while lowering the converter housing (as assembled in para 6-8) onto the transmission housing, guide the accessory-driven gear past the second-turbine drive gear. Seat the converter housing and remove the sling.


(2) To attach the converter housing, install one 7/16-14 x 2-3/4-inch bolt, twenty-

three 7/16-14 x 1-3/8-inch bolts, twenty-four 7/16-inch flat washers, and twenty-four 7/16-inch lockwashers (fig. 7-77). Tighten the bolts to 42-50 lb ft (57-67 N·m).

b. Converter Components


(1) Check to ensure that the step-joint sealing (installed in para 6-8) is firmly seated in the converter housing sleeve (fig. 7-77). For models with a dry converter housing, check to be sure the diaphragm oil seal is packed with high-temperature grease.

(2) Install the torque converter pump (as assembled in para 6-7) onto the converter ground sleeve (fig. 7-78). Install the splined




S2614

Fig. 7-77. Installing torque converter housing bolts



S1497

Fig. 7-76. Installing torque converter housing assembly



S1498

Fig. 7-78. Installing torque converter stator

spacer. Install the stator, hub projection first, onto the ground sleeve.

(3) For models with a dry converter housing, install the sealring into the groove in the converter pump splitline. The sealring used on models with a dry housing has a rectangular cross-section—0.113–0.123 x 0.133–0.143 in. (2.88–3.12 x 3.38–3.63 mm), and will fit into the groove in the converter pump either way. The sealring must be installed with the 0.133–0.143 inch (3.38–3.63 mm) dimension in the clamp direction (fig. 7-79) in order to provide adequate seal. (The O.D. of the sealring may be marked with white paint.) Fill in the remaining sealring groove area with petrolatum.

(4) Install the snapring onto the converter ground sleeve to retain the stator (fig. 7-80). Install the first- and second-turbine assembly (as assembled in para 6-6) onto the turbine drive-gear shafts.

7-12. INSTALLATION OF INPUT COMPONENTS

NOTE

Direct-mount models with flex disks, proceed to paragraph 7-12a. Direct-mount models with a drive ring, proceed to paragraph 7-12b. Remote-mount models, proceed to paragraph 7-12c.

a. Direct Mount (flex disk)

(1) Install the torque converter drive cover (fig. 7-81).






Fig. 7-79. Assembly of converter pump sealring



S1499


Fig. 7-80. Installing first-and-second turbine assembly



S1500

Fig. 7-81. Installing torque converter drive cover—direct mount

ASSEMBLY OF TRANSMISSION



S2615

Fig. 7-82. Installing flex disk assembly (direct mount)

the converter cover (fig. 7-82). Install flex disk plate 4 (foldout 6,B), if applicable. Assemble the three flex disks so the cone of each will be parallel to the flex disk and washer assembly and install the three disks as an assembly (fig. 7-82). Install the disk plate and align all the disk holes with the tapped holes in the converter drive cover. Install six 1/2-13 x 7/8-inch, self-locking bolts and tighten them to 81-97 lb ft (110-131 N·m).

(4) If the transmission is equipped with a wet converter housing, gasket 13 (foldout 6,B) must be used when the transmission is attached to the engine housing. Proceed to paragraph 7-13.

b. Direct Mount (drive ring)

(1) Install torque converter drive cover 12 (foldout 6,B). Install twenty-four 5/16-24, self-locking nuts 11 to retain torque converter cover 12. Tighten the nuts to 14-18 lb ft (19-24 N·m).

(2) Lubricate sealring 10 with a high quality molybdenum disulfide grease, and install it into the groove behind the splines on converter drive cover 12.

(3) Apply sealer (Permatex No. 3 or equivalent) to drive ring 8 and to the drive ring mounting face on the engine flywheel or drive disk (also to gasket 13, if used). Install converter drive ring 8 and attach it with

eight 3/8-16 x 1-1/4-inch, 12-point bolts 9. Tighten the bolts to 36-43 lb ft (49-58 N·m). Pack the spaces between the internal teeth of drive ring 8 with molybdenum disulfide grease. Fill the spaces between the teeth completely, but do not use an excessive amount of grease. Proceed to paragraph 7-13.

c. Remote Mount (foldout 6,A)

(1) Install torque converter drive cover 20 or 24 and attached parts (as assembled in para 6-5) onto the converter pump. Install twenty-four 5/16-24 self-locking nuts 19 to retain the cover. Tighten the nuts to 14-18 lb ft (19-24 N·m).

(2) Install gasket 14 onto the converter housing front splitline. Install transmission front cover 13 with oil seal 11 (as assembled in para 6-4) and secure it with twelve 3/8-24 x 2-inch bolts 12, lockwashers 21, and 3/8-24 nuts 22. Tighten the nuts to 33-40 lb ft (45-54 N·m).

(3) Install spacer 3, if required. Install coupling assembly 8 or input flange 9 or 10 onto input shaft 18 or 23. Refer to paragraph 4-9b for instructions for installation, shim pack selection, and torque requirements.

7-13. INSTALLATION OF EXTERIOR COMPONENTS

a. External Thermostat. If required, install external thermostat kit 33 (foldout 7,B).

b. Oil Pump

(1) Install the gasket and oil pump assembly onto the pump mounting pad (fig. 7-83).

(2) Retain the pump with two 3/8-16 x 3-inch bolts, seven 3/8-16 x 2-inch bolts, and nine lockwashers (fig. 7-84). Tighten the bolts to 26-32 lb ft (36-43 N·m).

NOTE

If the pump assembly has a two-bolt, SAE C mounting pad, install six 3/8-16 x 2-inch bolts, three 3/8-16 x 3-inch bolts, and




Fig. 7-83. Installing oil pump assembly

S1501




Fig. 7-85. Installing control valve body assembly

S2538




Fig. 7-84. Installing oil pump assembly

S1421




Fig. 7-86. Installing valve body bolts

S2537

nine lockwashers. Tighten these bolts to 26-32 lb ft (36-43 N·m).

c. Oil Pump Drive Coupling. If the transmission is equipped with adapter drive coupling 18 (foldout 18,A), replace the coupling. Apply molybdenum disulfide grease (Molykote Type G or equivalent) onto the coupling splines and the mating splines of the pump. Install the drive coupling into the pump and retain it temporarily with a strip of tape.

d. Control Valve Body

(1) Remove the temporarily installed bolt and washer from the valve body mounting pad (refer to fig. 7-17). Install the valve body gasket and retain it with oil-soluble grease (fig. 7-85). Install the control valve body assembly.

(2) Install fifteen 3/8-16 x 2-1/2-inch bolts with lockwashers and one hidden 3/8-16 x 1-inch bolt and lockwasher (fig. 7-86). Progressing from the center of the valve body

ASSEMBLY OF TRANSMISSION

outward, tighten the bolts evenly to 26-32 lb ft (36-43 N·m).

e. Parking Brake, Output Flanges

(1) Install the brake backplate onto its mounting pad (fig. 7-87). Install and tighten the bolts. Refer to foldout 17,B.

Model	Back-plate	Bolts	Torque lb ft (N·m)
TT, TRT-1	2	7 (4)	81-97 (110-131)
TTB	8	7 (4)	81-97 (110-131)
TRT-3	13	20 (3) with lock- washers	117-140 (159-189)

(2) Install the spacer roller onto the backplate lever, and install the cam lever (fig. 7-88).

(3) Install two brake shoes (fig. 7-89). Install the two springs into the brake shoe holes away from the backplate. Install spacer 33 (foldout 17,A), if used, onto the output shaft. If flange 31, 32, or 34 is used, install the rear output flange. Install shaft sealing 37, making sure that it is well seated in the cavity between the shaft and flange. (Seal-ring not used in some models.) Refer to paragraph 4-9b for instructions for flange installation and torque requirements.






Fig. 7-87. Installing parking brake backplate

S2616



S2617

Fig. 7-88. Installing brake apply arm




S2618

Fig. 7-89. Installing rear output flange

(4) For transmission equipped with output flanges 35 or 36 (foldout 17,A), install the flange into brake drum 9 or 18 (foldout 17,B) and retain it with 3/8-24 self-locking bolts. Tighten the bolts to 41-49 lb ft (56-66 N·m) and install the assembly onto the output shaft. Refer to paragraph 4-9b for instructions for installation and torque requirements.


(5) If flange 31 or 32 (foldout 17,A) is used, install the brake drum onto the output flange (fig. 7-90); then rotate the drum 90°. For -1 models, attach the brake drum with four 3/8-24 x 5/8-inch, self-locking bolts (fig.

TT, TTB, TRT 2001 SERIES TRANSMISSIONS



S2620

Fig. 7-90. Installing parking brake drum




S2535

Fig. 7-91. Installing parking brake drum (some -1 models)

7-91). For -3 models, install eight 3/8-24 x 3/4-inch self-locking bolts (fig. 7-92). Tighten the bolts to 41-49 lb ft (56-66 N·m).


(6) For -1 models, install spacer 5 (foldout 17,A), if used, onto the output shaft and install the front output flange (fig. 7-93). Install shaft sealring 3 (foldout 17,A), making sure that it is well seated in the cavity between the shaft and flange. (Sealring is not used in some models.) Refer to paragraph 4-9b for instructions for flange installation and torque requirements.

(7) Tighten PTO flange retaining nut 29 (foldout 16,D) to 275-325 lb ft (373-440 N·m).



S1398

Fig. 7-92. Installing parking brake drum (-3 models)



S2621

Fig. 7-93. Installing front output flange

7-14. ASSEMBLY TECHNIQUES FOR VEHICLE-MOUNTED TRANSMISSIONS

a. Similar Procedures. Components are installed into the transmission in the vehicle by methods similar to those used when the transmission is removed. The methods and

ASSEMBLY OF TRANSMISSION

sequence outlined in the manual are a general guide but may require some variation because of positioning and space limitations.

b. Clutch Installation

(1) Special care is required to install clutch assemblies into a transmission mounted in the vehicle. Make sure that all clutch plates are properly engaged with their mating components and that all clutch springs are properly positioned.

(2) The reverse clutch requires that the clutch components be installed as an assembled unit. The assembly of the reverse clutch components results in a clutch and planetary unit similar to that shown in figure 7-94.

(3) Using two wires or cords, tie the clutch plates to the clutch anchor assembly by passing the wires or cords over the opposite tangs of the clutch plates, around the inner side of the anchor pins, and through the adjacent holes in the anchor (fig. 7-94). Secure the wire or cord ends at the under (rear) side of the clutch anchor.




Fig. 7-94. Reverse clutch plates and planetary wired in position on forward-and-reverse clutch anchor

(4) Install the entire assembly, clutch plates first, into the rear of the transmission, engaging the anchor pin slot with the anchor in the transmission housing. Remove the wires or cords and continue with the assembly procedures as applicable.

Section 8. WEAR LIMITS AND SPRING DATA

8-1. WEAR LIMITS DATA

a. Maximum Variations. The wear limits information in this section shows the maximum wear at which components are expected to function satisfactorily. Table 8-1 lists the wear limits data and is referenced to the exploded view (foldouts 6 through 18) in the back of the manual.

b. Cleaning, Inspection. Parts must be clean to permit effective inspection for wear or damage. Refer to paragraph 4-6.

c. Bearings, Bearing Journals, B o r e s. The application of bearings to any product is based on the recommendations of the bearing manufacturer and, therefore, no diametral dimensional deviation should be permitted in the bearing or mated parts. Bearings should be carefully checked for signs of distress before reinstalling.

d. Gears. Gears should be inspected for load pattern and signs of distress. Any distress indicates a possible future failure, and the reuse of such gears should be the decision of the individual customer, based on experience. Backlash cannot be used to establish critical wear of a gear. A gear usually pits, scuffs, scores, or galls long before the gear wear becomes critical.

e. Splines. Unless severe, spline wear is not considered detrimental except where it affects tightness of an assembly s u c h a s driveline flanges. Backlash cannot be used to establish critical wear because both mating

parts must be concentrically located to obtain accurate measurement of backlash.

f. Hook-type Sealrings. Sides of the sealring should be smooth—maximum wear 0.005 inch (0.12 mm). The sides of the groove into which the sealrings fit should be smooth—50 microinch (1.25 micrometers) equivalent, and square with the axis of rotation within 0.002 inch (0.05 mm). A new sealring should be installed if the groove is reworked or if there is wear on the sealring outside the diameter.

8-2. SPRING DATA

a. Springs must be clean to permit effective inspection. Springs should be replaced if there are signs of overheating, wear due to rubbing adjacent parts, or permanent set. Discard springs which do not meet the load-height specifications in Spring Data Table 8-2.

b. Inspection criteria (load versus height) a n d identification characteristics of the springs a r e presented in Table 8-2. The spring data are keyed to the exploded views (foldouts 6 through 18) in the b a c k of the manual.

NOTE

When more than one spring part member is listed for the same location, refer to parts catalog SA 1248 to determine which spring is used for your specific assembly number.

TT, TTB, TRT 2001 SERIES TRANSMISSIONS

Table 8-1. WEAR LIMITS

Illustration	Description	Wear Limit	
		in.	(mm)
Foldout 7,B	TORQUE CONVERTER HOUSING AND TURBINE DRIVE GEARS		
25	Thrust bearing front race, min thickness	0.028	0.71
27	Thrust bearing rear race, min thickness	0.120	3.04
Foldout 8,A	TURBINE DRIVEN GEARS AND FREEWHEEL CLUTCH		
9, 23	* Freewheel roller, min diameter	0.4980	12.65
12, 26	* Freewheel cam, max surface wear	0.003	0.07
28	* First-turbine driven gear hub, min OD	3.0327	77.02
Foldout 9,B	REVERSE CLUTCH AND PLANETARY		
5, 17	Clutch plate: min thickness	0.097	2.46
	max cone	0.030	0.76
6, 18	Clutch plate: min thickness	0.130	3.30
	max cone	0.012	0.30
	** Clutch pack, min thickness	1.185	30.09
11	Pinion, max end play in carrier 15	0.055	1.39
20	Clutch anchor, max face wear reverse face	0.020	0.50
	forward face	0.020	0.50
Foldout 10,A	FORWARD CLUTCH AND PLANETARY (-1 MODELS)		
2	Thrust washer, min thickness	0.125	3.17
7, 14, 21	Pinion, max end play in carrier	0.055	1.39
24	Thrust washer, min thickness	0.089	2.26
26	Clutch plate: min thickness	0.130	3.30
	max cone	0.012	0.30
27	Clutch plate: min thickness	0.097	2.46
	max cone	0.030	0.76
	** Clutch pack, min thickness		
	6-plate pack	0.681	17.29
	8-plate pack	0.908	23.06

* Total wear of freewheel parts (2 x roller wear + sum of cam surface wear at two opposing points + gear hub wear) must not exceed 0.010 inch (0.25 mm). (Determine cam surface wear by measuring depth of groove caused by roller contact in the cam pocket.)

** Total of individual plate thicknesses. Replace plates having the most wear with new plates to increase pack thickness.

WEAR LIMITS AND SPRING DATA

Table 8-1. WEAR LIMITS (cont)

Illustration	Description	Wear Limit	
		in.	(mm)
Foldout 10,B	FORWARD CLUTCH AND PLANETARY (TRT 2221-3, 2421-3)		
2	Thrust washer, min thickness	0.087	2.20
4, 31	Bushing, min ID	1.885	47.87
9, 36	Pinion, max end play in carrier	0.055	1.39
12, 15	Clutch plate:		
	min thickness	0.130	3.30
	max cone	0.012	0.30
13, 16	Clutch plate:		
	min thickness	0.097	2.46
	max cone	0.030	0.76
27	Adapter sleeve	no scoring permissible	
	* Clutch pack, min thickness	0.691	17.55
Foldout 11,A	FORWARD CLUTCH AND PLANETARY (TRT 2211-3, 2411-3)		
2	Thrust washer, min thickness	0.125	3.17
8	Pinion, max end play in carrier 4	0.055	1.39
13, 16	Clutch plate:		
	min thickness	0.130	3.30
	max cone	0.012	0.30
14, 17	Clutch plate:		
	min thickness	0.097	2.46
	max cone	0.030	0.76
	* Clutch pack, min thickness	0.691	17.55
Foldout 11,B	HIGH-RANGE CLUTCH AND PISTON HOUSING (TT MODELS)		
3	Transfer drive gear, max face wear	0.020	0.50
8, 13	Clutch plate:		
	min thickness	0.130	3.30
	max cone	0.012	0.30
9	Clutch plate:		
	min thickness	0.097	2.46
	max cone	0.030	0.76
	* Clutch pack, min thickness	0.357	9.06
	Max diametral clearance between:		
10, 12	high-range clutch hub and		
23, 33	bushing in piston housing		
	24, 34, 36, or 37	0.005	0.12
18	Sealring, min thickness	0.0880	2.23
19	Piston, max face wear	0.020	0.50
27, 29	Sealring, min thickness	0.0875	2.22

* Total of individual plate thicknesses. Replace plates having the most wear with new plates to increase pack thickness.

TT, TTB, TRT 2001 SERIES TRANSMISSIONS

Table 8-1. WEAR LIMITS (cont)

Illustration	Description	Wear Limit	
		in.	(mm)
Foldout 12,A	LOW-RANGE CLUTCH AND TRANSFER DRIVE GEAR (TRT-1 MODELS)		
9	Adapter sleeve	no scoring permissible	
19	Clutch piston, max face wear	0.010	0.25
23	Sleeve bushing, max ID	2.008	51.00
26, 29	Clutch plate:		
	min thickness	0.130	3.30
	max cone	0.012	0.30
27, 30	Clutch plate:		
	min thickness	0.097	2.46
	max cone	0.030	0.76
31	Backplate, max face wear	0.010	0.25
	* Clutch pack, min thickness	0.841	21.36
Foldout 12,B	HIGH-RANGE CLUTCH AND PLANETARY (TRT-1 MODELS)		
1	High-range sun gear assembly, min thickness	1.718	43.63
7	Pinion, max end play in carrier 5	0.055	1.39
13	Anchor, max face wear (rear)	0.020	0.50
16	Clutch plate:		
	min thickness	0.130	3.30
	max cone	0.012	0.30
17	Clutch plate:		
	min thickness	0.097	2.46
	max cone	0.030	0.76
	* Clutch pack, min thickness	1.135	28.82
Foldout 13,A	HIGH-RANGE CLUTCH, LOW-RANGE RING GEAR (TRT 2211-3, 2421-3 UNDERDRIVE)		
8	Clutch piston, max face wear	0.010	0.25
12, 15	Clutch plate:		
	min thickness	0.130	3.30
	max cone	0.012	0.30
13, 16	Clutch plate:		
	min thickness	0.097	2.46
	max cone	0.030	0.76
17	Backplate, max face wear	0.010	0.25
	* Clutch pack, min thickness	0.595	15.11
Foldout 13,B	LOW-RANGE CLUTCH AND PLANETARY (TRT 2221-3, 2421-3 UNDERDRIVE)		
1	Low-range sun gear assembly, min thickness	1.718	43.63

* Total of individual plate thicknesses. Replace plates having the most wear with new plates to increase pack thickness.

WEAR LIMITS AND SPRING DATA

Table 8-1. WEAR LIMITS (cont)

<u>Illustration</u>	<u>Description</u>	<u>Wear Limit</u>	
		<u>in.</u>	<u>(mm)</u>
Foldout 13,B (cont)	LOW-RANGE CLUTCH AND PLANETARY (TRT 2221-3, 2421-3 UNDERDRIVE) (cont)		
7	Pinion, max end play in carrier 5	0.055	1.39
13	Clutch anchor, max face wear (rear)	0.020	0.50
16	Clutch plate:		
	min thickness	0.130	3.30
	max cone	0.012	0.30
17	Clutch plate:		
	min thickness	0.097	2.46
	max cone	0.030	0.76
	* Clutch pack, min thickness	1.185	29.09
Foldout 14,A	LOW-RANGE CLUTCH, HIGH-RANGE PLANETARY		
8	Clutch piston, max face wear	0.010	0.25
12	Thrust bearing race, min thickness	0.028	0.71
14	Thrust bearing race, min thickness	0.182	4.62
16	Clutch plate:		
	min thickness	0.130	3.30
	max cone	0.012	0.30
17	Clutch plate:		
	min thickness	0.097	2.46
	max cone	0.030	0.76
19	Carrier, max face wear (front)	0.010	0.25
23	Pinion, max end play in carrier 19	0.055	1.39
	* Clutch pack, min thickness	1.108	28.14
Foldout 14,B	HIGH-RANGE CLUTCH, PLANETARY SUN AND RING GEARS		
4	Clutch anchor, max face wear (rear)	0.020	0.50
7, 10	Clutch plate:		
	min thickness	0.130	3.30
	max cone	0.012	0.30
8, 11	Clutch plate:		
	min thickness	0.097	2.46
	max cone	0.030	0.76
	* Clutch pack, min thickness	0.721	18.31
Foldout 15,A	HIGH-RANGE CLUTCH AND PISTON HOUSING (TTB MODELS)		
3	Transfer drive gear, max face wear	0.020	0.50
8, 13	Clutch plate:		
	min thickness	0.130	3.30
	max cone	0.012	0.30

* Total of individual plate thicknesses. Replace plates having the most wear with new plates to increase pack thickness.

TT, TTB, TRT 2001 SERIES TRANSMISSIONS

Table 8-1. WEAR LIMITS (cont)

<u>Illustration</u>	<u>Description</u>	<u>Wear Limit</u>	
		<u>in.</u>	<u>(mm)</u>
Foldout 15,A (cont)	HIGH-RANGE CLUTCH AND PISTON HOUSING (TTB MODELS) (cont)		
9	Clutch plate:		
	min thickness	0.097	2.46
	max cone	0.030	0.76
18	* Clutch pack, min thickness	0.357	9.06
19	Sealring, min thickness	0.880	2.23
	Piston, max face wear	0.020	0.50
	Max diametral clearance between:		
12	high-range clutch hub and		
34	bushing in piston housing 35	0.005	0.12
Foldout 15,B	INTERNAL BRAKE AND REAR COVER (TTB MODELS)		
14	Brake plate:		
	min thickness	0.097	2.46
	max cone	0.030	0.76
15	Brake plate:		
	min thickness	0.130	3.30
	max cone	0.012	0.30
	* Brake pack, min thickness	1.232	31.29
38	Rear cover, brake cylinder bores, max ID	1.6290	41.37
Foldout 17,A	OUTPUT SHAFTS AND DISCONNECT ASSEMBLY		
	Max diametral clearance between:		
13	front output shaft and		
25	bushing in output shaft 26	0.010	0.25
Foldout 18,A	OIL PUMP ASSEMBLIES		
3	Cover	no scoring permissible	
12	Driven gear shaft, min OD	0.749	19.02
Foldout 18,B	CONTROL VALVE ASSEMBLIES		
8	Valve, max clearance in body 9	0.004	0.10
16	Plug, max clearance in body 9	0.0035	0.09
20	Valve, max clearance in body 9	0.004	0.10
21	Valve plug, max clearance in plug 25	0.004	0.10
29, 39, 42	Valve, max clearance in body 9	0.003	0.07
45	Valve plug, max clearance in body 9	0.004	0.10
49	Valve plug, max clearance in plug 50	0.004	0.10
52	Valve, max clearance in body 9	0.003	0.07

* Total of individual plate thicknesses. Replace plates having the most wear with new plates to increase pack thickness.

Table 8-2. SPRING DATA

Fold-out	Ref.	Spring	Part No.	Color Code	No. Coils	Wire dia in. (mm)	Spring OD in. (mm)	Free Length in. (mm)	Length Under Load in. (mm)	lb. (N)
7,B	19	Lubrication pressure regulator valve	6773689	No color	13.5	0.048 (1.22)	0.403 (10.24)	1.44 (36.6)	1.00 (25.4)	5.6-6.8 (25-30)
7,B	22	Converter pressure regulator valve	6773551	Solid red, white stripe	10	0.080 (2.03)	0.468 (11.89)	1.21 (30.7)	1.00 (25.4)	23.4-28.6 (105-127)
			6880795	Solid light blue	12	0.067 (1.70)	0.434 (11.02)	1.55 (39.4)	1.02 (25.9)	31.4-34.6 (140-153)
8,A	7,21	Freewheel clutch	6774681	No color	19	0.041 (1.04)	0.251 (6.38)	1.22 (31.0)	1.00 (25.4)	5.3-6.3 (24-28)
			6833973	No color	26	0.033 (0.84)	0.175 (4.44)	1.41 (35.8)	1.14 (29.0)	6.1-7.2 (28-32)
			6835343	No color	27	0.033 (0.84)	0.185 (4.70)	1.50 (38.1)	1.14 (29.0)	6.1-7.2 (28-32)
9,B	22	Reverse, low-range clutch piston return	6772068	No color	37	0.105 (2.67)	0.625 (15.88)	5.51 (140.0)	4.18 (106.2)	44.8-49.6 (200-220)
			6775437	Green stripe	37.5	0.105 (2.67)	0.625 (15.88)	6.13 (155.7)	4.80 (121.9)	45.1-49.9 (201-222)
11,B	17	High-range clutch piston return	6756134	No color	Belleville spring		5.14 (130.6)	0.28 (7.1)	-	-
12,A	20	Low-range clutch piston return	6759491	No color	Belleville spring		6.70 (170.2)	0.27 (6.9)	-	-
12,B	19	High-range clutch piston return	6759491	No color	Belleville spring		6.70 (170.2)	0.27 (6.9)	-	-
13,A	9	High-range clutch piston return	6759491	No color	Belleville spring		6.70 (170.2)	0.27 (6.9)	-	-
13,B	19	Low-range clutch piston return	6759491	No color	Belleville spring		6.70 (170.2)	0.27 (6.9)	-	-
14,A	9	Low-range clutch piston return	6777032	No color	Belleville spring		6.70 (170.2)	0.27 (6.9)	-	-
14,B	13	High-range clutch piston return	6777032	No color	Belleville spring		6.70 (170.2)	0.27 (6.9)	-	-
15,A	17	High-range clutch piston return	6756134	No color	Belleville spring		5.14 (130.6)	0.28 (7.1)	-	-

WEAR LIMITS AND SPRING DATA

Table 8-2. SPRING DATA (cont)

Fold-out	Ref.	Spring	Part No.	Color Code	No. Coils	Wire dia in. (mm)	Spring OD in. (mm)	Free Length in. (mm)	Length Under Load in. (mm)	lb. (N)
15,B	11	Hydraulic brake return (TTB models)	6758503	No color	20	0.092 (2.34)	0.625 (15.88)	3.20 (81.3)	2.38 (60.5)	27.9-34.1 (125-151)
			6765710	No color	18.5	0.080 (2.03)	0.625 (15.88)	3.04 (77.2)	2.08 (52.8)	18.9-23.1 (85-102)
			6831441	No color	20	0.080 (2.03)	0.622 (15.80)	3.86 (98.0)	2.94 (74.7)	16.7-20.3 (75-90)
17,A	15	Disconnect detent	6773464	No color	14	0.062 (1.57)	0.353 (8.97)	1.32 (33.5)	1.15 (29.2)	11.9-14.5 (53-64)
17,B	5	Parking brake shoe-to-shoe*	9027076	Solid black	12	0.072 (1.83)	0.500 (12.70)	-	2.62 (66.5)	20.0* (89)
17,B	16	Parking brake shoe-to-shoe*	6758260	Solid black	18	0.142 (3.61)	0.812 (20.62)	4.00 (101.6)	4.62 (117.3)	60.0-75.0* (267-333)
18,B	14	Main-pressure regulator valve: 135-170 psi (931-1172 kPa)	6833211	Green stripe	18.5	0.127 (3.23)	0.772 (19.61)	3.62 (91.9)	2.50 (63.5)	90.0-102.0 (401-453)
			6834941	No color	17	0.125 (3.18)	0.768 (19.51)	3.62 (91.9)	2.50 (63.5)	90.0-102.0 (401-453)
			6835377	Blue stripe	17	0.118 (3.00)	0.754 (19.15)	3.61 (91.7)	2.50 (63.5)	80.0-90.0 (356-400)
		160-195 psi (1104-1344 kPa)	6835705	No color	16	0.125 (3.18)	0.765 (19.43)	3.64 (92.5)	2.50 (63.5)	100.0-110.0 (445-489)
			6885165	Solid white	17.6	0.128 (3.25)	0.777 (19.74)	3.66 (93.0)	2.50 (63.5)	100.0-110.0 (445-489)
18,B	15	Trimmer	6773593	No color	10	0.131 (3.33)	1.120 (28.45)	2.90 (73.7)	2.38 (60.5)	25.6-31.2 (114-138)
			6830365	No color	8	0.128 (3.25)	1.110 (28.19)	2.58 (65.5)	1.43 (36.3)	72.2-82.2 (322-365)

*Tension spring

Table 8-2. SPRING DATA (cont)

<u>Fold-out</u>	<u>Ref.</u>	<u>Spring</u>	<u>Part No.</u>	<u>Color Code</u>	<u>No. Coils</u>	<u>Wire dia in. (mm)</u>	<u>Spring OD in. (mm)</u>	<u>Free Length in. (mm)</u>	<u>Length Under Load in. (mm)</u>	<u>lb. (N)</u>
18,B	19	Clutch cutoff valve: 130 psi (896 kPa)	6765710	No color	18.5	0.080 (2.03)	0.625 (15.88)	3.04 (77.2)	2.08 (52.8)	18.9-23.1 (85-102)
			6831441	No color	20	0.080 (2.03)	0.622 (15.80)	3.86 (98.0)	2.94 (74.7)	16.7-20.3 (75-90)
		250 psi (1724 kPa)	6758503	No color	20	0.092 (2.34)	0.625 (15.88)	3.20 (81.3)	2.38 (60.5)	27.9-34.1 (125-151)
			23017350	Solid yellow, green end	20	0.092 (2.34)	0.625 (15.88)	3.20 (81.3)	2.03 (51.6)	39.6-48.4 (177-215)
		400 psi (2758 kPa)	6830366	Solid white	16.5	0.112 (2.84)	0.625 (15.88)	2.72 (69.1)	2.04 (51.8)	71.0-86.6 (316-385)
18,B	33	Selector valve detent	6769251	No color	10	0.062 (1.57)	0.480 (12.19)	1.14 (29.0)	0.78 (19.8)	13.6-14.0 (61-62)
			6770253	White stripe	11	0.054 (1.37)	0.480 (12.19)	1.24 (31.5)	0.78 (19.8)	7.6-8.4 (34-37)
			6833934	Solid white, orange stripe	10	0.054 (1.37)	0.490 (12.45)	1.47 (37.3)	0.080 (20.3)	11.9-13.1 (53-58)
18,B	38	Inching regulator front	6770298	No color	14.6	0.041 (1.04)	0.384 (9.75)	1.28 (32.5)	0.78 (19.8)	3.93-4.07 (17.5-18.1)
			6772046	No color	15.5	0.085 (2.16)	0.810 (20.57)	3.75 (95.2)	1.95 (49.5)	25.2-27.8 (113-123)
18,B	41	Inching regulator rear	6774595	No color	21.5	0.072 (1.83)	0.585 (14.86)	3.80 (96.5)	2.00 (50.8)	25.2-27.8 (113-123)
			6838473	No color	26.4	0.090 (2.29)	0.620 (15.75)	4.29 (109.0)	2.50 (63.5)	41.9-51.1 (187-227)
18,B	43	Inching valve return	6774594	No color	17	0.120 (3.05)	1.105 (28.07)	5.75 (146.0)	4.04 (102.6)	28.5-31.5 (127-140)

WEAR LIMITS AND SPRING DATA

Section 9. OWNER ASSISTANCE AND SERVICE LITERATURE

9-1. OWNER ASSISTANCE

The satisfaction and goodwill of the owners of Allison transmissions are of primary concern to Detroit Diesel Allison, its distributors, and their dealers.

As an owner of an Allison transmission, you have service locations throughout the U.S. and Canada, plus many outlets worldwide that are prepared and eager to meet your parts and service needs with:

- Expert service by trained personnel
- Emergency service 24 hours a day in many areas
- Complete parts support
- Sales teams to help determine your power requirements
- Product information and literature

We recognize, however, that despite the best intentions of everyone concerned, misunderstandings may occur. Normally, any such situation that arises in connection with the sale, operation, or service of your transmission will be handled by the distributor or dealer in your area (check the Yellow Pages for the Detroit Diesel Allison service outlet nearest you).

To further assure your complete satisfaction, we have developed the following three-step procedure to be followed in the event you have a problem that has not been handled satisfactorily.

Step One—Discuss your problem with a member of management from the distributorship or dealership. Frequently, complaints are the result of a breakdown in communication and can quickly be resolved by a member of management. If you have already discussed the problem with the Sales or Service Manager, contact the General Manager. If your problems originate with a dealer, explain the matter to a management

member of the distributorship with whom the dealer has his service agreement.

Step Two—When it appears that your problem cannot readily be resolved at the distributor level without additional assistance, contact the Detroit Diesel Allison Regional Office nearest you listed below:

EASTERN REGION

9 Sylvan Way
P.O. Box 3001
Parsippany, New Jersey 07054 USA
Phone: (201) 993-4047
TWX: 710-998-0563

SOUTHEASTERN REGION

5730 Glenridge Drive, NE
Atlanta, Georgia 30328 USA
Phone: (404) 257-3640
TWX: 810-751-8141

GREAT LAKES REGION

Suite 365
New Center One Building
3031 W. Grand Blvd.
P.O. Box 33122 (N65)
Detroit, Michigan 48232 USA
Phone: (313) 556-5400
TWX: 810-221-6283

MIDWESTERN REGION

475 Alexis R. Shuman Blvd.
Naperville, Illinois 60566 USA
Phone: (312) 961-6750
TWX: 910-651-3032

SOUTHWESTERN REGION

General Motors Building
130 E. Carpenter Freeway
Irving, Texas 75062 USA
Phone: (214) 659-5070
TWX: 910-860-5063

WESTERN REGION

Suite 2700
39465 Paseo Padre Parkway
Fremont, California 94538 USA
Phone: (415) 498-5200
TWX: 910-381-6105

TT, TTB, TRT 2001 SERIES TRANSMISSIONS

CANADA

Diesel Division - GM of Canada Ltd.
P. O. Box 5990
600 Clarke Road
London, Ontario N6A 4L6, Canada
Phone: (519) 452-5000
Telex: 064-5850
TWX: 610-352-0269

LATIN AMERICAN REGION

Detroit Diesel Allison
Gables Center, suite 321
95 Merrick Way
Coral Gables, Florida 33144 USA
Phone: (305) 446-4900
Telex: 810-848-7061

EUROPEAN REGION

Detroit Diesel Allison - Europe
Div. of GM Continental, S.A. Nederland
Parmentierplein 1, 3088 GN Rotterdam
Mail: P. O. Box 5061
3008 AB Rotterdam, Netherlands
Phone: 010-290-000
Telex: 28355 GMCNL

ASIA REGION

Detroit Diesel Allison
Div. of GM Oversea Corp.
15 Benoi Sector
Jurong Town, Singapore 2262
Phone: (65) 265-4697 or (65) 261-0801
Telex: RS 21608 A/B GM SING

MIDDLE EAST/AFRICA REGION

Detroit Diesel Allison
Athens Towers, "A" Bldg., 6th Floor
Messoghion 2/4
Athens 610, Greece
Phone: (30) 1-770-6669
(30) 1-778-5344
(30) 1-778-7281
Telex: 215759 DDA

PACIFIC REGION

Detroit Diesel Allison - Australia
Div. of GM Overseas Corp.
Princes Highway, P. O. Box 163
Dandenong, Victoria 3175
Australia
Phone: (61) 3-797-7911
Telex: AA30792

Step Three—If you are still not satisfied, present the entire matter in writing or by phone to the product headquarters:

Allison Transmission Operations: Manager Off-Highway Transmissions Service, Detroit Diesel Allison, P. O. Box 894, Indianapolis, Indiana 46206. Phone: (317) 242-3549.

The inclusion of all pertinent information will assist the Home Office in expediting the matter. If an additional review by the Home Office of all the facts involved indicates that some further action can be taken, the Regional Office will be so instructed.

If at this point your problem is still not resolved to your satisfaction, call or write: Manager Transmission Service, Indianapolis Operations (317) 242-3547 or Director Transmission Sales, Indianapolis Operations, (317) 242-3584.

When contacting the Regional or Home Office, please keep in mind that ultimately your problem will likely be resolved at the distributorship or dealership utilizing their facilities, equipment, and personnel. Therefore, it is suggested that you follow the above steps in sequence when experiencing a problem.

Your purchase of a Detroit Diesel Allison product is greatly appreciated, and it is our sincere desire to assure complete satisfaction.

9-2. SERVICE LITERATURE

Additional service literature is available for the owner who takes pride in his equipment. These books provide fully illustrated instructions for the maintenance, service, overhaul, and parts support of your transmission. To ensure that you get maximum performance and service life from your unit, see your dealer or distributor for the following publications. Check the Yellow Pages under Transmissions — Truck or Engines — Diesel for your nearest authorized service outlet.

OWNER ASSISTANCE AND SERVICE LITERATURE

TT, TTB, TRT 2001
Transmission Publications

For Allison Transmission information, the
number is:

1200, 1400, 2000 Series
Parts Catalog SA 1248

(317) 242-INFO

TT, TTB, TRT 2001, 3000, 4000
Operators Manual SA 1278

For off hours and times when all "INFO" lines
are busy, telephone answering equipment will
provide the opportunity for the caller to leave
a name and phone number for a prompt re-
turn call or call back on the next business day.

9-3. FACTORY SERVICE "INFO"


Detroit Diesel Allison maintains factory serv-
ice "INFO" telephone lines to respond to cus-
tomer needs on a timely basis when the nor-
mal channels of communications a r e not
available. "INFO" lines, created as part of
Detroit Diesel Allison's customer response
effort, are open between 8:00 a.m. and 4:30
p.m. (local time).

As a reminder, the service "INFO" lines are
not intended to bypass the normal channels of
communication, but rather to provide direct
factory assistance when normal contacts are
not available. Therefore, you are urged to
use the three-step procedure outlined under
"Owner Assistance" prior to using the service
"INFO" telephone line(s).


- 1 - Flex disk drive assembly
- 2 - Torque converter cover
- 3 - Second turbine
- 4 - First turbine
- 5 - Torque converter stator
- 6 - Torque converter pump
- 7 - Input flange
- 8 - Transmission front cover
- 9 - Torque converter drive cover
- 10 - Accessory-driven gear
- 11 - Transmission housing
- 12 - Oil suction tube
- 13 - Oil pump
- 14 - Accessory pump mounting pad
- 15 - First-turbine drive gear
- 16 - Reverse clutch piston
- 17 - Reverse clutch
- 18 - Reverse planetary pinion
- 19 - Forward (low-range) clutch
- 20 - Forward (low-range) piston
- 21 - Forward (low-range) planetary pinion
- 22 - Transfer drive gear
- 23 - Transmission rear cover
- 24 - High-range clutch
- 25 - High-range clutch hub
- 26 - Forward-and-reverse sun gear
- 27 - High-range piston
- 28 - Forward (low-range) planetary carrier assembly
- 29 - Rear output flange
- 30 - Rear output shaft

- 31 - Parking brake
- 32 - Transfer-driven gear
- 33 - Forward-and-reverse clutch anchor
- 34 - Disconnect coupling
- 35 - Disconnect shifter fork
- 36 - Front output shaft
- 37 - Front output flange
- 38 - Forward (low-range) ring gear
- 39 - Disconnect shifter shaft
- 40 - Reverse ring gear
- 41 - Reverse planetary carrier assembly
- 42 - First-turbine driven gear
- 43 - Freewheel clutch
- 44 - Second-turbine driven gear
- 45 - Second-turbine drive gear
- 46 - Torque converter housing
- 47 - Accessory drive gear
- 48 - Converter-driven PTO output flange
- 49 - Converter-driven PTO shaft
- 50 - Internal brake
- 51 - Brake-apply plate
- 52 - Brake piston
- 53 - Rear cover plug
- 54 - Diaphragm
- 55 - Output-driven PTO output shaft
- 56 - One-piece output shaft
- 57 - Shifter shaft hole plug
- 58 - Converter diaphragm
- 59 - Plug
- 60 - Oil seal

TT, TTB, TRT 2001 SERIES TRANSMISSIONS




**DIRECT MOUNT
(WITH DIAPHRAGM,
FOR "DRY" HOUSING)**




**REMOTE MOUNT
(WITHOUT DIAPHRAGM,
FOR "WET" HOUSING)**


TWO-PIECE OUTPUT SHAFT




ONE-PIECE OUTPUT SHAFT




**TT WITH CONVERTER
DRIVEN PTO**



**TT WITH OUTPUT
DRIVEN PTO**




TTB WITHOUT PTO



**TTB WITH CONVERTER
DRIVEN PTO**

- | | |
|--------------------------------|--|
| 1 - Flex disk drive | 25 - High-range clutch piston |
| 2 - Torque converter cover | 26 - Output shaft |
| 3 - Torque converter housing | 27 - High-range sun gear |
| 4 - Second turbine | 28 - High-range planetary carrier |
| 5 - First turbine | 29 - High-range ring gear |
| 6 - Converter ground sleeve | 30 - Rear output flange |
| 7 - Accessory driven gear | 31 - Transmission output shaft |
| 8 - Oil suction tube | 32 - Parking brake |
| 9 - Transmission housing | 33 - Forward-and-reverse sun gear |
| 10 - Oil pump drive gear | 34 - Transfer driven gear |
| 11 - Accessory mounting pad | 35 - Forward ring gear |
| 12 - Accessory drive splines | 36 - Forward-and-reverse clutch anchor |
| 13 - First-turbine drive gear | 37 - Front output flange |
| 14 - Second-turbine drive gear | 38 - Forward clutch |
| 15 - Reverse planetary carrier | 39 - Reverse clutch |
| 16 - Forward clutch piston | 40 - Reverse ring gear |
| 17 - Transfer drive gear | 41 - Reverse clutch piston |
| 18 - Forward planetary carrier | 42 - Reverse clutch hub |
| 19 - Adapter | 43 - First-turbine driven gear |
| 20 - Low-range clutch piston | 44 - Second-turbine driven gear |
| 21 - Low-range clutch | 45 - Freewheel clutch |
| 22 - High-range clutch anchor | 46 - Accessory drive gear |
| 23 - High-range clutch | 47 - Converter pump |
| 24 - Rear housing | 48 - Converter stator |

TT, TTB, TRT 2001 SERIES TRANSMISSIONS




S1505

Foldout 2. TRT 2421-1 Transmission

- 1 - Flex disk drive
- 2 - Torque converter cover
- 3 - Torque converter housing
- 4 - Second turbine
- 5 - First turbine
- 6 - Accessory driven gear
- 7 - Oil suction tube
- 8 - Transmission housing
- 9 - Oil pump drive gear
- 10 - Accessory drive coupling
- 11 - Accessory mounting pad
- 12 - First-turbine drive gear
- 13 - Second-turbine drive gear
- 14 - Reverse planetary carrier
- 15 - Rear output housing adapter
- 16 - Forward clutch piston
- 17 - High-range clutch drum
- 18 - High-range clutch
- 19 - Low-range clutch anchor
- 20 - Low-range clutch
- 21 - Low-range clutch piston
- 22 - Transmission output shaft
- 23 - Parking brake


- 24 - Output flange
- 25 - Rear housing
- 26 - Low-range planetary carrier
- 27 - Low-range ring gear
- 28 - Low-range sun gear
- 29 - Forward planetary carrier
- 30 - High-range clutch piston
- 31 - Forward-and-reverse sun gear
- 32 - Forward ring gear
- 33 - Forward clutch
- 34 - Forward-and-reverse clutch anchor
- 35 - Reverse ring gear
- 36 - Reverse clutch
- 37 - Reverse clutch hub
- 38 - Reverse clutch piston
- 39 - First-turbine driven gear
- 40 - Second-turbine driven gear
- 41 - Freewheel clutch
- 42 - Accessory drive gear
- 43 - Diaphragm
- 44 - Torque converter pump
- 45 - Torque converter stator



Foldout 3. TRT 2221-3 Transmission (with underdrive)


- 1 - Flex disk drive
- 2 - Torque converter cover
- 3 - Torque converter housing
- 4 - Second turbine
- 5 - First turbine
- 6 - Diaphragm
- 7 - Accessory driven gear
- 8 - Oil suction tube
- 9 - Transmission housing
- 10 - Oil pump drive gear
- 11 - Adapter coupling
- 12 - Accessory mounting pad
- 13 - First-turbine drive gear
- 14 - Second-turbine drive gear
- 15 - Reverse planetary carrier
- 16 - Adapter
- 17 - Forward clutch piston
- 18 - Low-range clutch drum
- 19 - Low-range clutch
- 20 - High-range clutch anchor
- 21 - High-range clutch
- 22 - High-range clutch piston
- 23 - Output shaft

- 24 - Parking brake
- 25 - Output flange
- 26 - Rear housing
- 27 - High-range sun gear
- 28 - High-range ring gear
- 29 - High-range planetary carrier
- 30 - Low-range clutch hub
- 31 - Low-range clutch piston
- 32 - Forward planetary carrier
- 33 - Forward-and-reverse sun gear
- 34 - Forward clutch
- 35 - Forward ring gear
- 36 - Forward-and-reverse clutch anchor
- 37 - Reverse clutch
- 38 - Reverse clutch hub
- 39 - Reverse clutch piston
- 40 - First-turbine driven gear
- 41 - Second-turbine driven gear
- 42 - Freewheel clutch
- 43 - Accessory drive gear
- 44 - Torque converter pump
- 45 - Torque converter stator



- 1 - Flex disk drive
- 2 - Torque converter cover
- 3 - Torque converter housing
- 4 - Second turbine
- 5 - First turbine
- 6 - Accessory driven gear
- 7 - Oil suction tube
- 8 - Transmission housing
- 9 - Oil pump drive gear
- 10 - Accessory drive coupling
- 11 - Accessory mounting pad
- 12 - First-turbine drive gear
- 13 - Second-turbine drive gear
- 14 - Reverse ring gear
- 15 - Forward clutch piston
- 16 - Forward ring gear
- 17 - Reverse planetary carrier

- 18 - Parking brake
- 19 - Output flange
- 20 - Rear housing
- 21 - Forward-and-reverse sun gear
- 22 - Forward planetary carrier
- 23 - Forward clutch
- 24 - Forward-and-reverse clutch anchor
- 25 - Reverse clutch
- 26 - Reverse clutch hub
- 27 - Reverse clutch piston
- 28 - First-turbine driven gear
- 29 - Second-turbine driven gear
- 30 - Freewheel clutch
- 31 - Accessory drive gear
- 32 - Diaphragm
- 33 - Torque converter pump
- 34 - Torque converter stator



A

- 1 - Flange retaining nut, 1-1/4-12
(nylon insert) A
- 2 - Flange washer
- 3 - Flange spacer
- 4 - Self-locking bolt,
3/8-24 x 1-1/8 in. (2) B
- 5 - Lockstrip
- 6 - Flange retaining washer
- 7 - Shim (as required)
0.025-in. (0.63-mm) thick
0.005-in. (0.13-mm) thick
- 8 - Torqmatic coupling assembly
- 9 - Flange (Mechanics 5C)
- 10 - Flange (Mechanics 6C)
- 11 - Oil seal
- 12 - Bolt, 3/8-24 x 2 in. (12)
- 13 - Transmission front cover
- 14 - Front cover gasket

- 15 - Ball bearing
- 16 - Bolt, 1/2-13 x 1-1/8 in. (6) C
- 17 - Lockstrip (3)
- 18 - Input shaft
- 19 - Self-locking nut, 5/16-24 (24) D
- 20 - Torque converter drive cover
- 21 - Lockwasher, 3/8 in. (12)
- 22 - Nut, 3/8-24 (12) E
- 23 - Input shaft
- 24 - Torque converter drive cover

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	450-700	611-949
<u>B</u>	41-49	56-66
<u>C</u>	67-80	91-108
<u>D</u>	14-18	19-24
<u>E</u>	33-40	45-54


B

- 1 - Self-locking bolt,
1/2-13 x 7/8 in. (6) A
- 2 - Flex disk plate
- 3 - Flex disk (3)
- 4 - Flex disk plate
- 5 - Flex disk and washer assembly
- 6 - Self-locking nut, 5/16-24 (24) B
- 7 - Torque converter drive cover
- 8 - Converter drive ring
- 9 - Twelve-point bolt, 3/8 x
1-1/4 in. (8) C

- 10 - Sealring
- 11 - Self-locking nut, 5/16-24 (24) B
- 12 - Torque converter drive cover
- 13 - Gasket

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	81-97	110-131
<u>B</u>	14-18	19-24
<u>C</u>	36-43	49-58


A



9812A

Foldout 6.A. Transmission front cover and remote-mount input drive

B



19056

Foldout 6.B. Transmission direct-mount input drive

A

- 1 - Ball bearing
- 2 - First turbine and support assembly
- 3 - First-turbine support
- 4 - First turbine
- 5 - First-turbine roll pin
TT, TTB, TRT 2211, 2221 (6)
TT, TTB, TRT 2411, 2421 (9)
- 6 - Second turbine
- 7 - Internal snapping
- 8 - Ball bearing
- 9 - External snapping
- 10 - Torque converter stator
- 11 - Spacer
- 12 - Bolt, 1/4-28 x 1-1/4 in. (12) A
- 13 - Lockstrip (6)

- 14 - Torque converter pump retainer
- 15 - Torque converter pump assembly
- 16 - Special bolt, 5/16-24 x 1.30 in. (24)
- 17 - Torque converter pump gasket
- 18 - Double-row ball bearing
- 19 - Input accessory drive gear
- 20 - Sealring*
- 21 - Sealring

*Not used with "wet" housings

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	10-12	14-16

B


- 1 - Accessory drive gear
- 2 - Accessory-driven gear
- 3 - Bolt, 7/16-14 x 1-3/8 in. (23) A
- 4 - Lockwasher (23)
- 5 - Flat washer (23)
- 6 - Ball bearing
- 7 - External snapping
- 8 - Accessory drive shaft
- 9 - Ball bearing
- 10 - Ball bearing (standard duty)
- 11 - External snapping
- 12 - Ball bearing
- 13 - Converter ground sleeve
- 14 - Self-locking bolt,
5/16-18 x 3/4 in. (4) B
- 15 - Step-joint sealring
- 16 - Ball bearing
- 17 - Second-turbine drive gear
- 18 - Lubrication regulator valve guide pin
- 19 - Lubrication regulator valve spring
- 20 - Lubrication regulator valve
- 21 - Converter pressure regulator valve
guide pin
- 22 - Converter pressure regulator valve
spring
- 23 - Converter pressure regulator valve
- 24 - Step-joint sealring
- 25 - Thrust race
- 26 - Thrust roller bearing
- 27 - Thrust race
- 28 - First-turbine drive gear
- 29 - Ball bearing

- 30 - Lubrication bypass tube
- 31 - External thermostat kit
- 32 - Thermostat assembly
- 33 - Sealring
- 34 - Connector
- 35 - Adapter
- 36 - Converter housing assembly
- 37 - Pipe plug, 3/4 in. NPTF C
- 38 - Converter housing
- 39 - Plug, 1/2-14 PTF D
- 40 - Converter housing sleeve
- 41 - Dowel pin (2)
- 42 - Flat washer, 7/16 in.
- 43 - Lockwasher, 7/16 in.
- 44 - Bolt, 7/16-14 x 2-3/4 in. A
- 45 - Roller bearing (heavy duty)
- 46 - Diaphragm assembly*
- 47 - Oil seal*
- 48 - Diaphragm*
- 49 - Cup plug*
- 50 - Step-joint sealring

*Used with "dry" housings

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	42-50	57-67
<u>B</u>	17-20	24-27
<u>C</u>	33-37	45-50
<u>D</u>	23-27	32-36


A



Foldout 7,A. Torque converter

63778

B



Foldout 7,B. Torque converter housing and turbine drive gears

63780

A

- 1 - Ball bearing
- 2 - Self-locking nut, 3/8-24 (12) A
- 3 - Second-turbine driven gear
- 4 - Ball bearing
- 5 - Spring retainer plate
- 6 - Spring pin (3)
- 7 - Spring (3)
- 8 - Freewheel roller cage
- 9 - Freewheel roller (15)
- 10 - Freewheel cam assembly
- 11 - Roll pin
- 12 - Freewheel cam
- 13 - Retainer plate
- 14 - Square-head bolt (12)
- 15 - Ball bearing
- 16 - Self-locking nut, 3/8-24 (12) A
- 17 - Second-turbine driven gear
- 18 - Ball bearing

- 19 - Spring retainer plate
- 20 - Spring pin (3)
- 21 - Spring (3)
- 22 - Freewheel roller cage
- 23 - Freewheel roller (15)
- 24 - Freewheel cam assembly
- 25 - Roll pin
- 26 - Freewheel cam
- 27 - Square-head bolt (12)
- 28 - First-turbine driven gear
- 29 - Bearing spacer
- 30 - Ball bearing
- 31 - Bearing spacer
- 32 - Ball bearing

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	41-49	56-66


B

- 1 - Self-locking bolt, 3/8-16 x 5/8 in. A
- 2 - Suction tube
- 3 - Male nut, 1 3/4-14 B
- 4 - Suction tube compression sealring
- 5 - Transmission housing gasket
- 6 - Remote filter plug
- 7 - Plug, 3/4-14 NPTF C
- 8 - Transmission housing
- 9 - Breather
- 10 - Cup plug
- 11 - Oil seal
- 12 - Accessory drive cup plug
- 13 - Bolt, 3/8-16 x 7/8 in. (6) D
- 14 - Lockwasher, 3/8 in. (6)
- 15 - Core hole cover
- 16 - Gasket
- 17 - Drain plug, 3/4-14 NPTF C
- 18 - Nameplate
- 19 - Drive screw, no. 4 x 1/4 in. (4)

- 20 - Bolt, 3/8-16 x 7/8 in. (6) D
- 21 - Lockwasher, 3/8 in. (6)
- 22 - Oil strainer assembly
- 23 - Gasket
- 24 - Anchor pin
- 25 - Oil filler plug
- 26 - Add-level oil plug, 1/4-18 NPTF E
- 27 - Full-level oil plug, 1/4-18 NPTF E
- 28 - Cup plug
- 29 - Flat washer
- 30 - Plug C

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	36-43	49-58
<u>B</u>	120-150	163-204
<u>C</u>	33-37	45-50
<u>D</u>	26-32	36-43
<u>E</u>	14-16	19-21


A



Foldout 8,A. Turbine driven gears and freewheel clutch

3803C

B



Foldout 8,B. Transmission housing (-1 models)

Copyright 1984 General Motors Corp.

63820

A

- 1 - Oil suction tube
- 2 - Sealring
- 3 - Male nut, 1-3/4-14 A
- 4 - Sealring
- 5 - Transmission housing gasket
- 6 - Remote filter plug
- 7 - Plug, 3/4-14 NPTF B
- 8 - Breather
- 9 - Cup plug
- 10 - Nameplate
- 11 - Drive screw, No. 4 x 1/4 in. (4)
- 12 - Accessory drive cup plug
- 13 - Oil seal
- 14 - Oil strainer
- 15 - Sealring
- 16 - Oil strainer cover
- 17 - Lockwasher, 3/8 in. (2)
- 18 - Bolt, 3/8-16 x 3/4 in. (2) C
- 19 - Oil level ADD plug D
- 20 - Oil level FULL plug D

- 21 - Oil level tube
- 22 - Oil level tube
- 23 - Oil drain plug, 3/4 in. NPTF B
- 24 - Oil filler plug D
- 25 - Anchor pin
- 26 - Transmission housing assembly
- 27 - Transmission housing
- 28 - Plug (2) D
- 29 - Baffle plate
- 30 - Self-locking bolt, 5/16-18 x 5/8 in. (3) E
- 31 - Self-locking bolt, 5/16-18 x 5/8 in. E


<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	120-150	163-204
<u>B</u>	33-37	45-50
<u>C</u>	26-32	36-43
<u>D</u>	Tighten sufficiently to prevent leakage	
<u>E</u>	17-20	23-27

B

- 1 - Piston sealring
- 2 - Piston sealring
- 3 - Piston sealring
- 4 - Reverse clutch piston
- 5 - External-tanged, reverse clutch plate (4)
- 6 - Internal-splined, reverse clutch plate (4)
- 7 - Forward-and-reverse sun gear (standard-speed low gear)
- 8 - Spacer
- 9 - Reverse planetary carrier assembly
- 10 - Thrust washer (4)
- 11 - Planetary pinion (matched set of 4)
- 12 - Pinion roller (88)
- 13 - Thrust washer (4)
- 14 - Spindle (4)
- 15 - Reverse planetary carrier

- 16 - Forward-and-reverse sun gear (high speed, low gear)
- 17 - External-tanged reverse clutch plate
- 18 - Internal-splined reverse clutch plate
- 19 - Forward-and-reverse clutch anchor assembly
- 20 - Forward-and-reverse clutch anchor
- 21 - Anchor pin (6)
- 22 - Piston return spring (12)
- 23 - Return spring guide pin (12)
- 24 - Check ball, white (2)
- 25 - Retainer (2)


A



Foldout 9,A. Transmission housing (-3 models)

8187A

B



Foldout 9,B. Reverse clutch and planetary

9798A

A

- 1 - Reverse ring gear
- 2 - Thrust washer
- 3 - Forward planetary carrier assembly
- 4 - Spindle (4)
- 5 - Thrust washer (4)
- 6 - Pinion roller (88)
- 7 - Pinion (matched set of 4)
- 8 - Thrust washer (4)
- 9 - Forward planetary carrier
- 10 - Forward planetary carrier assembly
- 11 - Spindle (6)
- 12 - Thrust washer (6)
- 13 - Pinion roller (120)
- 14 - Pinion (matched set of 6)
- 15 - Thrust washer (6)
- 16 - Forward planetary carrier
- 17 - Forward planetary carrier assembly

- 18 - Spindle (6)
- 19 - Thrust washer (6)
- 20 - Pinion roller (120)
- 21 - Pinion (matched set of 6)
- 22 - Thrust washer (6)
- 23 - Forward planetary carrier
- 24 - Thrust washer
- 25 - Internal snapping
- 26 - Internal-splined low-range clutch plate (4)
- 27 - External-tanged low-range clutch plate (4)
- 28 - Forward ring gear
- 29 - Forward clutch piston assembly
- 30 - Check ball and retainer kit
- 31 - Check ball, white (2)
- 32 - Retainer (2)

- 33 - Forward clutch piston
- 34 - Piston sealring
- 35 - Piston sealring
- 36 - Piston sealring
- 37 - Forward clutch piston housing
- 38 - Self-locking bolt (10) A
3/8-16 x 1-1/2-in. (earlier models)*
3/8-16 x 1-3/4-in. (later models)
- 39 - Plug, 1/4-18 PTF B

*Used with flat washers

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	36-43	49-58
<u>B</u>	14-16	19-21

B


- 1 - Reverse planetary ring gear
- 2 - Thrust washer
- 3 - Forward planetary carrier assembly
- 4 - Bushing
- 5 - Forward planetary carrier
- 6 - Spindle (6)
- 7 - Thrust washer (6)
- 8 - Roller (120)
- 9 - Pinion (matched set of 6)
- 10 - Thrust washer (6)
- 11 - Internal snapping
- 12 - Internal-splined clutch plate (2)
- 13 - External-tanged clutch plate (2)
- 14 - Forward planetary ring gear
- 15 - Internal-splined clutch plate
- 16 - External-tanged clutch plate

- 17 - Forward clutch piston
- 18 - Piston sealring
- 19 - Piston sealring
- 20 - Piston sealring
- 21 - Bearing retainer
- 22 - Ball bearing
- 23 - Adapter gasket
- 24 - Adapter assembly
- 25 - Plug, 1/4 in. (2) A
- 26 - Adapter
- 27 - Sleeve
- 28 - Self-locking bolt,
3/8-24 x 1-1/4 in. (6) B
- 29 - Twelve-point bolt,
3/8-16 x 1-3/4 in. (2) C

- 30 - Forward planetary carrier assembly
- 31 - Bushing
- 32 - Forward planetary carrier
- 33 - Spindle (6)
- 34 - Thrust washer (6)
- 35 - Roller (120)
- 36 - Pinion (matched set of 6)
- 37 - Thrust washer (6)


<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	8-10	11-13
<u>B</u>	41-49	56-66
<u>C</u>	36-43	49-58

TT, TTB, TRT 2001 SERIES TRANSMISSIONS



Foldout 10,A. Forward clutch and planetary (-1 models)

1354



Foldout 10,B. Forward clutch and planetary (TRT 2221-3, 2421-3)

9850

A

- 1 - Reverse planetary ring gear
- 2 - Thrust washer
- 3 - Forward planetary carrier assembly
- 4 - Forward planetary carrier
- 5 - Spindle (6)
- 6 - Thrust washer (6)
- 7 - Roller (120)
- 8 - Pinion (matched set of 6)
- 9 - Thrust washer (6)
- 10 - Internal snapping
- 11 - Ball bearing
- 12 - Spacer

- 13 - Internal-splined clutch plate (2)
- 14 - External-tanged clutch plate (2)
- 15 - Forward planetary ring gear
- 16 - Internal-splined clutch plate
- 17 - External-tanged clutch plate
- 18 - Forward clutch piston
- 19 - Piston sealring
- 20 - Piston sealring
- 21 - Piston sealring
- 22 - Internal snapping
- 23 - Ball bearing
- 24 - Spacer


B

- 1 - Ball bearing
- 2 - Transfer drive gear assembly
- 3 - Transfer drive gear
- 4 - Pin (6)
- 5 - External snapping
- 6 - Nut, 5/16-24 (12) A
- 7 - Lockstrip (6)
- 8 - High-range clutch plate
- 9 - High-range, external-tanged clutch plate
- 10 - High-range clutch hub (PTO)
- 11 - External snapping
- 12 - High-range clutch hub
- 13 - High-range clutch plate
- 14 - Flat washer (12)
- 15 - Self-locking bolt, 5/16-24 x 7/8 in. (12)
- 16 - External snapping
- 17 - High-range clutch piston return spring
- 18 - Hook-type sealring
- 19 - High-range clutch piston
- 20 - Sealring
- 21 - Sealring expander
- 22 - High-range clutch piston housing assembly (speedometer drive)

- 23 - Bushing
- 24 - High-range clutch piston housing
- 25 - Pin
- 26 - Speedometer drive shaft
- 27 - Hook-type sealring
- 28 - Ball bearing
- 29 - Hook-type sealring
- 30 - Bolt, 1/2-20 x 2-3/4 in. (6) B
- 31 - Lock tab (6)
- 32 - High-range clutch piston housing assembly (earlier models)
- 33 - Bushing
- 34 - High-range clutch piston housing
- 35 - Sleeve
- 36 - High-range clutch piston housing assembly (later models)
- 37 - High-range clutch piston housing (PTO without brake)
- 38 - Step-joint sealring (2)
- 39 - Sealring


<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	14-18	19-24
<u>B</u>	83-100	113-135

A



Foldout 11,A. Forward clutch and planetary (TRT 2211-3, 2411-3)

B



Foldout 11,B. High-range clutch and piston housing (TT models)

A

- 1 - Ball bearing
- 2 - External snapping
- 3 - Transfer drive gear
- 4 - Ball bearing
- 5 - Adapter gasket
- 6 - Adapter sealring
- 7 - Adapter assembly
- 8 - Adapter
- 9 - Sleeve
- 10 - Bolt, 3/8-16 x 1-1/8 in. (16) A
- 11 - Lockwasher, 3/8 in. (16)
- 12 - Sealring (2)
- 13 - Low-range clutch drum assembly
- 14 - Pin (4)
- 15 - Clutch drum
- 16 - Sealring expander
- 17 - Clutch piston outer sealring
- 18 - Clutch piston inner sealring


- 19 - Low-range clutch piston
- 20 - Clutch piston return spring
- 21 - External snapping
- 22 - Sleeve assembly
- 23 - Bushing
- 24 - Sleeve
- 25 - External snapping
- 26 - Internal-splined clutch plate
- 27 - External-splined clutch plate
- 28 - High-range ring gear
- 29 - Internal-splined clutch plate (3)
- 30 - External-splined clutch plate (2)
- 31 - Low-range clutch backplate
- 32 - Internal snapping

<u>Torque</u>	<u>lb ft</u>	<u>N•m</u>
<u>A</u>	26-32	36-43


B

- 1 - High-range planetary sun gear assembly
- 2 - Sun gear
- 3 - Thrust washer
- 4 - High-range planetary carrier assembly
- 5 - High-range planetary carrier
- 6 - Thrust washer (6)
- 7 - Pinion (matched set of 6)
- 8 - Roller (96)
- 9 - Spindle (6)
- 10 - Thrust washer (6)
- 11 - Internal snapping
- 12 - High-range clutch anchor assembly

- 13 - Anchor
- 14 - Pin (short) (4)
- 15 - Pin (long) (2)
- 16 - Internal-splined clutch plate (5)
- 17 - External-tanged clutch plate (5)
- 18 - External snapping
- 19 - Clutch piston return spring
- 20 - Sealring expander
- 21 - Clutch piston outer sealring
- 22 - Clutch piston inner sealring
- 23 - High-range clutch piston



Foldout 12,A. Low-range clutch and transfer drive gear (TRT-1 models)



Foldout 12,B. High-range clutch and planetary (TRT-1 models)

A

- 1 - Sealring (2)
- 2 - High-range clutch drum assembly
- 3 - Pin (4)
- 4 - Clutch drum
- 5 - Sealring expander
- 6 - Clutch piston outer sealring
- 7 - Clutch piston inner sealring
- 8 - High-range clutch piston
- 9 - Clutch piston return spring


- 10 - External snapping
- 11 - External snapping
- 12 - Internal-splined clutch plate
- 13 - External-splined clutch plate
- 14 - Low-range ring gear
- 15 - Internal-splined clutch plate (2)
- 16 - External-splined clutch plate
- 17 - High-range clutch backplate
- 18 - Internal snapping

B

- 1 - Low-range planetary sun gear assembly
- 2 - Sun gear
- 3 - Thrust washer
- 4 - Low-range planetary carrier assembly
- 5 - Low-range planetary carrier
- 6 - Thrust washer (6)
- 7 - Pinion (matched set of 6)
- 8 - Roller (96)
- 9 - Spindle (6)
- 10 - Thrust washer (6)
- 11 - Internal snapping
- 12 - Low-range clutch anchor assembly

- 13 - Anchor
- 14 - Pin (long) (2)
- 15 - Pin (short) (4)
- 16 - Internal-splined clutch plate (5)
- 17 - External-tanged clutch plate (5)
- 18 - External snapping
- 19 - Clutch piston return spring
- 20 - Sealring expander
- 21 - Clutch piston outer sealring
- 22 - Clutch piston inner sealring
- 23 - Low-range clutch piston


A



4295A

Foldout 13.A. High-range clutch, low-range ring gear (TRT 2221-3, 2421-3 with underdrive)

B



4358A

Foldout 13.B. Low-range clutch and planetary (~3 models with underdrive)

A

- 1 - Sealring (2)
- 2 - Low-range clutch drum assembly
- 3 - Pin (4)
- 4 - Clutch drum
- 5 - Sealring expander
- 6 - Clutch piston outer sealring
- 7 - Clutch piston inner sealring
- 8 - Low-range clutch piston
- 9 - Clutch piston return spring
- 10 - External snapping
- 11 - External snapping
- 12 - Bearing race
- 13 - Roller bearing


- 14 - Bearing race
- 15 - Low-range clutch hub
- 16 - Internal-splined clutch plate (5)
- 17 - External-splined clutch plate (4)
- 18 - High-range planetary carrier assembly
- 19 - High-range planetary carrier
- 20 - Spindle (6)
- 21 - Thrust washer (6)
- 22 - Roller (120)
- 23 - Pinion (matched set of 6)
- 24 - Thrust washer (6)
- 25 - Internal snapping

B

- 1 - High-range planetary sun gear
- 2 - Internal snapping
- 3 - High-range clutch anchor assembly
- 4 - Anchor
- 5 - Pin (long) (2)
- 6 - Pin (short) (4)
- 7 - Internal-splined clutch plate (2)
- 8 - External-tanged clutch plate (2)
- 9 - High-range ring gear


- 10 - Internal-splined clutch plate
- 11 - External-tanged clutch plate
- 12 - External snapping
- 13 - Clutch piston return spring
- 14 - Sealring expander
- 15 - Clutch piston outer sealring
- 16 - Clutch piston inner sealring
- 17 - High-range clutch piston

A



4297

B



4296A

Foldout 14,A. Low-range clutch, high-range planetary (~3 models with overdrive)

Foldout 14,B. High-range clutch, planetary sun and ring gears (~3 models with overdrive)

A

- 1 - Ball bearing
- 2 - Transfer drive gear assembly
- 3 - Transfer drive gear
- 4 - Pin (6)
- 5 - External snapping
- 6 - Nut, 5/16-24 (12) A
- 7 - Lockstrip (6)
- 8 - High-range clutch plate
- 9 - High-range, external-tanged clutch plate
- 10 - High-range clutch hub (models with converter-driven PTO)
- 11 - External snapping
- 12 - High-range clutch hub
- 13 - High-range clutch plate
- 14 - Flat washer (12)
- 15 - Self-locking bolt, 5/16-24 x 7/8 in. (12)
- 16 - External snapping
- 17 - Piston return spring
- 18 - Hook-type sealring
- 19 - High-range clutch piston
- 20 - Sealring
- 21 - Sealring expander

- 22 - High-range clutch piston housing (PTO)
- 23 - Lock tab (6)
- 24 - Bolt, 1/2-20 x 2-3/4 in. (6) B
- 25 - Step-joint sealring (2)
- 26 - O-ring seal
- 27 - External snapping
- 28 - PTO shaft assembly
- 29 - Pin
- 30 - PTO shaft
- 31 - Internal snapping
- 32 - Ball bearing
- 33 - High-range clutch piston housing assembly
- 34 - Bushing
- 35 - High-range clutch piston housing
- 36 - Lock tab (6)
- 37 - Bolt, 1/2-20 x 2-3/4 in. (6) B
- 38 - Sealring


<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	14-18	19-24
<u>B</u>	83-100	113-135

B

- 1 - Gasket
- 2 - Diaphragm assembly
- 3 - Pipe plug, 1/4 in. NPTF A
- 4 - Diaphragm
- 5 - Sleeve
- 6 - Pin (6)
- 7 - Lockwasher, 3/8 in.
- 8 - Bolt, 3/8-16 x 2 in. B
- 9 - Lockwasher, 3/8 in. (2)
- 10 - Bolt, 3/8-16 x 1-1/8 in. (2) B
- 11 - Brake return spring (12)
- 12 - Spring guide pin (12)
- 13 - Brake hub
- 14 - External-tanged brake plate (6)
- 15 - Internal-splined brake plate (5)
- 16 - Step-joint sealring
- 17 - External snapping
- 18 - Ball bearing
- 19 - External snapping
- 20 - Brake-apply plate assembly
- 21 - Brake adjusting ring
- 22 - Spring pin (6)
- 23 - Brake-apply plate
- 24 - Sealring
- 25 - Sealring (3)
- 26 - Brake piston (3)


- 27 - Brake piston cup (3)
- 28 - Expander assembly (3)
- 29 - Sealring
- 30 - Plug, 7/16-20 C
- 31 - Brake manifold fitting C
- 32 - Brake manifold
- 33 - Brake manifold fitting C
- 34 - Brake manifold
- 35 - Brake manifold fitting C
- 36 - Plug, 7/16-20 C
- 37 - Rear cover assembly (PTO)
- 38 - Rear cover
- 39 - Lip-type oil seal
- 40 - Dust shield
- 41 - PTO output flange
- 42 - Flange retaining washer
- 43 - Self-locking nut, 7/8-14 C
- 44 - Plug
- 45 - Bolt, 3/8-16 x 2-3/4 in. (18) B
- 46 - Lockwasher, 3/8 in. (18)

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	14-16	19-21
<u>B</u>	26-32	35-43
<u>C</u>	275-325	373-440



Foldout 15,A. High-range clutch and piston housing (TTB models)

19055



Foldout 15,B. Internal brake and rear cover (TTB models)

6394

A

- 1 - Rear housing gasket
- 2 - Rear housing
- 3 - Lockwasher, 3/8 in. (17)
- 4 - Bolt, 3/8-16 x 1-1/8 in. (17) A
- 5 - High- and low-range input shaft
- 6 - Rear bearing
- 7 - External snapping
- 8 - Internal snapping
- 9 - Sealring
- 10 - Oil retainer
- 11 - Internal snapping

- 12 - Clutch anchor pin
- 13 - Welch plug
- 14 - Plug, 1/4 in. B
- 15 - Bolt, 3/8-16 x 1-1/2 in. (3) A
- 16 - Lockwasher, 3/8 in. (3)

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	26-32	36-43
<u>B</u>	8-10	11-13

B

- 1 - Rear housing gasket
- 2 - Rear housing
- 3 - Lockwasher, 3/8 in. (15)
- 4 - Bolt, 3/8-16 x 2-3/4 in. (15) A
- 5 - Output shaft (underdrive models)
- 6 - External snapping
- 7 - Output shaft (overdrive models)
- 8 - Rear bearing
- 9 - Internal snapping
- 10 - Spacer
- 11 - Oil seal

- 12 - Clutch anchor pin
- 13 - Welch plug
- 14 - Plug, 1/4 in. B
- 15 - Plug, 3/8 in. C

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	26-32	36-43
<u>B</u>	8-10	11-13
<u>C</u>	12-16	17-21

C

- 1 - Rear housing gasket
- 2 - Plug, 1/8 in. A
- 3 - Lockwasher, 3/8 in. (18)
- 4 - Bolt, 3/8-16 x 1-3/4 in. (18) B
- 5 - Rear housing assembly
- 6 - Baffle
- 7 - Oil seal

- 8 - Oil drain tube
- 9 - Rear housing

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	4-5	5.5-6.7
<u>B</u>	26-32	36-43

D

- 1 - Gasket
- 2 - Sealring
- 3 - Pipe plug A
- 4 - Rear cover (with speedometer drive)
- 5 - Lockwasher, 3/8 in. (19)
- 6 - Bolt, 3/8-16 x 1-1/8 in. (19) B
- 7 - Gasket
- 8 - Speedometer drive adapter
- 9 - Gasket
- 10 - Speedometer drive sleeve assembly
- 11 - Lip-type oil seal
- 12 - Washer (cork)
- 13 - Speedometer drive sleeve
- 14 - Lockwasher, 5/16 in. (2)
- 15 - Bolt, 5/16-18 x 2-1/4 in. (2) C
- 16 - External snapping

- 17 - PTO shaft assembly
- 18 - Pin
- 19 - PTO shaft
- 20 - Internal snapping
- 21 - Ball bearing
- 22 - Rear PTO cover assembly
- 23 - Sleeve
- 24 - Rear cover
- 25 - Lip-type oil seal
- 26 - Dust shield
- 27 - PTO output flange
- 28 - Flange retaining washer
- 29 - Self-locking nut, 7/8-14 D
- 30 - Bolt, 3/8-16 x 1-1/8 in. (19) B
- 31 - Lockwasher, 3/8 in. (19)
- 32 - Pipe plug A


- 33 - Pipe plug A
- 34 - Rear cover
- 35 - Lockwasher, 3/8 in. (19)
- 36 - Bolt, 3/8-16 x 1-1/8 in. (19) B

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	10-12*	14-16*
	18-22**	25-29**
<u>B</u>	26-32	35-43
<u>C</u>	13-16	18-21
<u>D</u>	275-325	373-440


* For 1/8 in. NPTF plugs

** For 3/8 in. NPTF plugs

TT, TTB, TRT 2001 SERIES TRANSMISSIONS



Foldout 16,A,B,C. Rear housings and output shafts (TRT models)



Foldout 16,D. Rear covers and PTO shaft (TT models)

Copyright 1984 General Motors Corp.

A

- 1 - Flange retaining nut, 1-1/4-12 A
(nylon insert)
- 2 - Flange washer
- 3 - Sealring (use after S/N 23290)
- 4 - Flange (Mechanics 5C)
- 5 - Flange spacer
- 6 - Flange (Type 5N)
- 7 - Flange (S1480)
- 8 - Front output shaft orifice plug
- 9 - Lip-type oil seal
- 10 - Internal snapping
- 11 - Ball bearing
- 12 - Output shaft
- 13 - Front output shaft
- 14 - Detent ball (2)
- 15 - Detent spring
- 16 - Shifter fork shaft orifice plug
- 17 - Lip-type oil seal
- 18 - Shifter fork shaft
- 19 - Shifter fork
- 20 - Disconnect coupling
- 21 - Ball bearing
- 22 - Spacer

- 23 - Transfer-driven gear
- 24 - Rear output shaft assembly
- 25 - Bushing
- 26 - Rear output shaft
- 27 - Spacer
- 28 - Ball bearing
- 29 - Internal snapping
- 30 - Lip-type oil seal
- 31 - Flange (Type 5N)
- 32 - Flange (Mechanics 5C)
- 33 - Spacer
- 34 - Flange (Mechanics 5C)
- 35 - Flange (S1480)
- 36 - Flange (Mechanics 5C)
- 37 - Sealring (use after S/N 23290)
- 38 - Flange washer
- 39 - Flange retaining nut, 1-1/4-12 A
(nylon insert)

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	450-700	611-949

B


- 1 - Parking brake assembly*
- 2 - Brake backplate*
- 3 - Roller*
- 4 - Brake shoe and lining (2)*
- 5 - Brake shoe return spring (2)*
- 6 - Cam lever*
- 7 - Self-locking bolt,
1/2-13 x 7/8 in. (4) A*
- 8 - Brake backplate (TTB)
- 9 - Brake drum*
- 0 - Self-locking bolt, 3/8-24 x 5/8 in. (4) B*
- 1 - Self-locking bolt, 3/8-24 x 5/8 in. (4) B*
- 2 - Parking brake assembly**
- 3 - Brake backplate**
- 4 - Roller**
- 5 - Brake shoe and lining (2)**

- 16 - Brake shoe return spring (2)**
- 17 - Cam lever**
- 18 - Brake drum**
- 19 - Self-locking bolt, 3/8-24 x 3/4 in. (8) B**
- 20 - Bolt, 5/8-11 x 1-1/4 in. (3) C**
- 21 - Lockwasher, 5/8 in. (3)**

<u>Torque</u>	<u>lb ft</u>	<u>N·m</u>
<u>A</u>	81-97	110-131
<u>B</u>	41-49	56-66
<u>C</u>	117-140	159-189


* -1 models

** -3 models



Foldout 17,A. Output shafts and disconnect assembly (-1 models)

6477B



Foldout 17,B. Parking brake

6476B

A

- 1 - Gasket
- 2 - Oil pump assembly
- 3 - Oil pump cover
- 4 - Oil pump cover gasket
- 5 - Drive gear
- 6 - Driven gear assembly
- 7 - Driven gear
- 8 - Needle bearing (2)
- 9 - Oil pump body assembly
- 10 - Oil pump body
- 11 - Dowel pin
- 12 - Driven gear shaft
- 13 - Lip-type oil seal
- 14 - Lockwasher, 3/8 (7)

- 15 - Bolt, 3/8-16 x 2 in. A
4-bolt C pad (7)
2-bolt B pad (7)
2-bolt C pad (6)
- 16 - Lockwasher, 3/8 in. (2)
- 17 - Bolt, 3/8-16 x 3 in. (2) A
- 18 - Adapter drive coupling
- 19 - Bolt, 3/8-16 x 3 in. A
- 20 - Lockwasher, 3/8 in.

<u>Torque</u>	<u>lb ft</u>	<u>N•m</u>
<u>A</u>	26-32	36-43

B


- 1 - Control valve body gasket
- 2 - Lockwasher, 3/8 (16)
- 3 - Bolt, 3/8-16 x 1 in. A
- 4 - Bolt, 3/8-16 x 2-1/2 in. (15) A
- 5 - Control valve body assembly
- 6 - Plug B
- 7 - Gasket
- 8 - Main-pressure regulator valve
- 9 - Control valve body
- 10 - Ball
- 11 - Ball retainer plug
- 12 - Valve stop
TRT 2211-3 (1)
TRT 2411-3 (2)
- 13 - Spring retainer (earlier models)
- 14 - Main-pressure regulator spring
- 15 - Trimmer spring
- 16 - Trimmer plug
- 17 - Gasket
- 18 - Plug C
- 19 - Clutch cutoff valve spring
- 20 - Clutch cutoff valve
- 21 - Cutoff valve plug (hydraulic actuated)
- 22 - Sealring
- 23 - Gasket
- 24 - Cup (hydraulic actuated)
- 25 - Retainer plug (hydraulic actuated) D
- 26 - Oil seal
- 27 - Internal snapping
- 28 - Bracket
- 29 - Manual range selector valve (models without neutral start switch)
- 30 - Detent ball (2)
- 31 - Plug D

- 32 - Gasket
- 33 - Detent spring (2)
- 34 - Gasket
- 35 - Plug B
- 36 - Plug, 1/8 in. E
- 37 - Inching valve stop
- 38 - Spring
- 39 - Inching regulator valve
- 40 - Regulator valve stop
- 41 - Inching regulator valve spring
- 42 - Inching control valve
- 43 - Valve return spring
- 44 - Sealring
- 45 - Plug
- 46 - Oil seal
- 47 - Internal snapping
- 48 - Push-on retaining ring
- 49 - Cutoff valve plug (air actuated)
- 50 - Retainer plug (air actuated) D
- 51 - Plug E
- 52 - Manual range selector valve (models with neutral start switch)
- 53 - Gasket
- 54 - Plug (neutral switch hole) F
- 55 - Plug, 1/8 in. E

<u>Torque</u>	<u>lb ft</u>	<u>N•m</u>
<u>A</u>	26-32	36-43
<u>B</u>	80-90	109-122
<u>C</u>	90-100	123-135
<u>D</u>	60-70	82-94
<u>E</u>	10-12	14-16
<u>F</u>	30-40	41-54

TT, TTB, TRT 2001 SERIES TRANSMISSIONS


A



Foldout 18,A. Oil pump assemblies

6374A

B



Foldout 18,B. Control valve assemblies

112448