

# CLARK

## TORQUE CONVERTER

### MAINTENANCE & SERVICE MANUAL

C-270

SERIES

**CLARK EQUIPMENT COMPANY**



CUSTOMER SERVICE DIVISION

PUBLICATION DEPT. — JACKSON, MICHIGAN




● **TORQUE CONVERTERS  
UP TO 1000 HORSEPOWER**

● **TRANSMISSIONS  
UP TO 1000 HORSEPOWER**



● **AXLES**



The new 28000 Series transmissions are offered in fully power-shifted 2, 3, and 4 speed versions, along with a 6 speed configuration employing a range shift.



## FOREWORD




This manual has been prepared to provide the customer and the maintenance personnel with information and instructions on the maintenance and repair of the **CLARK** Torque Converter.

Extreme care has been exercised in the design, selection of materials and manufacturing of these units. The slight outlay in personal attention and cost required to provide regular and proper lubrication, inspection at stated intervals, and such adjustments as may be indicated will be reimbursed many times in low cost operation and trouble free service.

In order to become familiar with the various parts of the torque converter, its principal of operation, trouble shooting and adjustments, it is urged that the mechanic study the instructions in this manual carefully and use it as a reference when performing maintenance and repair operations.

Whenever repair or replacement of component parts is required, only Clark-approved parts as listed in the applicable parts manual should be used. Use of "will-fit" or non-approved parts may endanger proper operation and performance of the equipment. The Clark Equipment Company does not warrant repair or replacement parts, nor failures resulting from the use thereof, which are not supplied by or approved by the Clark Equipment Company. **IMPORTANT: Always furnish the Distributor with the converter serial and model number when ordering parts.**








**C-270 CONVERTER WITH OFFSET OUTPUT**

ITEM	DESCRIPTION	QTY.	ITEM	DESCRIPTION	QTY.
1	Inlet Cover (3000 Trans. only).....	1	55	Bearing Retainer Screw Lockwasher.....	3
2	Inlet Cover Plug (3000 Trans. only).....	1	56	Output Shaft Cotter Pin.....	1
3	Cover Bolt Lockwasher (3000 Trans. only)....	1	57	Companion Flange.....	1
4	Cover Bolt—Long (3000 Trans. only).....	1	58	Bearing Retainer Oil Seal.....	1
5	Cover Bolt—Short (3000 Trans. only).....	3	59	Bearing Retainer Stud Nut.....	2
6	Cover Bolt Lockwasher (3000 Trans. only)....	3	60	Bearing Retainer Stud Lockwasher.....	2
7	Valve Stop.....	1	61	Bearing Retainer.....	1
8	Valve Stop "O" Ring.....	1	62	Bearing Retainer "O" Ring.....	1
9	Valve Piston.....	1	63	Output Shaft Bearing Retainer Stud.....	2
10	Valve Spring—Inner.....	1	64	Output Shaft Rear Bearing.....	1
11	Valve Spring—Outer.....	1	65	Output Shaft Bearing Snap Ring.....	1
12	Valve Stop Roll Pin.....	1	66	Output Shaft.....	1
13	Air Breather Check Valve Assembly— Out of Location.....	1	67	Output Shaft Gear.....	1
14	Air Breather—Out of Location.....	1	68	Output Shaft Front Bearing.....	1
15	Regulator Valve to Housing Screw Lockwasher.....	4	69	Bearing Snap Ring.....	1
16	Regulator Valve to Housing Screw.....	4	70	Output Gear Snap Ring.....	1
17	Valve Stop Roll Pin.....	1	71	Turbine Shaft Gear.....	1
18	Valve Stop "O" Ring.....	1	72	Turbine Shaft Snap Ring.....	1
19	Valve Stop.....	1	73	Turbine Shaft Bearing.....	1
20	Regulating Valve Assembly.....	1	74	Turbine Shaft Piston Ring.....	1
21	Valve Housing Pipe Plug.....	1	75	Turbine Shaft.....	1
22	Valve Housing Pipe Plug.....	1	76	Stator Support & Sleeve Assembly.....	1
23	Safety Valve Seat.....	1	77	Stator Support Piston Ring.....	1
24	Safety Valve Plunger.....	1	78	Impeller Hub Gear Snap Ring.....	1
25	Safety Valve Spring.....	1	79	Impeller Hub Gear.....	1
26	Regulator Valve to Housing "O" Ring.....	1	80	Stator Support Screw.....	6
27	Regulator Valve to Housing Gasket.....	1	81	Stator Support Screw Lockwasher.....	6
28	Converter Housing Pipe Plug.....	2	82	Turbine.....	1
29	Pump Drive Gear.....	3	83	Turbine Hub.....	1
30	Pump Drive Gear Snap Ring.....	3	84	Turbine Shaft Snap Ring.....	1
31	Converter Housing Pipe Plug.....	1	85	Reaction Member Snap Ring.....	1
32	Converter Housing.....	1	86	Reaction Member.....	1
33	Converter Housing Pipe Plug.....	2	87	Reaction Member Spacer.....	1
34	Oil Baffle Screw Lockwasher.....	3	88	Impeller Bearing Snap Ring.....	1
35	Oil Baffle Screw.....	3	89	Impeller Hub Bearing.....	1
36	Converter Housing Pipe Plug.....	1	90	Impeller Hub.....	1
37	Converter Housing Pipe Plug.....	1	91	Impeller Hub "O" Ring.....	1
38	Pump Drive Shaft Bearing.....	3	92	Impeller.....	1
39	Pump Drive Shaft Spacer.....	3	93	Hub to Impeller Screw Lockwasher.....	8
40	Pump Drive Shaft Bearing.....	3	94	Hub to Impeller Screw.....	8
41	Pump Drive Shaft.....	3	95	Oil Baffle.....	1
42	Pump Drive Shaft Snap Ring.....	3	96	Oil Baffle "O" Ring.....	1
43	Pump Shaft Washer.....	3	97	Oil Baffle Oil Seal.....	1
44	Pump Shaft Snap Ring.....	3	98	Impeller to Cover "O" Ring.....	1
45	Charging Pump Sleeve.....	1	99	Impeller Cover Bearing Snap Ring.....	1
46	Pump Mounting Stud.....	6	100	Impeller Cover Bearing.....	1
47	Pump Gasket.....	1	101	Impeller Cover.....	1
48	Pump Mounting Stud Nut Lockwasher.....	6	102	Impeller Cover Sleeve.....	1
49	Pump Mounting Stud Nut.....	6	103	Ring Gear Screw.....	8
50	Converter Charging Pump.....	1	104	Plain Washer.....	8
51	Output Shaft Nut.....	1	105	Flywheel Ring Gear.....	1
52	Output Shaft Washer.....	1	106	Turbine Shaft Snap Ring.....	1
53	Output Shaft "O" Ring.....	1	107	Turbine Hub Screw Washer.....	8
54	Bearing Retainer Screw.....	3	108	Turbine Hub Screw.....	8
			109	Impeller to Cover Screw.....	24
			110	Impeller to Cover Lockwasher.....	24








# C-270 CONVERTER WITH INLINE OUTPUT

ITEM	DESCRIPTION	QTY.	ITEM	DESCRIPTION	QTY.
1	Inlet Cover (3000 Trans. only).....	1	53	Converter Housing Plug.....	2
2	Inlet Cover Plug (3000 Trans. only).....	1	54	Oil Baffle Screw Lockwasher.....	3
3	Cover Bolt Lockwasher (3000 Trans. only)....	1	55	Oil Baffle Screw.....	3
4	Cover Bolt—Long (3000 Trans. only).....	1	56	Output Flange.....	1
5	Cover Bolt—Short (3000 Trans. only).....	3	57	Turbine Shaft Cotter Pin.....	1
6	Cover Bolt Lockwasher (3000 Trans. only)....	3	58	Offset Drive Hole Cover "O" Ring.....	1
7	Valve Stop.....	1	59	Cover Stud.....	2
8	Valve Stop "O" Ring.....	1	60	Cover Stud Nut Lockwasher.....	2
9	Valve Piston.....	1	61	Cover Stud Nut.....	2
10	Valve Spring—Inner.....	1	62	Offset Drive Hole Cover.....	1
11	Valve Spring—Outer.....	1	63	Cover Screw.....	3
12	Valve Stop Roll Pin.....	1	64	Cover Screw Lockwasher.....	3
13	Air Breather Check Valve Assembly— Out of Location.....	1	65	Pump Hole Cover Screw.....	12
14	Air Breather—Out of Location.....	1	66	Pump Hole Cover Screw Lockwasher.....	12
15	Regulator Valve to Housing Screw Lockwasher.....	4	67	Pump Hole Cover.....	2
16	Regulator Valve to Housing Screw.....	4	68	Pump Hole Cover Gasket.....	2
17	Valve Stop Roll Pin.....	1	69	Hub to Impeller Screw.....	8
18	Valve Stop "O" Ring.....	1	70	Hub to Impeller Screw Washer.....	8
19	Valve Stop.....	1	71	Companion Flange Spacer.....	1
20	Regulating Valve Assembly.....	1	72	Snap Ring.....	1
21	Valve Housing Pipe Plug.....	1	73	Turbine Shaft Bearing.....	1
22	Valve Housing Pipe Plug.....	1	74	Piston Ring.....	1
23	Safety Valve Seat.....	1	75	Turbine Shaft.....	1
24	Safety Valve Plunger.....	1	76	Stator Support & Sleeve Assembly.....	1
25	Safety Valve Spring.....	1	77	Stator Support Screw Lockwasher.....	6
26	Regulator Valve to Housing "O" Ring.....	1	78	Stator Support Screw.....	6
27	Regulator Valve to Housing Gasket.....	1	79	Piston Ring.....	1
28	Converter Housing Pipe Plug.....	2	80	Impeller Hub Gear Snap Ring.....	1
29	Pump Drive Gear.....	3	81	Impeller Hub Gear.....	1
30	Pump Drive Gear Snap Ring.....	3	82	Turbine.....	1
31	Pump Drive Gear.....	3	83	Turbine Hub.....	1
32	Converter Housing Pipe Plug.....	1	84	Turbine Locating Snap Ring.....	1
33	Converter Housing Pipe Plug.....	1	85	Reaction Member Snap Ring.....	1
34	Converter Housing Pipe Plug.....	1	86	Reaction Member.....	1
35	Pump Drive Shaft Bearing.....	3	87	Reaction Member Spacer.....	1
36	Pump Drive Shaft Spacer.....	3	88	Bearing Snap Ring.....	1
37	Pump Drive Shaft Bearing.....	3	89	Impeller Hub Bearing.....	1
38	Pump Drive Shaft.....	3	90	Impeller Hub.....	1
39	Pump Drive Shaft Snap Ring.....	3	91	Impeller Hub "O" Ring.....	1
40	Pump Shaft Washer.....	3	92	Impeller.....	1
41	Pump Shaft Snap Ring.....	3	93	Oil Baffle.....	1
42	Charging Pump Sleeve.....	1	94	Oil Baffle "O" Ring.....	1
43	Pump Mounting Stud.....	6	95	Oil Seal.....	1
44	Pump Gasket.....	1	96	Impeller to Cover "O" Ring.....	1
45	Pump Mounting Stud Nut Lockwasher.....	6	97	Bearing Snap Ring.....	1
46	Pump Mounting Stud Nut.....	6	98	Impeller Cover Bearing.....	1
47	Converter Charging Pump.....	1	99	Impeller Cover.....	1
48	Turbine Shaft Nut.....	1	100	Impeller Cover Sleeve.....	1
49	Turbine Shaft Washer.....	1	101	Ring Gear to Flywheel Bolt.....	8
50	Flange "O" Ring.....	1	102	Ring Gear to Flywheel Bolt Washer.....	8
51	Oil Seal.....	1	103	Ring Gear.....	1
52	Converter Housing Plug.....	1	104	Turbine Retaining Snap Ring.....	1
			105	Turbine Hub Screw Washer.....	8
			106	Turbine Hub Screw.....	8
			107	Impeller to Cover Bolt Lockwasher.....	24
			108	Impeller to Cover Bolt.....	24





C-270 SERIES CONVERTER OIL FLOW DIAGRAM



## IRREGULARITIES IN PERFORMANCE

### C-270 Series Converters

TROUBLE	PROBABLE CAUSE	REMEDY
1. Low converter OUT pressure (Below 25 P.S.I. with engine at 2000 RPM — NO LOAD)	Worn oil sealing and "O" rings	A. Trouble is internal and will require a complete tear-down of the converter.
	Worn oil pump.	B. Replace.
	Safety Valve stays open.	C. Clean and check valve spring and valve.
2. Suction line taking air.	Low oil level.	D. Fill to proper level.
	Suction line connections taking air.	E. Check oil line connections and tighten securely.
	Worn oil pump.	F. Replace.
3. High converter OUT pressure (Above 40 P.S.I. with engine at 2000 RPM — NO LOAD)	Oil cooler or oil lines restricted.	G. Check oil cooler line and oil cooler for restrictions. Clean or replace.
	Oil too heavy	H. Check oil weight. See oil recommenda- tions.
	Cold oil.	I. Converter pressure in cold weather will vary. As soon as converter gets hot, pres- sure should drop.
4. Over-heating	See items No. 1 & 2.	
	Oil cooler or oil cooler lines restricted causing safety valve to stay open.	J. Clean and check oil cooler and oil cooler lines. Replace if necessary.
	Oil cooler too small.	K. Replace with larger cooler.
	Worn oil pump	L. Replace oil pump.
	Converter drain line to transmission or oil sump not installed properly.	M. Install at lowest drain opening in conver- ter housing. Line must maintain constant gradual drop to oil sump for gravity drain.
5. Noisy Converter.	Worn coupling gear.	N. Replace.
	Worn oil pump	O. Replace.
	Damaged bearing.	P. A complete teardown will be necessary to determine this. Replace if necessary.
	Worn drive gears.	Q. Replace.
6. Low clutch pressure. (See pressure specifications)	Transmission malfunc- tion.	R. Close pressure line to transmission con- trol valve. If clutch pressure returns to normal, trouble is in transmission.
	Worn oil pump.	S. Replace.
	Regulator valve stuck open.	T. Clean and check valve for worn or dirty parts, replace if necessary.



**IRREGULARITIES IN PERFORMANCE (Cont'd.)****C-270 Series Converters**

<b>TROUBLE</b>	<b>PROBABLE CAUSE</b>	<b>REMEDY</b>
7. High clutch pressure. (See pressure specifications)	Regulator valve stuck closed.	U. See item T.
8. Lack of power.	Improper engine function.	V. Tune engine.
	Engine stall speed below normal.	W. Tune engine. Check governor.
	Low converter out pressure.	X. See item No. 1.
	Air in the oil.	Y. See item No. 2.
	Improper oil.	Z. See oil recommendations.
9. Oil in engine flywheel housing.	"O" ring between impeller cover and impeller damaged.	AA. Replace.
	Oil baffle "O" ring damaged.	BB. Replace.
	Oil baffle oil seal damaged.	CC. Replace.

**GENERAL INFORMATION:**

Use Clark 228190 or 1533614 Oil Filter only.

Use Clark 215502 Oil Filter Element only.

Use minimum number of Pipe and Hose Fittings.

Gravity drain from Converter Sump to Transmission must be of minimum length and have no "U" bends to trap air or oil.

Cooler capacity for normal application, 30 per cent of net Engine Horsepower at Governed Speed.

Check oil level with engine idling and transmission in neutral.

CHANGE OIL FILTER ELEMENT EVERY 250 HOURS. DRAIN AND REFILL SYSTEM EVERY 500 HOURS.

**TORQUE SPECIFICATIONS:**

3/8" Capscrew	20 to 25 Pounds Feet Torque
7/16" Capscrew	35 to 40 Pounds Feet Torque
1/2" Capscrew	45 to 50 Pounds Feet Torque
Turbine Hub Bolt	30 to 35 Pounds Feet Torque
Output Flange Nut	200 to 250 Pounds Feet Torque

Apply Permatex No. 2 or Crane Sealer to all Pipe Plugs and Hose Connections.

Apply a light coat of Permatex No. 2 on all bores that take a Lip Type Oil Seal.



**OIL PRESSURE AND LUBRICATION RECOMMENDATIONS**  
**for**  
**C-270 SERIES CONVERTERS**

Make all checks after complete system is up to normal operating temperature (200°F.)

**A. CONVERTER PRESSURE CHECK**

Operate Engine at 2000 R.P.M.  
 Place Transmission Direction and Speed Levers in neutral.

Converter OUT.....25 Minimum  
 40 Maximum

**TRANSMISSION CLUTCH OIL PRESSURE P.S.I.**

The C-270 Converter will be equipped with one of three variations involving the clutch regulating valve. They are as follows:

1. Inlet cover for **Converter oil only** with clutch pressure valve in transmission control cover. **180 to 220 P.S.I.** pressure range. (See note)
2. Pressure regulator valve on Converter with a **240 to 280 P.S.I.** pressure range. (See Note).
3. Pressure regulator valve on Converter with a **180 to 220 P.S.I.** pressure range. (See Note).

**NOTE:** All pressure must be equal within **5 P.S.I.** If clutch pressure varies in any one clutch more than **5 P.S.I.** repair clutch. All pressures must be taken with two clutches engaged.

**B. OIL IN A TORQUE CONVERTER** is used primarily as means of transmitting power as well as providing adequate lubrication. Such oil must have the following properties:

1. It must remain fluid at all prevailing temperatures.
2. It must not foam excessively nor materially increase in volume.
3. It must be chemically stable at elevated temperatures.
4. It must be free from additives and impurities which would centrifuge out during operation.
5. **IT MUST BE CLEAN.** Dirt in the converter hydraulic circuit will cause wear and shorten life. Also it will cause malfunction by damaging the hydraulic pump, pressure regulating valves and oil seals within the unit.

RECOMMENDED OILS FOR CLARK POWER SHIFT TRANSMISSIONS AND CONVERTERS HAVING COMMON OIL SYSTEM		
Prevailing Ambient Temp.	SAE Spec.	Type
<b>INITIAL FILL</b>		
Above 0° F	Type "A" Suffix "A" or Dexron * Type C-2	Automatic Transmission Fluid Hydraulic Fluid
Below 0° F	Type "A" Suffix "A" or Dexron *	Automatic Transmission Fluid
<b>SUBSEQUENT FILL OR REFILLS</b>		
Above 0° F	Type "A" Suffix "A" or Dexron * Type C-2 SAE 10 Mil. 2104B	Automatic Transmission Fluid Hydraulic Fluid MS-DG Grade 10
Below 0° F	Type "A" Suffix "A" or Dexron *	Automatic Transmission Fluid

\* DEXRON is a Registered Trademark of General Motors Corporation




### C-270 SERIES CONVERTER

The following instructions will cover the disassembly and assembly of the C-270 Converter in a sequence that would normally be followed after the Converter has been removed from the vehicle.

**CAUTION:** Cleanliness is of extreme importance and an absolute must in the repair and overhaul of the Converter. Before attempting any repairs the exterior of the unit must be thoroughly cleaned to prevent the possibility of dirt and foreign matter entering the mechanism.

### DISASSEMBLY




**Figure 1**

Remove bolts securing impeller cover to impeller.




**Figure 2**

Use two bolts in threaded puller holes 180° apart to remove impeller cover from impeller.




**Figure 3**

If pilot bushing sleeve is to be replaced use procedure as shown above.



**Figure 4**


If necessary to replace pilot bearing, remove retain-er ring and use small inside bearing puller.



**Figure 5**


Remove outer turbine hub retain-er ring.






**Figure 6**

Remove turbine and hub assembly from turbine shaft. Remove turbine locating ring.




**Figure 7**

Remove reaction member retainer ring.




**Figure 8**

Remove reaction member from stator support, threaded puller holes are provided should reaction member be too tight to be removed by hand.



**Figure 9**

Reaction member and spacer.



**Figure 10**


Remove three bolts that secure oil baffle to Converter Housing.



**Figure 11**


Install special puller tool as shown above, turn jack screw pulling oil baffle and impeller from stator support as an assembly. Special tool can be made for easier removal of impeller assembly but it is not necessary. (See Figure 12).






**Figure 12**

If special tool is not available, remove oil baffle bolts part way. Tap lightly on each bolt, this will loosen oil baffle from Converter Housing, remove oil baffle and impeller from housing as an assembly.




**Figure 13**

Remove impeller hub gear retainer ring.




**Figure 14**

Remove impeller hub gear and oil baffle from impeller.



**Figure 15**

Remove oil baffle oil seal and "O" ring. **NOTE:** Oil seal should be removed only if it is to be replaced.



**Figure 16**


Remove impeller hub bolt lockwire and hub bolts.



**Figure 17**


Remove impeller hub from impeller. Remove hub "O" ring.






**Figure 18**

Remove hub bearing retainer ring and press bearing from hub.



**Figure 21**


On offset output, remove stator support and turbine shaft assembly from Converter Housing.



**Figure 19**


PUMP DRIVES VARY IN QUANTITY FROM ONE TO THREE — ALL DRIVES DISASSEMBLE THE SAME.

Remove oil pump drive gear retaining rings. Remove drive gears from pump shafts.




**Figure 22**

On inline output remove companion flange cotter, nut, washer, "O" ring, and companion flange from inline turbine shaft.



**Figure 20**


Remove stator support bolts.



**Figure 23**


Remove inline turbine shaft by using a brass hammer and tapping on threaded end of shaft. Stator support and turbine shaft will come out as a unit.






**Figure 24**

On offset output remove turbine shaft gear retainer ring and turbine shaft gear.




**Figure 25**

Remove turbine shaft bearing retainer ring from stator support. **NOTE:** Use same procedure on inline output or offset output.




**Figure 26**

Press turbine shaft from stator support. Press turbine bearing from turbine shaft. Remove oil sealing rings from stator support and turbine shaft. **NOTE:** Use same procedure on inline output or offset output.




**Figure 27**

On the inline output Converter, the offset output shaft cover need not be removed unless "O" ring is to be changed.



**Figure 28**


Remove pump adaptor sleeve from pump shaft. Remove pump shaft washer retainer ring and pump shaft washer.



**Figure 29**


Tap on pump shaft from inside Converter Housing, pump shaft and bearings will come out as an assembly.






**Figure 30**

Remove pump shaft bearing locating ring. Press bearings from pump shaft.



**Figure 31**

Remove pressure regulator valve assembly. Use caution as not to lose safety valve plunger or spring (See arrow).



**Figure 32**

Depress piston stop and remove piston stop roll pin. Remove piston stop and inner and outer spring. Remove roll pin at opposite end. Remove valve stop and valve piston.


## CLEANING AND INSPECTION

Cleanliness of the respective parts is absolutely necessary in re-assembling. Dirt in its many forms can and will cause trouble. Therefore, re-assembling the Converter or any of its parts be sure all parts have been thoroughly cleaned with a suitable cleaning fluid. After cleaning, all parts should be dried with moisture free compressed air.

A thorough visual examination of all parts should be made before re-assembly. Any parts that show excessive wear or damage should be replaced. Small nicks or burrs may be removed with a hone or crocus cloth. It is recommended that all gaskets, oil seals, piston sealing rings, "O" rings and internal lockwashers be replaced.


A light coat of Permatex No. 2 applied to the outer diameter of oil seals, assures a good oil tight fit between oil seal and housing. The use of grease is recommended when positioning new gaskets in their respective locations. Piston sealing rings and "O" rings should be coated with Automatic Transmission Fluid to facilitate assembly.

## REASSEMBLY



**Figure 33**


Install valve piston (Top view Figure 33). Install valve stop and new "O" ring in valve housing and secure with roll pin. Install inner and outer valve spring in valve housing. Install valve spring stop and new "O" ring in valve housing. Depress spring stop and install spring stop roll pin.



**Figure 34**


Install pump shaft rear bearing locating ring. Press rear bearing on pump shaft with bearing snap ring toward rear of shaft. Install bearing spacer and press front bearing on shaft until it shoulders against bearing spacer.






**Figure 35**

Install pump shaft and bearing assembly in Converter Housing.




**Figure 36**

Tap pump shaft and bearing assembly in Converter Housing until rear bearing snap ring shoulders against bearing bore.




**Figure 37**

Install pump shaft washer and washer retainer ring. Pump adaptor sleeve can be installed just before pump.




**Figure 38**

Press offset output shaft oil seal in bearing retainer, Lip of seal in. **NOTE:** Oil seal must be pressed 5/16" below rear face of bearing retainer. Press rear output shaft bearing in bearing retainer and secure with retainer ring. Press inline output shaft oil seal in Converter Housing. Lip of seal in. **NOTE:** Oil seal must be pressed 5/16" below rear face of Converter Housing.



**Figure 39**


Press front output shaft bearing on offset output shaft and secure with bearing retainer ring. Install output shaft gear on output shaft.



**Figure 40**


Press offset output shaft, gear and bearing assembly through rear bearing and bearing retainer. Secure output shaft gear in vise equipped with soft jaws. Install companion flange, new flange "O" ring, flange washer and flange nut, tighten nut 200 to 250 foot pounds torque. Install nut cotter.






**Figure 41**

Install new "O" ring (See arrow) on offset output shaft bearing retainer. Install output shaft assembly to Converter Housing and secure with nuts, bolts and lockwasher, tighten 35 to 40 foot pounds torque.



**Figure 42**

Press rear bearing on turbine shaft, this is also the output shaft for the inline output Converter, install shaft oil sealing ring (See arrow).




**Figure 43**

Press shaft and bearing assembly in stator support. Use Caution as not to damage oil sealing ring. Secure bearing with retainer ring. Use same procedure on inline output or offset output.




**Figure 44**

Install output shaft gear on offset output shaft and secure with retainer ring.



**Figure 45**


Install oil sealing ring (See arrow) on stator support, Use same procedure on inline output or offset output.



**Figure 46**


Install companion flange spacer on threaded end of inline output shaft. **NOTE:** Spacer must be put on shaft before shaft installation in Converter Housing, as spacer will not pass through oil seal. Align holes in stator support with holes in Converter Housing. Install bolts and tighten 45 to 50 foot pounds torque. Lockwire in pairs to prevent loosening. On stator support, use same procedure on inline output or offset output.






**Figure 47**

Install oil pump drive gears and secure with retainer rings.



**Figure 48**

On inline output shaft install companion flange, new flange "O" ring, flange washer and flange nut. Tighten nut 200 to 250 foot pounds torque. Secure with cotter pin.




**Figure 49**

Press new oil seal in oil baffle with lip of seal down.




**Figure 50**

Press impeller bearing in impeller hub and secure with retainer ring. Install new "O" ring (see arrow) on impeller hub. Align holes in impeller hub with holes in impeller. Install bolts and tighten 35 to 50 foot pounds torque. Lockwire in pairs to prevent loosening.



**Figure 51**


Install oil baffle on impeller assembly. Install impeller hub gear on impeller hub and secure with retainer ring. Install new "O" ring on oil baffle (See arrow).



**Figure 52**


Install impeller and oil baffle assembly over stator support and into Converter Housing. Align holes in oil baffle with holes in Converter Housing. Install bolts and lockwashers into oil baffle. Tighten baffle bolts evenly to prevent damaging oil baffle "O" ring. Tighten 20 to 25 foot pounds torque.





**Figure 53**

Install reaction member on stator support with tang as shown.




**Figure 56**

Install turbine and hub assembly on turbine shaft and secure with outer retaining ring.




**Figure 54**

Install reaction member on stator support and secure with retaining ring.




**Figure 57**

Press pilot bearing in impeller cover and secure with retainer ring.



**Figure 55**


Install inner turbine locating ring on turbine shaft.



**Figure 58**


Heat impeller cover sleeve to 200° and press on impeller cover.






**Figure 59**

Install spring and plunger in Converter Housing. (See arrow). Install new gasket on valve assembly. Install new "O" ring on valve assembly. Secure valve assembly to Converter Housing with bolts and lock-washers. Tighten 20 to 25 foot pounds torque.



**Figure 60**

Install new "O" ring (See arrow) on impeller cover. Align holes in impeller cover with holes in impeller.




**Figure 61**

Install impeller cover to impeller bolts and lock-washers and tighten 20 to 25 foot pounds torque.

FLYWHEEL RING GEAR INSTALLATION  
C-270 SERIES CONVERTER ONLY

IF THE FLYWHEEL RING GEAR IS REMOVED OR REPLACED FOR ANY REASON, IT MUST BE INSTALLED AS SHOWN BELOW.



TIGHTEN SCREWS TO 20-25 FT. LB. ABOVE TORQUE REQUIRED TO RUN SCREWS INTO PLACE. (SCREWS HAVE INTERFERENCE FIT THREADS.)  
LOCKWIRE IN PLACE.

CAUTION

LOCKWIRE MUST NOT INTERFERE WITH TOOTH ENGAGEMENT BETWEEN THE DRIVE RING AND IMPELLER COVER.



CLARK OF COURSE



ONE SOURCE . . .

**CLARK®** OF COURSE