

**OPERATIONS  
AND  
MAINTENANCE  
MANUAL**

**FOUR AND SIX CYLINDER  
OVERHEAD VALVE GASOLINE ENGINE**

**WHITE**  
**ENGINES, INC.**

***Hercules Engine Division***

**101 ELEVENTH ST., S.E.**

**CANTON, OHIO 44702**

**A SUBSIDIARY OF WHITE MOTOR CORPORATION**

# OPERATION AND MAINTENANCE MANUAL FOR GASOLINE ENGINES


Four Cylinder Serial Numbers . . . . . 3110792 - 3120380

Six Cylinder Serial Numbers . . . . . 3306821 - 3317500


Four and Six Cylinder Serial Numbers\* . . . . . 3317501 - 3400000

\*All Four and Six Cylinder serial numbers are now included in one range of numbers

**WHITE** / *Hercules Engine Division*  
**ENGINES, INC.** / 101 ELEVENTH ST., S.E.  
CANTON, OHIO 44702  
A SUBSIDIARY OF WHITE MOTOR CORPORATION



6 Cylinder Series — Distributor Side



6 Cylinder Series — Carburetor Side

# Section and Group Index

	Page		Page
Description and Maintenance .....	16 to 53	Engine Trouble Shooting—Continued	
Air Cleaner .....	16, 17	Excessive Smoke from Exhaust .....	61
Bayonet Gauge .....	18	Explosion in Carburetor or Air Cleaner .....	64
Bearings, Main .....	36, 37	Explosion in Muffler .....	64
Bearings, Connecting Rod .....	21, 22, 23	Fuel System .....	56, 57
Bellhousing or Flywheel Housing .....	18, 19	Loss of Power .....	54, 55
Breather .....	17	Low Oil Pressure .....	63
Camshaft .....	19, 20	Rapid Cylinder or Piston Wear .....	63
Carburetor .....	21	Spark Knock or Ping .....	64
Connecting Rod .....	21, 22, 23	Valve Sticking .....	63
Cooling System .....	23, 24		
Crankshaft .....	24, 25	Fits and Tolerances .....	66 to 68
Cylinder and Crankcase .....	25		
Cylinder Head .....	25, 26	General Description and Features of Design .....	7, 8
Fan Assembly .....	26	Camshaft .....	8
Flywheel .....	27	Connecting Rods and Pistons .....	8
Fuel Pump .....	27, 28, 29	Cylinder Block and Crankcase .....	7
Gear Cover—External Governor .....	29, 30	Cylinder Head .....	7
Generator .....	30	Main Bearings .....	7
Governor—Velocity .....	30	Oiling System .....	8
Governor—External .....	31, 32, 33, 34	Piston .....	8
Ignition Timing .....	34, 35	Valves .....	8
Main Bearings .....	36, 37		
Manifold .....	37, 38	Introduction .....	5
Oil Filter .....	38		
Oil Pan .....	38, 39	Lubrication .....	13, 14, 15
Oil Pressure Regulator .....	40	Oil Changing .....	14
Oil Pump .....	40, 41	Description of Lubricating System .....	13
Oil Seal .....	42	Lubrication Instructions .....	13, 14
Piston .....	42	Lubrication Record .....	15
Piston Pin .....	43	Oil Level .....	14
Piston Rings .....	43	Viscosity Grades .....	14
Spark Plugs .....	44, 45	Use Good Oil .....	14
Starting Motor .....	46		
Thermostat and Bypass .....	47	Maintenance—See Description	
Valves .....	47, 48	and Maintenance .....	16 to 53
Valve Guides and Seats .....	48, 49, 50		
Valve Tappets .....	51	Operation .....	9 to 13
Water Pump and Fan Assembly .....	51, 52	Cold Weather Starting .....	12
Electrical Systems .....	53	Cold Weather Starting Suggestions .....	12
		Operating Instructions After Starting .....	11, 12
Engine Storage .....	13	Precautions .....	9, 10
		Starting and Operating Suggestions .....	10
Engine Trouble Shooting .....	54 to 64	Starting the Engine .....	10, 11
Bearing Failures .....	62, 63	Stopping the Engine .....	10
Burned Valves or Valve Sets .....	63, 64		
Clutch Assembly .....	58	Preventive Maintenance .....	14, 15
Cooling System .....	57, 58	Specifications .....	6
Electrical System .....	58 to 61	Tools .....	65
Engine Knocking .....	55	Warranty .....	4
Engine Misses Intermittently .....	54	Torque Wrench Torque .....	66 to 68
Excessive Oil Consumption .....	62		

# WARRANTY

## INDUSTRIAL ENGINE

Hercules Engine Division White Engines, Inc. (hereinafter called Hercules), warrants each new engine or component thereof, sold by it as follows:

For one (1) year from date of shipment from the factory, or for six (6) months of service, or 500 hours of service, whichever shall first occur, or such other period of time as may be agreed upon in writing by Hercules in respect to the application in which the engine is used.

Hercules shall furnish to the original owner-user, at its factory or at a point designated by it, without charge, parts to replace those parts which upon inspection at its factory or at such point, are determined by Hercules to have been defective in material workmanship.

This Warranty does not obligate Hercules to bear the cost of labor or transportation charges in connection with the replacement of defective parts or repair of the engine, nor shall it apply to an engine upon which repairs or alterations have been made unless authorized by Hercules.

Hercules makes no Warranty in respect to trade accessories, since they are subject to the warranties of their respective manufacturers.

THE FOREGOING WARRANTY IS THE SOLE REMEDY OF THE ORIGINAL OWNER-USER AND IS IN LIEU OF ALL OTHER WARRANTIES, WHETHER WRITTEN, ORAL OR IMPLIED (INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR PURPOSE), AND SUPERSEDES ANY DIFFERENT WARRANTY IN THE ORIGINAL OWNER-USER'S PURCHASE ORDERS. IN NO EVENT SHALL HERCULES BE LIABLE FOR CONSEQUENTIAL DAMAGES OR CONTINGENT LIABILITIES ARISING OUT OF THE FAILURE OF ANY ENGINE OR PARTS TO OPERATE PROPERLY.

---

**WHITE** / Hercules Engine Division  
**ENGINES, INC.** / 101 ELEVENTH ST., S.E.  
CANTON, OHIO 44702  
A SUBSIDIARY OF WHITE MOTOR CORPORATION

# Introduction

Hercules gasoline engines are available in four cylinder and six cylinder models, and are of the overhead valve, four cycle, heavy-duty commercial type engines. The design is the result of years of development and field experience. Extensive tests have proven that these engines are adaptable to purposes for which such sizes and types are required. The engines are built as vertical engines (piston motion in a vertical plane) or as horizontal engines having the pistons moving in a horizontal plane.

All locations given as right-hand (R.H.) or left-hand (L.H.) have reference to the observer's position when facing the flywheel or clutch. The cylinder block of the four and six cylinder models is reversible; therefore, the camshaft and distributor may be on either the right-hand or left-hand side, depending upon the application. The front of the engine is the timing gear end, regardless of the cylinder block position. The flywheel and clutch end is the rear end of the engine. Therefore, when reference is made to No. 1 cylinder or front main bearing, it is always the one nearest the timing gears. Cylinders, connecting rods, main bearing caps, etc., are numbered from the front or timing gear end of the engine and are all stamped on the camshaft side of the engine. All dimensions are given in inches and fraction of inches, except as otherwise noted. All weights and measures are in United States avoirdupois or liquid measure standards.

This book is divided into the following sections, which appear in the order named — Specifications, Operation, Lubrication, Description and Maintenance, Trouble Shooting, Fits and Tolerances and Tools.

Where necessary to refer to accessories which are not furnished by Hercules, information and comments given are general and may not apply to the specific accessory used.

As an operator, you owe it to yourself to read this book carefully.

# SPECIFICATIONS

Model	No. Cyls.	Bore and Stroke	Displacement Cu. In.
G-2000 .....	4	3 $\frac{3}{4}$ " x 4 $\frac{1}{2}$ "	198
G-2300 .....	4	4" x 4 $\frac{1}{2}$ "	226
G-3000 .....	6	3 $\frac{3}{4}$ " x 4 $\frac{1}{2}$ "	298
G-3400 .....	6	4" x 4 $\frac{1}{2}$ "	339

## MAIN BEARING

	Four Cylinder	Six Cylinder
Number of Bearings .....	5	7
Bearing Diameter (Main) .....	2 $\frac{7}{8}$ " — 73.0 MM	2 $\frac{7}{8}$ " — 73.0 MM
Bearing Length (Front) .....	1 $\frac{1}{32}$ " — 26.2 MM	1 $\frac{1}{32}$ " — 26.2 MM
Bearing Length (Center) .....	2 $\frac{1}{8}$ " — 54.0 MM	2 $\frac{1}{8}$ " — 54.0 MM
Bearing Length (Rear) .....	1 $\frac{1}{32}$ " — 26.2 MM	1 $\frac{1}{32}$ " — 26.2 MM
Bearing Length (Intermediate) .....	1 $\frac{1}{32}$ " — 26.2 MM	1 $\frac{1}{32}$ " — 26.2 MM
Bearing Length (No. 2) .....		
Bearing Length (No. 3) .....		

## CAMSHAFT BEARING

	Four Cylinder	Six Cylinder
Number of Bearings .....	4	4
Bearing Diameter .....	2 $\frac{1}{16}$ " — 52.4 MM	2 $\frac{1}{16}$ " — 52.4 MM
Bearing Length (Front) .....	1 $\frac{1}{16}$ " — 27.0 MM	1 $\frac{1}{16}$ " — 27.0 MM
Bearing Length (Intermediate) .....	1 $\frac{3}{16}$ " — 20.6 MM	1 $\frac{3}{16}$ " — 20.6 MM
Bearing Length (Rear) .....	1 $\frac{1}{16}$ " — 27.0 MM	1 $\frac{1}{16}$ " — 27.0 MM

## CONNECTING ROD

	Four Cylinder	Six Cylinder
Bearing Diameter .....	2 $\frac{3}{8}$ " — 60.32 MM	2 $\frac{3}{8}$ " — 60.32 MM
Bearing Length .....	1 $\frac{11}{16}$ " — 29.8 MM	1 $\frac{11}{16}$ " — 29.8 MM
Rod Length (C to C) .....	8" — 203.2 MM	8" — 203.2 MM

## GENERAL DATA

Cooling .....	Belt Driven Centrifugal Pump
Generator Mounting .....	Standard Swivel Type Generators
Water Pump—Fan Assembly .....	Mounted on Front of Cylinder Block
Method of Suspension .....	3 or 4 Point
Flywheel .....	For Any Standard Clutch

## GENERAL DESCRIPTION AND FEATURES OF DESIGN

### CYLINDER BLOCK AND CRANKCASE

The cylinder block and crankcase are cast in one piece, in order to permit more efficient cooling, by water jacketing the cylinders the full length of the bore. This construction results in a very rigid unit which provides a sturdy support for the crankshaft.

The cylinder block is so designed as to be reversible; that is, the crankshaft may be installed in the crankcase so that the camshaft may be on either the right-hand or the left-hand side of the engine. The timing gears and gear cover can be assembled to either end of the cylinder block. Therefore, it is essential that, when this engine is torn down for rebuilding, it be known and recorded which way the cylinder block is installed, that is, if the distributor or magneto is mounted on either the right or left-hand side of the engine.

### MAIN BEARINGS

The four cylinder engine has five main bearings and the six cylinder engine has seven main bearings. This permits a main bearing being placed on each side of each connecting rod bearing, see Illustration No. 1. This construction helps to eliminate vibration at high speeds. The center main bearing cap is held in position by four alloy steel cap screws  $\frac{1}{2}$ " in diameter, while the remaining bearing caps are held by two alloy steel cap screws  $\frac{9}{16}$ " in diameter.

The crankshaft end thrust is controlled by the center main bearing. This shell has suitable flanges on both sides of the bearing, which form a thrust bearing.

Precision or insert type bearings are used; in this construction there is a removable shell in each cap, as well as for the upper part, and the upper shell is not interchangeable with the lower shell except for the thrust bearing. These bearing shells are completely finished before being put in place and no line reaming or scraping is required. This allows removal of the bearings to be easily accomplished. Each bearing shell has a small ear or projection which fits into a recess in the cylinder block or cap, which allows the ear or projection to rest against the adjoining case or cap to prevent the shell from rocking or rotating. These shells are approximately  $\frac{1}{16}$ " thick, and the bearing metals commonly used are harder and have a higher melting point than ordinary babbitt metal. This permits the use of a hardened crankshaft.




Illustration No. 1

### CYLINDER HEAD

The cylinder head is a one piece, detachable casting and is attached to the cylinder block using a gasket, studs and nuts. The valve seats are usually machined right in the casting while the valve guides are the removable bushing type.

**CAUTION:** On a new or reconditioned engine, the cylinder head must be retightened and the valve tappet clearance reset after 25 to 40 hours of service. See "Fits and Tolerances," Page 66.

A torque wrench is recommended for this operation. See "Fits and Tolerances" for recommended tensions.



## CONNECTING RODS AND PISTONS

Like the main bearings, the connecting rods have the precision or insert type of bearing construction. No shims are used; therefore, bearing adjustment is accomplished by installation of new bearing inserts.

The piston pin is of the full floating type. This means that the pin can rotate in either the piston bosses or in the bushing at the top end of the connecting rod, but the fit in the piston is intended to be much tighter than the fit in the connecting rod bushing. Consequently, the movement in the piston consists of a light, creeping action while the normal rotation of the pin occurs in the bushing in the connecting rod. The piston pin is prevented from moving endwise and making connection with the cylinder wall by means of snap rings which are located in grooves machined in the bosses of the piston.

## CAMSHAFT

The camshaft is supported on removable bearings in the crankcase. At the center of the shaft is located the spiral gear, which meshes with the gear attached to the oil pump shaft and drives the oil pump. The camshaft end thrust is controlled by a thrust plate located between the front bearing and the camshaft gear. This plate is held to the cylinder block by two cap screws.

## VALVES

The valves are installed in the cylinder head. The intake valve head is larger in diameter than the exhaust valve head in order to increase the efficiency and insure more power. Both intake and exhaust valves are forged from special alloy steel and the exhaust valves, in particular, are of high heat resisting material. The exhaust valves of some engines may be equipped with a rotocap which permits this valve to rotate slightly during the opening and closing cycles. The valve tappets are of the mushroom type and are hollow to allow the push rod to properly seat.

## OILING SYSTEM

The lubricating system is the pressure type, having a gear type oil pump with the suction end in the oil pan oil sump and therefore needs no priming. The oil pump is gear driven through a suitable gear arrangement at the center of the camshaft and forces oil under regulated pressure to all main bearings, camshaft bearings, rocker arms, and connecting rod bearings.

The cylinder walls, valve tappets, and so forth, are lubricated by means of oil drain-back and the mist of oil thrown off around the various pressure-lubricated bearings.

External openings are provided for connection of an oil pressure gauge, by-pass type oil filter, or other accessories requiring pressure lubrication.

## OPERATION

This section covers those items which are of particular interest to the operator and does not cover such work as might be required of a maintenance crew. This does not mean that an operator should not acquaint himself with the various subjects covered in other sections of this book.

### PRECAUTIONS

#### READ BEFORE STARTING THE ENGINE

The precautions listed below, if followed, will help eliminate operating difficulties and abnormal wear.

1. **Filters**—keep them clean—they are the guardians of your engine—dirty filters cause rapid wear. low engine output. See “Oil Filters,” Page 39.
2. **Fuel**—keep it clean—do not use a dirty container to handle it—insist on the fuel being clean when you get it. Procure it from a reputable company.
3. **Lubricating Oil**—keep it clean—drain the crankcase often. Use the best brands obtainable, having specifications as set forth in “Lubricating,” Page 14.
4. Do not allow the **Oil Level** to fall much below the 4/4 mark on the bayonet gauge. As the lubricating oil is the medium for removing the friction heat in the bearings, the larger the volume of oil, the more heat it can absorb and dissipate. Do not fill above the 4/4 or full mark.
5. **Do Not Run The Engine** at any time without lubricating oil and a cooling solution (water or anti-freeze mixture).
6. Do not use oil, fuel oil or kerosene in the cooling system or as a cooling medium, as these will be detrimental to the synthetic rubber water pump seal.
7. **Never Run The Engine** with the water or anti-freeze solution **boiling**. This allows the lubrication to break down and may seriously damage the engine.
8. Do not put cold water in an **Overheated Engine**. It may crack the cylinder head, block, etc. An overheated engine shows negligence in operation.
9. Do not allow the **Air Cleaners** to become clogged or to operate without all the connections being tight. Keep them clean and properly serviced. These units protect your engine from undue wear only when they are given intelligent care.
10. Never allow your **Batteries** to run low or dry of water. The plates will warp and ruin the battery.
11. **Do Not Attempt Starting The Engine** until the lubricating oil, water and fuel supply have been checked and the engine properly prepared for starting See “Starting and Operating Suggestions,” Page 10.
12. **Do Not Run The Engine** at high speed without load, as this will cause undue wear and shorten the engine's life.
13. **Do Not Idle The Engine** for long periods, as it is not only detrimental to the engine but also increases operating costs as you are using fuel without any benefit.
14. **Do Not Use The Engine As A Brake** in intermediate or low gear unless the vehicle speed is held to that used in the same gears on the level. The high engine speeds possible when using low or intermediate gear descending steep grades will turn the engine much faster than the speed for which it is designed, and severe damage may result.
15. **Never Allow** the engine to **Run Without The Oil Pressure** showing on the gauge. Damage from lack of lubrication will result.
16. Do not allow the fuel in the tank to run low, as it may allow the line to the fuel pump to uncover long enough to fill the lines with air and cause the engine to stop, resulting in lost time taken for repriming.
17. Loss of power, erratic running and poor performance often result from **Air In The Fuel System or Vapor Lock**. Be sure there are no leaks in the fuel lines and filters which will allow this condition to exist.
18. Remember dirt, grit, water, lint or any foreign matter in the fuel and lubricating oil are detrimental to the engine and it is your duty, as an operator, to see that they do not get into the engine.
19. Do not attempt to start the engine in cold weather until you have read “Cold Weather Starting.” Page 12.

20. Some external heat will help starting in cold weather and save the batteries.
21. Never run the starting motor longer than 15 seconds at one time without a rest period of at least one minute before allowing it to run again. Failure to follow this procedure may result in a burned out starting motor.
22. **CAUTION:** On a new engine or reinstallation of the cylinder head, the cylinder head nuts must be retightened and the valve tappet clearance reset after 25 to 40 hours of service.
23. Do not attempt to start or operate this engine without first reading the instructions in this book carefully. As an operator, you owe it to yourself.

### STOPPING THE ENGINE

**CAUTION:** Always be sure the proper method of stopping the equipment and engine is fully understood before starting the engine.

1. If the engine has been operating at or near full load, it should be allowed to run at fast idle (800 to 1000 RPM) for one or two minutes after load is removed and then returned to idle before being stopped. This allows valves and other internal engine temperatures to equalize.
2. If the atmospheric temperature is below freezing and no anti-freeze solution is used, the complete water circulating system should be drained. This includes the engine water jackets, water pump, radiator and all water pipes.
3. If an anti-freeze solution is used, the solution should be checked with a hydrometer to make sure the solution will not freeze. It is best to have a solution that will not freeze at temperatures far below those then being experienced.
4. Do not fill the batteries with water when shutting down, as this makes them more liable to freezing. Fill the batteries just before starting up for the day's run.

### STARTING AND OPERATING SUGGESTIONS

1. Use a good brand of fuel.
2. Use only the best lubricating oil obtainable. See "Lubricating," page 14.
3. An SAE 20 oil is a good grade to start with (unless extreme cold weather is prevalent); from this, the proper grade can be determined. See "Lubrication" for complete information relative to the grade to use for the climatic conditions encountered.
4. Fill the cooling system with clean water (if in a locality where the water has a large percentage of dissolved minerals or is alkaline—use rain water). Allow sufficient time for the water to seek the lowest level, then complete filling. Run the engine and recheck the level.

**NOTE:**—Some Manufacturers of Permanent type Anti-freeze also market a cooling system sealer. It is recommended that this sealer be installed when installing the Anti-freeze solution.

5. Be sure the batteries are hooked up properly before pressing the starter button.
6. If possible, turn the engine over three or four times by hand to be sure there is nothing sticking or water has not seeped into the cylinder, as the starting motor has sufficient power to bend or break certain parts should anything be out of place.
7. Be sure all fuel line connections are tight and the fuel system properly primed.
8. Always follow the starting instructions outlined below to eliminate difficulties.

### STARTING THE ENGINE

**First Time the Engine Is Started** or starting the engine after a long period of shutdown.

1. Fill the fuel tank with suitable fuel.
2. Fill the cooling system with clean, pure water, or, if the atmosphere is below freezing and the engine is to stand or operate in these temperatures, use an anti-freeze solution.
3. Fill the crankcase with suitable lubricating oil to the 4/4 or full mark on the oil gauge rod. See "Lubrication" and "Bayonet Gauge."

## OPERATION

---

4. If possible, turn the engine over by means of a hand crank three or four times to start oil circulation and distribute the oil already on the surfaces. This hand cranking also prevents possibilities of damage due to water having accumulated in the cylinders.
5. In addition to the procedure just described, check the lubrication of the generator, starter, fan, water pump and any other accessories. Check the air cleaners to make sure there are no obstructions, that they are properly installed, and are clean, and that they are properly filled with oil (if oil bath cleaners are used). **"Check Fan Belt Tension."**
6. Check the entire electrical system to be sure there are no loose connections and all component parts are properly connected together.
7. See that no loose bars, tools, parts, etc., are lying in, or on, any part of the engine, as they could cause serious damage or wreckage of the engine or bodily injury to anyone near.
8. **Never attempt to start with a wide-open throttle.** Have the throttle open not more than one-fifth of the total opening.
9. Turn the ignition switch to "On." Crank the engine with the choke completely closed for a couple of turns or until the engine fires and then open the choke part way to prevent **"flooding."** As the engine warms, the choke should be opened fully. (A little practice in proper choke operation makes starting very easy). If the carburetor is equipped with automatic choke, it should require no action by the operator. Simply turn on the switch, operate the throttle to start the engine.

**Usual Routine Way of Starting the Engine.** If the engine has been operating recently and nothing has been removed or repaired since it last operated the following is all that is necessary to start:

1. Check fuel supply.
2. Check the lubricating oil in the engine base with the gauge rod. Be sure the oil is to the 4/4 or full mark on the rod. See Illustration No. 6.
3. Check the cooling solution.
4. Inspect the installation to see that all is in good order and tight and no loose tools, bars or parts are lying on the engine.
5. **Never attempt to start the engine with a wide-open throttle.** Have the throttle open not more than one-fifth of the total opening.
6. Start the engine by operating the starter switch after turning the ignition "On." Use the choke as discussed in No. 9, above.

## OPERATING INSTRUCTIONS AFTER STARTING

After the engine has started, an inspection of the whole engine unit should be made to make sure all parts are functioning properly.

1. Look at the lubricating oil gauge. If no pressure shows after the the engine has run 10 to 12 seconds, shut down the engine and ascertain what the trouble may be. With the bearings in good condition and the proper grade of oil, the pressure should be 30 to 40 pounds at full engine speed. If the oil is very cold or heavy, this pressure may be much higher. As the oil heats up, the pressure will reduce.
2. Check the water temperature. If the water temperature is above 200° F., shut down the engine and ascertain what the trouble may be. Never operate with the water boiling, as this heat on the cylinder walls breaks down the oil film and also causes considerable water loss due to evaporation.
3. See that no loose tools or parts are lying on, or near, the unit, as they might fall into a place where they would cause damage or personal injury.
4. Observe the engine operation for smoothness, quietness and exhaust condition. If the fuel is up to specifications and has the proper ignition qualities, the engine may still run **raggedly** because a cylinder or two is firing irregularly due to being cold. As the engine begins to **warm up**, however, all cylinders should fire regularly. If they do not, trace out the trouble, some hints of which will be found in **"Engine Trouble Shooting,"** Page 54.
5. See that there is an adequate supply of fuel in the tank and that fuel is being delivered to the fuel pump. The delivery can be checked by slightly loosening the nut connecting the supply pipe to

the carburetor; if a good quantity of fuel appears, it is an indication that the fuel pump is being supplied with sufficient fuel. If no fuel or very little appears, shut down the engine and check the supply tank again. If the fuel supply is inadequate, check the fuel line from the tank to the pump for leaks from loose connections, broken nuts and cracked or broken lines. Also check the lines for obstructions inside or having been pinched closed or nearly so. If the lines are found satisfactory, check the pump for a broken diaphragm, springs and worn or broken valves.

6. Check and see that there are no oil or water leaks.
7. Clean the lubricating oil filter often. This will insure maximum efficiency from this unit and does not require much time or energy to accomplish.
8. Keep all the fuel filters clean and give them regular attention.
9. Observe the fan and belt operation. Loose fan belts allow slippage, which reduces the efficiency of the fan and wears the belts out rapidly, and, also, affects the efficiency of the water pump.
10. See that the radiator, if one is used, is free of obstructions between the fins or tubes, as they will obstruct the air flow and reduce the cooling efficiency of the radiator unit.

### COLD WEATHER STARTING

At extremely low temperatures, difficulty may be encountered in starting the engine due to (a) battery charge or output being low due to temperatures or (b) gasoline with vapor pressure too low to readily vaporize or (c) improper choke action.

In starting any engine, and particularly a cold engine, do not allow it to run up to governed speed or do not run the engine much over 800 or 1000 RPM until the oil has become warm enough to circulate and the water or cooling solution has become warm enough to take the chill off the cylinder block. This usually takes four or five minutes if the engine is equipped with a thermostat. A longer period is generally required for engines not so equipped; these engines should have the radiator covered for the first few minutes in order to allow the water or cooling solution to warm up. If the unit is not equipped with a thermo-gauge or thermometer, this can then be checked by placing the hand on the cylinder block or cylinder head and, as soon as the engine becomes warm enough, can be run up to maximum speed. This is probably the most important phase of the engine operation, as damage can result in the first few seconds of running if the engine is allowed to run maximum load and maximum speed before lubrication has been established and before the parts have started to warm up normally. For correct oil to use, see "Viscosity Grades," Page 14.

### COLD WEATHER STARTING SUGGESTIONS

If ignition and carburetor are correct, starting in cold weather can be made less difficult by observing the following suggestions.

1. Late ignition timing causes hard starting. (Magnet impulse coupling should click or release on, or slightly after, top dead center.)
2. Never attempt to start with a wide-open throttle. Have the throttle open not more than one-fifth of the total opening.
3. Close the carburetor choke and turn the engine several times before the ignition switch is closed, if the engine is hand cranked.
4. Close the ignition switch and keep the choke closed nearly all the way, then crank the engine over in the same way as has been followed in warmer weather.
5. When the engine starts to fire, keep the choke partially closed until the engine warms up sufficiently to run normally.

**NOTE:**—With automatic choke equipment no manual choke action is required.

6. Heating the cooling solution and lube oil will assist starting in extremely cold weather.
7. Lube Oil — See Viscosity Grades Page 14.
8. Cheap gasoline makes cold weather starting very difficult.
9. Be sure the gasoline flows through the carburetor. Ice may have blocked the gasoline due to water in the gasoline.
10. If the engine has been standing idle for several days, remove the spark plugs and dry out; at the same time, pour a tablespoon of oil in each spark plug hole.

## LUBRICATION

### ENGINE STORAGE AND RUST PREVENTION

If the engine is to be idle for a month or more, special preparation should be made to protect the internal engine parts such as valves, cylinder bores, camshaft or other working parts from RUST. This is especially necessary in high humidity conditions. The following method of preparation has proved very successful when followed thoroughly.

- A. Start and operate the engine a few minutes, under load if possible, until the water and oil temperatures are normal. Then drain all the lubeoil from the oil filters.
- B. Refill the oil pan to the "Full" mark of the gauge with an oil similar to the following using the proper viscosity for the climatic conditions.

#1 — Gulf No-Rust Engine Oil — Grade #1 — SAE #10W

Grade #2 — SAE #30

#2 — Shell Ensis Mill-L-21260 — Code 66200 — SAE #10W

Code 66202 — SAE #30

**NOTE:**—It is also recommended that oil of this type be used when the end unit is to be shipped with lubeoil in the engine or when the unit is used for demonstration purposes.

- C. Engines which have been operating on leaded gasoline should be run on Unleaded or standard White Gasoline for at least ten minutes in addition to the time it takes to run out the leaded gasoline in the fuel lines and carburetor.
- D. Remove the air cleaner and with the engine running at approximately 1200 to 1500 R.P.M., slowly pour about 4 ounces of the above no-rust oil into the carburetor air intake. Gradually increase the amount of oil through the carburetor until the motor stalls and stops. Shut-off ignition switch.
- E. Remove the spark plugs and, using a pump type oil can with a long narrow spout, give each cylinder six or eight squirts of the no-rust oil through the plug holes.
- F. Remove the rocker arm cover and thoroughly oil the rocker arms, valve springs and valve stems. Crank the engine over with the starter a couple of times while oiling the rocker arms and valve stems.
- G. Reassemble the rocker arm cover, spark plugs and any other removed parts. In damp or humid climates seal off all openings with moisture proof tape. (Breather, air intake, exhaust pipe, etc.).
- H. Approximately every two weeks the engine should be cranked over six or eight revolutions to redistribute the oil film over the wearing surfaces and prevent rust.

The above rust proofing methods have proved successful in practically all cases; however, White Engines, Inc., Hercules Engine Division cannot assume any responsibility for engine storage results.

## LUBRICATION

### DESCRIPTION OF THE LUBRICATING SYSTEM

The lubricating system is the pressure type, having a gear type oil pump with the suction end in the oil pan oil sump and therefore needs no priming. The pump is gear driven through a suitable gear arrangement at the center of the camshaft.

The oil pump forces the oil under pressure to the main oil header in the cylinder block. This oil header is a drilled passage extending the length of the cylinder block on the side opposite the camshaft and is closed at both ends with suitable plugs.

The oil pressure is controlled by a pressure control mechanism assembled to a passage drilled in the cylinder block which connects directly with the oil header. Also, there is a safety pressure relief valve assembled to the oil pump which prevents excessive pressure build-up.

From the main header the oil is distributed, under controlled pressure, through drilled passages to all main bearings, camshaft bearings, and rocker arms. From the main bearings oil is delivered under pressure, through drilled passages in the crankshaft, to all connecting rod bearings.

The cylinder walls, valve tappets, and so forth, are lubricated by means of oil drain-back and the mist of oil thrown off around the various pressure-lubricated bearings.

External openings are provided for connection of an oil pressure gauge, by-pass type oil filter, or other accessories requiring pressure lubrication.

## LUBRICATION INSTRUCTIONS

**Oil Level.** The level of the oil in the crankcase is determined by a bayonet or dip stick type gauge. Wipe off the gauge and reinsert to determine the oil level accurately. The oil level should be maintained at, or near, the 4/4 (or FULL) mark on the gauge. See Illustration No. 6.

The engine must be stopped for at least two minutes before the oil level is checked. This time will allow the oil to drain back into the oil pan and prevent overfilling.

## OIL CHANGING

Frequency of oil changes depends on the application of the engine and the severity of the operation. Under normal operating conditions the oil, and Oil Filter should be changed every 100 hours. A new or reconditioned engine should have the oil, and the Oil Filter changed after the first 50 hours of operation.

Frequent and regular oil changing, together with the use of good oil, is low cost insurance against expensive repairs.

## USE GOOD OIL

White Engines, Inc., Hercules Engine Division recommends that only the best quality, heavy-duty, detergent type oil produced by recognized concerns familiar with the lubrication requirements of internal combustion engines be used. An oil having an A.P.I. service designation of "SD or SE" is recommended.

## VISCOSITY GRADES

The S.A.E. numbers indicate the relative viscosity or body of the lubricating oil. Select grade of oil from the following tabulation:

<u>Air Temperature</u>	<u>S.A.E. Number</u>
-10°F to 30°F	10W
30°F to 60°F	20 - 20W
40°F and Up	30

The filter should be changed at the same time the oil is changed in the crankcase. Recheck the oil level after running the engine approximately five minutes to fill the filters. Use the bayonet gauge when replenishing the oil supply and fill to the 4/4 (or FULL) mark on this gauge.

## ACCESSORIES

Accessories mounted on the engine usually carry their own lubricating instructions, which should be followed.

## SUGGESTED PREVENTIVE MAINTENANCE SCHEDULE GASOLINE - LPG - NATURAL GAS

### A. DAILY

1. Check air cleaner. See note \*.
2. Check crankcase oil level.
3. Check coolant level.
4. Check generator charge.
5. Check oil pressure reading.
6. Check general condition of unit. Tighten, repair, or replace parts as necessary.

\*--The air cleaner must be checked (maintain proper oil level) and cleaned every four hours in very dusty or dirty areas. In other areas it may be possible to extend the time to 50 or 100 hours. All connections between air cleaner and carburetor must be air-tight.

## LUBRICATION

B. 100 HOURS OR 3000 MILES. IN ADDITION TO "A" SERVICES

1. Change crankcase oil, and oil filter.
2. Clean crankcase breather system.
3. Lubricate generator, distributor, etc.
4. Tighten accessory drive belts.
5. Check radiator air passages for air flow restrictions, dirt, chaff, etc. Clean, if dirty.

C. 400 HOURS OR 12000 MILES. IN ADDITION TO "B" SERVICES

1. Tune-up.
2. Check and adjust or replace ignition points and condenser.
3. Replace spark plugs.
4. Check compression. If variation between cylinders exceeds 25%, schedule unit for valve, piston ring or major overhaul as necessary.

[illegible]

\* Mark in date if different from crankcase oil change, otherwise check.



## DESCRIPTION AND MAINTENANCE

This section covers a brief description and function of the various parts of the engine along with complete instructions covering the repair, disassembly and reassembly of the various component parts of the engine.

This section has the various subjects arranged alphabetically for convenience in locating.




Illustration No. 2

### AIR CLEANER

Since dirt is the greatest enemy of any internal combustion engine, it is necessary to take every precaution to prevent it from entering the engine. This is accomplished by the use of efficient air cleaners, either Dry or Oil Bath type, many versions of which are available. Two typical types of popular air cleaners are shown disassembled in Illustration No. 2 (Dry Type) and Illustration No. 3 (Oil Bath).

The Oil Bath Air Cleaner (Illustration No. 3) accumulates the dirt which they separate from the incoming air in the screen and oil reservoir. Proper dirt removal depends on keeping the elements clean and maintaining the correct oil level in the reservoir to insure full screen bathing action. Therefore, the oil level **MUST** be maintained.

Each 100 to 150 hours, or until a satisfactory maintenance schedule suited to actual operating conditions can be worked out, the air cleaner should be removed from the engine, thoroughly washed and cleaned. The oil reservoir and screen should be soaked and washed with solvent or gasoline and blown dry with compressed air, if available. If compressed air is not available, wipe the air cleaner bowl dry and shake the screen as dry as possible. Before reassembling the cleaner, dip the screen in clean lubricating oil and fill the reservoir to the proper level (use the same grade as used in the engine crankcase). Inspect the bowl gasket and, if broken or torn, replace with a new gasket. Reassemble the air cleaner and install the complete unit on the engine, making sure all connections between the air cleaner and manifold are air tight.




Illustration No. 3

## GENERAL DESCRIPTION AND MAINTENANCE

The Dry Type Air Cleaners (Illustration No. 2) are very popular due to their high efficiency in removing dirt and also to the ease of maintenance.

The Dry Type requires the same attention to maintenance schedule, element changes and air tight connections as the Oil Bath Type. This will vary as to operating conditions.

It is very essential that all connections between the air cleaner, carburetor, manifold and cylinder head be absolutely air tight. It is possible under certain conditions for enough abrasive laden air to be drawn into the engine through a loose connection or faulty gasket to cause rapid wear to the cylinders, rings, valves and other internal operating parts. Also as the dirt builds up, due to lack of maintenance and accumulates in the carburetor passageways, it has an action similar to closing the choke valve. This may show as a lack of power, excessive fuel consumption, internal engine deposits, lube oil dilution, cylinder wash or other trouble which can cause poor performance and rapid engine wear. Very little restriction due to dirty air filters is sufficient to create a very rich fuel mixture. Therefore, one of the most essential preventative measures is proper maintenance of the air intake filters. The unit should be checked at least once a day and, if operating in severe dusty conditions, may require cleaning as often as three or four times daily.




Illustration No. 4

**NOTE:**—If a pre-cleaner is used, it also must be removed and serviced regularly.




Illustration No. 5

### BREATHER

The breather allows clean air to enter or accumulated gases to escape from the crankcase, the normal process of engine breathing. The two breathers illustrated, Illustrations No. 4 and No. 5, are the screen type and are easily removed for servicing.

They should be inspected at frequent and regular intervals, the period depending on the kind or conditions of operation. If required, all parts should be thoroughly cleaned with solvent and blown dry with compressed air to insure free breathing action.

Before reassembly to the engine, apply a small quantity of lubricating oil (the same as used in the engine crankcase) to the screens.

If positive type crankcase ventilation is used (required on some specifications) it may consist of the following:

1. A crankcase ventilation valve is usually mounted between the rocker arm and the intake manifold.
2. An oil bath air cleaner of suitable capacity mounted on the oil filler pipe, the rocker arm cover or other suitable locations to permit clean air to enter the crankcase.

Both the ventilating valve and the air cleaner must receive frequent and regular attention to insure proper operation, the period depending on the kind of operations encountered.

## BAYONET GAUGE

The bayonet gauge is used to determine the amount of oil in the oil pan and is readily accessible. The oil level in the oil pan should always be maintained at, or near, the FULL mark Illustration No. 6. When the oil level drops to the ADD mark on the gauge, add one U. S. quart.

## BELLHOUSING

The bellhousing is a casting which covers the rear end of the cylinder block. There are many types of housings used, some of which may be a plate type housing and others which form a complete housing for the flywheel and clutch, to which the transmission, torque converter or other drive mechanism is attached. The bellhousing usually forms the rear motor support.

### TO REMOVE THE BELLHOUSING

1. Drain the crankcase oil.
2. Remove the clutch or power take-off mechanism and electric starter.
3. Remove the flywheel. See "Flywheel," Page 27.
4. Remove oil pan.
5. If the engine is in the unit, place suitable supports under the rear of the crankcase to support the engine.
6. Remove the rear motor support screws.
7. Remove the bellhousing attaching screws and stud nuts.

**NOTE:**—There are four bolts from the oil pan adapter to the bellhousing. (See Illustration No. 1.).

8. Pull the bellhousing away from the engine, Illustration No. 7. It may be necessary to tap the housing with a soft hammer to loosen from the dowels or gaskets sticking to the block.

### TO INSTALL THE BELLHOUSING

1. Install a new oil seal in the bellhousing, using a small amount of sealing compound in the bore before pressing in the seal. Cement a new gasket to the bellhousing, allowing cement to dry sufficiently to prevent the gasket from skidding.




Illustration No. 6




Illustration No. 7

2. Clean and polish the oil seal surface of the crankshaft, making sure there are no nicks or scratches present. Crocus cloth or very fine polishing cloth is suitable for this purpose.
3. Apply a thin coat of oil soap to the seal and the seal surface of the crankshaft. Be sure the hole marked (A), Illustration No. 7, is plugged with the socket head screw. Using care in placing the oil seal over the crankshaft and making sure that the dowels properly enter their respective holes, assemble the bellhousing to the engine and secure in place with the screws and nuts as removed. Check the bellhousing mounting dowels to be sure that they are tight and in good condition.
4. Install the rear motor support screws and remove the jack or block from under the crankcase.
5. Install the flywheel. See "Flywheel."
6. Install the clutch or power take-off mechanism, oil pan and electric starter.
7. Fill the crankcase to the proper level with the correct grade of lubricating oil.

## CAMSHAFT

The camshaft is supported on three or four (depending on the model) large diameter pressure lubricated removable bearings in the crankcase and is driven by means of a suitable gear which meshes with the crankshaft gear.




Illustration No. 8




Illustration No. 9

**NOTE:** There are two crankshaft-camshaft gear combinations used in clockwise rotating engines. Counter-clockwise rotating engines have two similar combinations, but the helix angle of the gear teeth is cut in the opposite direction so that the thrust forces of the gears may be properly controlled.

One combination, having a twenty-five tooth crankshaft gear and a fifty tooth camshaft gear, used with distributor ignition is considered standard.

The second combination, having a twenty-four tooth crankshaft gear and a forty-eight tooth camshaft gear, is used with horizontal drive magneto ignition.

The timing of these two gears requires no check of position of the valve. It is only necessary to line up the punch marks on the two gears, the cam gear being shown as (A) and the crank gear as (B) in Illustration No. 8.

The camshaft end play is controlled by a thrust plate (A), Illustration No. 9, located between the front camshaft bearing and the camshaft gear. Correct end play of .0015" to .0035" is regulated by the thickness of the thrust plate.

## TO REMOVE THE CAMSHAFT

Assuming that the radiator, and so forth, have been removed, the camshaft may be removed, as follows, without removing the engine from the chassis.

1. Drain the lubricating oil and remove the oil pan.
2. Turn the engine over until No. 1 cylinder is on top dead center and remove the oil pump.
3. Disconnect and remove the distributor, if used.
4. Remove the fan blade and belt for easier access to the gear cover and gears.
5. Remove the crank grab nut and fan drive pulley.
6. Disconnect the governor linkage and remove the gear cover. See "Gear Cover," Page 29.
7. Remove the governor parts, if used. See "Governor, External," Page 31.
8. Remove the rocker arm cover, rocker arms and push rods.
9. Valve tappets must be held in the "up" position in order to remove and insert the camshaft. One method of accomplishing this is to make a holder, Illustration No. 10, from music wire by bending a "V" on one end of the wire. This holder may be inserted into the hollow part of the tappet and the tappet lifted away from the camshaft. This holder is then bent over the push rod hole edge of the cylinder head so that the tappet will remain in this position. Use one wire for each tappet.

**NOTE:** To remove and assemble the camshaft to the engine with the engine out of the chassis, the same procedure is followed, except Item No. 9 is disregarded. With the engine out of the chassis, it is only necessary to set the engine on the bellhousing or upside down (support the engine with suitable blocks so that the cylinder head studs will clear), push the tappets to the "up" position and remove the camshaft.

10. With the tappets in the raised position, rotate the engine until the two holes in the camshaft gear expose the thrust plate attaching screws. Illustration No. 11.
11. Remove the thrust plate attaching screws and pull the camshaft forward out of the engine block. Inspect the camshaft lobes, oil pump gear, journals, etc., for wear or damage. Also, inspect the thrust plate for clearance. If any of the parts need replacement or adjustment, disassemble the camshaft and drive gear as follows:

Remove the nut, place the shaft in an arbor press and, with suitable supports under the gear press the shaft out of the gear.




Illustration No. 10




Illustration No. 11

## CARBURETOR

A carburetor is an accessory designed to mix gasoline and air in proper proportions and to furnish this proportionate mixture to the engine under varying operating conditions.

It is essential to clearly recognize that the function of the carburetor cannot extend beyond the proportionate mixing of fuel and air. This knowledge will avoid many false leads in diagnosing so-called "carburetor troubles."

The carburetor, itself, including all the carefully designed and balanced jets, floats, passageways, compensators, chokes and internal adjustments are determined and established at the factory only after extensive and exhausting tests to determine the correct air fuel mixture for all loads and speeds of the engine. **NO TAMPERING OR CHANGES** by inexperienced or unauthorized persons should be tolerated by any Operator as serious damage can result.

If internal or major service is needed the work should be done only by authorized carburetor service center. They have the specifications, correct parts and know-how to restore it to factory specifications and to insure proper operation.

The things that should be done by the maintenance man is to be sure all linkage, throttle levers, choke connections, etc. are kept properly adjusted and tightened so that full throttle and choke action is maintained. Also, air cleaner or hose attaching parts must fit and be kept air tight as described under "Air Cleaner," Page 16.

### AIR CLEANER AND AIR FILTER RESTRICTION—AFFECT ON CARBURETION

Most air filters, now used on gasoline engine carburetors, accumulate the dirt they separate from the incoming air. As this dirt builds up, it has an action similar to closing the choke valve. Both cause restriction and this increases the suction on the carburetor jets. Very little increase in suction is sufficient to create a mixture so rich that it will not only seriously impair engine operation but will also dilute the oil and cause as much wear as dirt. See "Air Cleaner."

## CONNECTING ROD

The connecting rods are heavy alloy steel forgings with precision type bearings for the shaft and bronze bushings for the piston pins. With this precision or insert shell type bearing, the cap and rod is split slightly below center so that the bearing split opposite the locking lugs does not match with the split in the forging. No shims are used and, therefore, when reconditioning of the bearings is necessary, only the bearing shells need to be replaced.

**CAUTION:** Do not file or grind the caps, as new bearings cannot be installed in a connecting rod that has been filed.

**NOTE:** As built at the factory, the connecting rods and caps are marked on the camshaft side and to the front of the engine with the cylinder number in which they are used.




Illustration No. 12




Illustration No. 13

### TO REMOVE THE CONNECTING RODS

**CAUTION:** Connecting rods and caps are matched—keep them paired together, as otherwise they cannot be reinstalled.

1. Drain the radiator and disconnect the hoses.
2. Remove the thermostat housing and thermostat so that the water pump bypass hose can be removed from the water pump. Also, disconnect the water temperature gauge thermocouple.
3. Disconnect and remove the carburetor from the manifold.
4. Disconnect the exhaust pipe from the manifold and remove the head cover heat shield, if used.
5. Disconnect the wires and remove the distributor from the engine.
6. Remove the cylinder head cover, rocker arm assemblies and push rods.
7. Remove the cylinder head nuts and lift the cylinder head assembly carefully from the engine (manifold may be removed with the head).
8. Remove the oil pan and crank the engine so that No. 1 cylinder is in firing position and remove the oil pump. If a tachometer drive is used, this must be removed before the oil pump can be removed.
9. Carefully scrape the carbon deposit from the top of each cylinder bore so that the pistons can be removed without damage to the rings.
10. Turn the crankshaft so that the connecting rod caps can be removed and the piston and rod assembly pushed carefully upward with a block of wood or hammer handle, Illustration No. 12, to remove from the engine.

**NOTE:** Keep the rod cap and bearings of each respective rod together—do not mix.

11. Turn the engine, as required, so that the other rods and pistons may be removed.

### TO DISCONNECT THE CONNECTING RODS FROM THE PISTONS

Remove the piston pin retaining rings and push the pin out of the piston and connecting rod bushing. The pistons may be heated in boiling water to facilitate removal of the piston pins.

Inspect the piston pin and bushing for wear and replace, if necessary. If new parts are used, check the connecting rod alignment on a standard aligning fixture.

### TO INSTALL THE CONNECTING RODS

1. Assemble the connecting rod and piston and insert the retaining rings.

**NOTE:** To make it easier to assemble these parts, the piston may be heated in boiling water for a few minutes. **Do not heat the piston pin.**

2. Inspect the crankshaft for any rough or scored marks that might damage the connecting rod bearing. If any rough marks are found, use an oil stone, very fine emery cloth or Crocus cloth to polish the shaft. Clean the shaft thoroughly after polishing.
3. Install the piston rings on the pistons. See "Piston Rings," Page 43.
4. Select the proper piston and connecting rod assembly and turn the crankshaft so that it is in the correct position.
5. Apply a liberal coat of lubricating oil to the cylinder bores, pistons, rings and piston pin. Space the piston rings so that no two slots are in line.
6. With the piston rings compressed as shown in Illustration No. 13, use a hammer handle or block of wood to force the piston and rings into the cylinder bore. At the same time, use care that the connecting rod is in line with the crankshaft journal.
7. With the piston entirely in the cylinder bore, insert the upper shell and pull the connecting rod down to the crankshaft.

## GENERAL DESCRIPTION AND MAINTENANCE

---

8. Place the lower shell in the cap and assemble the cap to the connecting rod. Tighten the cap screws to proper tension and try the connecting rod for side movement. See **Fits and Tolerances** for proper clearance and proper cap bolt tension.
9. Repeat the above operations for all connecting rods.
10. Install the oil pump. See **"Oil Pump,"** Page 40.
11. Inspect the top of the cylinder block and pistons. Be sure no foreign matter is present and install the cylinder head gasket.
12. Install the cylinder head. See **"Cylinder Head,"** Page 25.
13. Insert the valve push rods and install the rocker arm assemblies.
14. Adjust the tappets to the proper clearance. See **"Valves,"** Page 47.
15. Install the cylinder head cover, using a new gasket. Install the nuts and washers as removed.
16. Install the thermostat, thermostat housing and water pump bypass hose and connect the water temperature gauge thermocouple.
17. Install the distributor and connecting wires. See **"Ignition Timing,"** Page 34.
18. Install and connect the carburetor and connect the exhaust pipe to the manifold. Install heat shield.
19. Connect the radiator hoses and fill the radiator with clean water or anti-freeze.
20. Install the oil pan, using new gaskets, and fill the crankcase with the proper grade of lubricating oil.

### CONNECTING ROD BEARING REPLACEMENT

If excessive clearance develops between the shaft and bearing shells, new bearing shells should be installed. If the clearance is excessive with the new bearings, regrind the shaft and use undersized bearings.

The connecting rod bearings may be replaced as outlined below.

1. Remove the oil pan. See **"Oil Pan,"** Page 39.
2. Locate the crankshaft so the connecting rod cap can be removed.
3. Remove the cap screws.
4. With a soft hammer, tap the cap to loosen it and remove the cap.
5. Replace the bearing shells as outlined under 8, 9 and 10 above.
6. Reassemble the oil pan to the engine. See **"Oil Pan."**

### COOLING SYSTEM

Perhaps the best method for care of the cooling system is to clean and flush the system periodically; also, use some good rust and corrosion preventive between cleaning periods. Almost all natural water contains some mineral salts which stimulate corrosion.

Exhaust gas leakage between the cylinder head and gasket also results in corrosion if exhaust gases discharge into the water, combining to form a variety of acids, such as carbonic, nitrous and sulphurous, all supporting electrolytic corrosion. The cylinder head bolts should be re-torqued when the engine is being given a major tune-up.

Air leaks around the hose connections and through the water pump should be carefully guarded against, since oxygen is a major factor in promoting corrosion. Check the hose connections frequently for air leaks.

If the engine or unit is equipped with a pressure type sealed system, it is imperative that the correct type radiator cap be used. This is determined by the type of system used.



There are two types of sealed cooling systems which are used extensively. One type has a safety relief valve arrangement built into the radiator filler cap. Illustration No. 14. The overflow pipe is also connected to the radiator filler neck above the lower seat of the pressure cap. In this manner, if excessive pressure develops in the cooling system, the lower part of the pressure cap will raise from its seat and allow the vapor to escape through the overflow pipe.

This type of cap should never be removed quickly. Always turn the cap off slowly until the pressure has escaped through the overflow pipe, then remove the cap.

The second type of pressure sealed cooling system has the pressure relief valve and overflow pipe built into the top tank as a separate unit (not connected to the filler neck).

However, if any type of sealed cooling system is used, the proper filler cap, good gaskets and a smooth gasket surface are essential if excessive loss of coolant is to be prevented.

From the above, it can readily be understood why serious overheating of the engine results when the incorrect filler cap, bad gaskets or a rough surface are encountered.

Use a good commercial neutralizer in the cooling system—one purchased from a reputable company. To obtain the best results, follow the instructions of the manufacturer.

## CRANKSHAFT

The crankshaft is a machined forging having all bearing journals surface-hardened. The nominal diameter of the main bearings is  $2\frac{7}{8}$ " while the nominal diameter of the connecting rod journals is  $2\frac{3}{8}$ ". The shaft has passages drilled to carry oil, under pressure, to the connecting rod bearings. These passages should be cleaned with a wire brush, see Illustration No. 15, before the shaft is installed in the engine.

While the diameters given above are only nominal, the following table gives the actual sizes, both standard and undersize, to which the shaft may be reground.

**WARNING!** When regrinding a crankshaft, it is imperative that the original radius from journal to cheek be maintained. Crankshaft breakage may result from improper grinding of this fillet.

## HEAVY DUTY CRANKSHAFT

Size	Main	Connecting Rod
Standard	2.8734/2.8744"	2.3730/2.3740"
.020" U. S.	2.8534/2.8544"	2.3530/2.3540"
.040" U. S.	2.8334/2.8344"	2.3330/2.3340"
.060" U. S.	2.8134/2.8144"	2.3130/2.3140"




Illustration No. 14




Illustration No. 15

## GENERAL DESCRIPTION AND MAINTENANCE

---

To replace crankshaft main bearings, see **Main Bearings.** To replace crankshaft connecting rod bearings, see **"Connecting Rod."**

### TO REMOVE THE CRANKSHAFT GEAR

If a suitable arbor press is not available, the following method may be used:

Due to the extremely tight fit of the crankshaft gear on the crankshaft, it is almost impossible to pull this gear with any of the commercial pullers. Since replacement of this gear would only be brought about by the gear being badly worn or damaged, it may be removed in the following manner: Use a  $\frac{1}{4}$ " diameter drill centered midway between the edge of the keyway and the base of the gear teeth, drill through the gear parallel with the keyway, then spread the gear with a chisel and pull from the shaft. **CAUTION:** Be careful not to drill into the crankshaft.

### TO INSTALL A NEW GEAR

1. Insert the Woodruff key in the shaft.
2. Lay the gear on a sheet of asbestos or other fireproof material and heat the gear with a blowtorch evenly on both sides until the gear turns a pale straw yellow. (If the gear is clean and untarnished, this color will indicate it is heated to approximately 450° F.)
3. Assemble the hot gear on the crankshaft and, with a suitable driver, quickly force the gear into correct position. A piece of 2" diameter pipe may be used as a driver.
4. Allow the gear and shaft to cool.

## CYLINDER AND CRANKCASE

The cylinders are cast integral with the crankcase and have the water jacket carried the full length of the cylinders. This results in more uniform cooling of the pistons and cylinder walls and lower lubricating oil temperatures than is possible with any other type of construction without the use of an oil cooler.

Material is cast iron with forged bearing caps fastened to the crankcase with  $\frac{1}{2}$ " and  $\frac{9}{16}$ " cap screws. The most casual inspection of the cylinder block will disclose the very rigid construction provided to support the crankshaft and this rigidity, coupled with the large diameter of the crankshaft, results in a very rugged and smooth running engine.

Some engines are equipped with dry, removable cylinder sleeves. Those not equipped with cylinder sleeves may be rebored up to .060" oversize.

The cylinder block has a drilled passageway running the length of the block, which is closed on the ends with suitable pipe plugs, known as an oil header. From this header, various passages are drilled to carry oil to the main bearings, camshaft bearings and rocker arms. The passageway for the rocker arms is open at the camshaft thrust flange screw on the rear of the block, and this screw hole (A), Illustration No. 7, must be plugged to prevent oil leakage.

All oil passages should be thoroughly cleaned with a wire brush and solvent at overhaul time.

To replace main bearings, see **"Main Bearings."**

Core openings are closed by expansion type brass or steel plugs. If any of these should leak, remove and replace with new plugs.

## CYLINDER HEAD

The cylinder head is a one piece casting and is detachable. The valve seats are a part of this casting while the valve guides are removable bushings. The head is held to the cylinder block by studs and nuts; and, in order to insure against leaks, the head must be carefully drawn down by means of the stud nuts which should be progressively tightened, working from the center of the head toward the ends, as shown in Illustration No. 16.

A torque wrench is recommended for this operation. See **"Fits and Tolerances"** for recommended tensions.

**NOTE:** The cylinder head nuts must be retightened and the valve tappet clearance reset after 25 to 40 hours of service.




Illustration No. 16

If cylinder head gasket failure is encountered, a thorough check should be made of contributing factors. Detonation, pre-ignition or spark knock (caused by ignition which is too far advanced) will cause a shock load in the combustion chamber which will damage cylinder head gaskets and, if allowed to continue, may destroy the pistons and piston rings. Fuel with an octane rating too low may also contribute to detonation and corrosion of the gasket to the point where it will start leaking. Cooling solutions which are contaminated by corrosive combustion gases leaking into the cooling system are very detrimental to the internal parts of the entire cooling system.

#### TO REMOVE THE CYLINDER HEAD

1. Drain the radiator and remove the water thermostat housing and hoses. Also, disconnect the water temperature gauge thermocouple from the cylinder head.
2. Disconnect the exhaust pipe from the manifold.
3. Remove the intake manifold and carburetor from the cylinder head.
4. Remove the spark plug cables and spark plugs.
5. Remove the cylinder head cover, shield head cover, rocker arm assemblies and push rods.
6. Remove the cylinder head attaching nuts and lift the cylinder head from the engine. Tap the head lightly with a soft hammer, if necessary, to loosen it. Do not pry on the contact surfaces.

#### TO REPLACE THE CYLINDER HEAD

1. Before installing the cylinder head, clean out the carbon deposits by scraping or brushing. If the valves are to be ground or otherwise serviced. See "Valves," Page 47.
2. Clean the cylinder block and cylinder head contact surfaces.
3. Install a clean, new cylinder head gasket on the cylinder block. The gasket must be assembled with the bead (rolled edge around the combustion chamber) down. No shellac or gasket cement is necessary.
4. Place the cylinder head and valve assembly on the block.
5. Start the head nuts and tighten evenly using a torque wrench. Start at the center of the head and work progressively to the outer ends, Illustration No. 16. See "Fits and Tolerances," Page 66.
6. Install the push rods and rocker arms.
7. Adjust the valve tappets to the proper clearance. See "Valves."
8. Install the cylinder head cover, using a new gasket, if required.

#### FAN ASSEMBLY (Cooling)

The cooling fan is mounted on the water pump driven pulley, which is driven from a drive pulley mounted on the crankshaft by the use of one or more "vee" belts. Various accessories may be mounted on the engine and driven by these belts. Therefore, it is not possible to list the fan belt specifications.

## FLYWHEEL

The various flywheels used on this series of engines are usually made of cast iron and may be machined to accommodate different types and sizes of clutches, as well as generators and other types of couplings. The flywheel is fastened to the crankshaft with six bolts. One of these bolts is off center so that the flywheel can only be installed in one position. This properly locates the flywheel on the crankshaft for timing purposes. The timing mark, which indicates that No. 1 piston is on top center, may be seen (depending on the type of the bellhousing) through either a drilled hole provided in the bellhousing, Illustration No. 17, or as shown in Illustration No. 18. Some flywheels have a mark 2° before top dead center which is used to indicate ignition point opening when using a timing light, with the engine idling at 400 RPM.




Illustration No. 17

### TO REMOVE THE FLYWHEEL

1. Disconnect and remove the power take-off or transmission and clutch, whichever is used.
2. Remove the flywheel bolt lock wires and remove the flywheel bolts.
3. Using a Lady-Foot pry bar, pull the flywheel from the crankshaft.




Illustration No. 18

### TO INSTALL THE FLYWHEEL

1. Turn the crankshaft so that No. 1 cylinder is in top dead center position.
2. Turn the flywheel so that the timing mark is in line with the timing hole in the bellhousing. Then, install the flywheel on the crankshaft and draw in place with the flywheel attaching bolts. Do not draw any one bolt tight until all are progressively tightened.
3. Attach the indicator, as shown in Illustration No. 19, to check the concentricity of the pilot bore. This should not exceed .005" total reading.
4. Attach the indicator, as shown in Illustration No. 20, to check the face of the flywheel. This should not exceed .008" total reading.
5. Install the lock wires.
6. Install the starting motor.
7. Install the clutch and transmission or power take-off, as removed.

## FUEL PUMP

There are many different types of fuel pumps used on this series of engines, most of which mount on a suitable pad provided on the cylinder block.

Fuel pumps commonly used are of the diaphragm type, operated by a rocker arm actuated from an eccentric on the camshaft, similar to the pump shown in Illustration No. 21.




Illustration No. 19




Illustration No. 20

In a great majority of cases, trouble attributed to the fuel pump is generally caused by failure in some other part of the fuel system; therefore, be sure that the trouble is actually in the fuel pump before removing it for inspection or repair. For instance, if the engine is not getting enough gasoline, check the level of the fuel in the fuel tank and check for broken, leaking or clogged fuel supply lines. Then, before removing the fuel pump from the engine, check for a leaking bowl gasket, loose diaphragm or top cover screws, or bad valves and springs. See Illustration No. 21.

If the engine is getting too much fuel, this is usually caused by a defective choke arrangement, punctured carburetor float, defective carburetor needle valve or improper carburetor adjustment; this is generally not caused by the fuel pump.

#### TO REMOVE THE FUEL PUMP

1. Disconnect the fuel line from the tank and the fuel line to the carburetor and move out of the way.
2. Remove the two attaching screws which hold the pump to the crankcase and remove the pump from the crankcase, remembering that the rocker arm will catch on the case unless it is carefully pulled out of the small opening.

**NOTE:**—If the fuel pump is forced away from the crankcase by the spring tension on the rocker arm, this will indicate that the high point of the eccentric is toward the pump; and, in order to facilitate installation of the pump, the engine should be cranked over one full turn to place this high spot away from the fuel pump, opposite to that shown in Illustration No. 21.

#### TO TEST THE FUEL PUMP

Before installing the fuel pump, it is always desirable to test it. This can be accomplished as follows:

1. Hook the fuel supply line from the tank to the pump inlet connection.
2. Holding the pump in hand, work the rocker arm, using long, even strokes. After quite a few strokes, the bowl will fill with fuel; and, after it is filled, a few more strokes will force it through the pump and out the outlet side.
3. With strokes approximately  $\frac{1}{4}$ " to  $\frac{1}{2}$ " at the tip of the rocker arm, the pump should be able to deliver quite a bit of fuel. If it does not, with these short strokes, this would indicate that the pump requires servicing and should be taken to an authorized Service Station.




Illustration No. 21

## TO INSTALL THE FUEL PUMP

1. Place a new gasket on the fuel pump.
2. Insert the rocker arm in the hole in the crankcase, being careful to keep the flange of the fuel pump in correct position while the two cap screws are started (some installations use studs and nuts).
3. A slight pressure will be exerted by the rocker arm springs while the screws are being pulled tight. However, if this pressure is excessive, remove the pump and turn the engine over one turn and endeavor to install the pump as outlined above. This light pressure can be noted, but it should not be excessively strong as to bend the rocker arm or prevent installation.
4. Connect the fuel lines.

## GEAR COVER and HOUSING (External Governor)

The gear cover consists of the cover and a gear housing. The gear housing usually forms the front support for the engine and is doweled to the cylinder block. The cover plate covers the gear housing and timing gears, and on it the governor is mounted. The front oil seal for the crankshaft is installed in the cover plate. This cover plate can be removed for inspection of the timing gears, and so forth, without removing the gear housing, Illustration Nos. 22 and 23.

If necessary to remove this gear housing, remove the camshaft as outlined under "Camshaft," remove the oil pan and remove the housing attaching screws and pull the housing forward away from the cylinder block. It may be necessary to tap the housing with a soft hammer to loosen it from the dowels or gasket cement.

**NOTE:**—Internal bolts fasten this housing to the oil pan adapter. The oil pan must be removed to gain access to these bolts for their removal.

## TO REMOVE THE GEAR COVER

Assuming that the radiator has been removed, the gear cover may be removed as follows:

1. Remove the fan blade and belt for easier access to the gear cover and gears.
2. Remove the crank grab nut and fan drive pulley.
3. Remove the governor, linkage and spring, if used.
4. Remove the screws from the gear cover and pull the gear cover forward away from the engine.
5. The oil seal may be pressed from the gear cover, if replacement is necessary.

## TO REASSEMBLE THE GEAR COVER

1. Press a new crankshaft oil seal in the gear cover and cement a new gasket in place, allowing sufficient time for it to dry so the gasket will not skid.
2. Install the gear cover on the engine and secure with screws and nuts as removed.
3. Install the fan drive pulley and crank grab nut on the crankshaft.
4. Install the governor, control rod and connect the operating spring, if used.
5. Install the fan blade and fan belt, using the screws and lock washers as removed. The fan belt should be tightened so that there is approximately 1" deflection when grasped midway between the fan and drive pulleys.
6. Install the radiator, together with any other disassembled parts, and fill the cooling system with the proper solution (water or anti-freeze).
7. Adjust the governor linkage, see "Governor."

## GENERATOR

A periodic inspection should be made of the charging circuit. The intervals between these checks will vary, depending upon the type of service. Dirt, dust and high speed operation are factors which will contribute to increased wear of the bearings, brushes, etc. Under normal conditions, an inspection of the generator or alternator should be made every 100 hours.

1. **Wiring**—A visual inspection should be made of all wiring to insure that there are no broken wires and that all connections are clean and tight. Special attention should be paid to the ground connections at the battery and generator or alternator.
2. **Commutator**—(Generator) If the commutator is dirty or discolored, it can be cleaned by holding a piece of 00 sandpaper against it while turning the armature slowly. Blow the sand out of the generator after cleaning the commutator. If the commutator is rough or worn, the generator should be removed from the engine, the armature removed and the commutator turned down.

**Alternator**—No maintenance required except at overhaul period.

3. **Brushes**—The brushes should slide freely in their holders. If the brushes are oil soaked or if they are worn to less than one-half their original length, they should be replaced.

**Alternator**—Usually no brush replacement except at overhaul period.

4. **Lubrication**—Add 3 to 5 drops of medium engine oil to the oilers in the end heads every 100 hours of operation.

**Alternator**—Permanent type lubrication — None required between overhaul periods.

If the generator does not function properly after the above checks, the generator and the regulator or circuit breaker should be taken to an authorized service station for inspection and repairs.

## GOVERNOR

Two types of governors are used.

### 1. VELOCITY TYPE

This type of governor is sandwiched between the carburetor and the intake manifold and is controlled by the velocity of the air passing through the carburetor into the engine.

This governor is used primarily in mobile units to prevent engine speeds in excess of those considered safe by the equipment manufacturer.

It has only one adjustment which increases or decreases the maximum engine speed.

**WARNING:**—Never increase the maximum engine speed above that specified by the equipment manufacturer without specific approval. To do so will invite possible equipment destruction or bodily harm.




Illustration No. 22




Illustration No. 23

## 2. MECHANICAL TYPE — Externally Mounted

This type of governor is mounted externally on the engine gear cover, Illustration No. 22, and is gear driven by a gear which meshes with the camshaft gear, Illustration No. 23. **NOTE:** Illustrations No. 22 and No. 23 show the governor mounted on an engine having the camshaft on the right-hand side, standing at flywheel end of engine.

This governor operates on the principle of centrifugal weights or “flyballs.” In operation, the centrifugal force developed by the revolving weights is opposed by a spring called the speed operating spring. The weights are attached to the weightshaft and rotate with it. As the weights revolve centrifugal force tends to throw them outward, moving the weight noses longitudinally along the shaft.

This longitudinal movement of force is transmitted, by a sliding sleeve and thrust bearing arrangement, to a fulcrum yoke fastened to the operating shaft and through the shaft to a lever and spring arrangement. The spring tension tends to balance or oppose the force exerted by the flyweights and the lever is connected, by suitable linkage, to the carburetor throttle valve.

Thus, as long as the spring tension (force) exactly balances the force exerted by the rotating flyweights, the throttle position will be held stationary at a position which will admit the proper amount of fuel to produce the power required; therefore, the engine will run at a constant speed as long as the power requirement from the engine remains constant, but should the power requirement from the engine change, the engine speed will change unless a corresponding change is made in the throttle position.

If the power requirement from the engine is reduced, the engine speed will increase, which, in turn, will cause the governor to rotate faster and create added force. This added force exceeds the spring force and moves the throttle closed, slowing the engine and reducing the governor weight force until it is again equalled or balanced by the spring force, with the throttle at a point which will admit the proper amount of fuel for the new load requirement.

Conversely, if the power requirement from the engine is increased, the engine speed will decrease, thereby slowing the governor and decreasing its force. The spring force will then exceed the weight force and open the throttle to admit more fuel to produce power and increase the engine speed until the spring force is again balanced by the weight at the new power requirement and throttle position.

Most mechanical type governors used on Gasoline engines are equipped with governor control linkage which features optional “constant” or “variable” speed governor control, depending on the application on which the engine is to be used and the governor adjustment procedure.

To clarify the governor adjusting procedure, the governor application is divided into two types as outlined below.






Illustration No. 24

The "constant speed" type is used where it is necessary to operate equipment at one pre-determined governor controlled speed, regardless of power required (within the limits of the engine) to drive the equipment at the desired speed.

**NOTE:**—If the governor is to be used as a "constant speed" control, a loose lever arrangement, K, Illustration No. 24, and manual control mechanism should be utilized to over-ride the governor and return the engine to idle speed prior to stopping the engine. Lever B is hinged at the bolt shown, but is held straight by a spring, L. This arrangement permits manual over-ride of the governor with minor effort, but returns to full governor control of the engine when the manual control is moved to wide open throttle position.

The "variable speed" type is used where it is necessary to change equipment speed and retain full governor control of the engine speed (within the limits of the engine and governor) at the modified speed and power requirement.




Illustration No. 25

## GENERAL DESCRIPTION AND MAINTENANCE

**NOTE:**—If the governor is to be used as a “variable speed” control, the throttle control is connected to the bell crank at M, Illustration No. 25. The control must have sufficient stroke to move this lever through  $2\frac{5}{8}$ ” of travel and have a position locking feature capable of withstanding 50 pounds of force developed by the governor.

To adjust governor for constant speed, Illustration No. 24.

1. With engine stopped and tension of spring A holding lever B in full throttle position, as shown.
2. Adjust length of rod assembly C to obtain  $\frac{1}{32}$  -  $\frac{1}{16}$ ” clearance between throttle stop pin and lever D.
3. Adjust spring eye bolt E to obtain approximately  $\frac{1}{2}$ ” of thread above top nut.
4. Back adjusting screws G and F out several turns.
5. Start engine, attach speed indicating tachometer, and open throttle while noting engine speed.
6. Turn screw G in (clockwise) to increase engine speed, out (counter-clockwise) to decrease the engine speed.

**WARNING:**—Do not set the maximum engine speed above that specified by the equipment manufacturer. To do so will invite possible equipment destruction or bodily harm.

7. After correct speed is obtained, turn screw F in tight and lock both screws with the lock nuts.

**NOTE:**—If correct speed cannot be obtained by adjusting screw G, readjust eye bolt E up to increase speed — down to decrease speed.

8. Spring eye bolt, H, is utilized to adjust the sensitivity of the governor. Lengthening the distance, I, from center of shaft to center of spring eye will decrease the sensitivity of the governor action, but will increase over-run (difference between full-load and no-load engine speed).

Shortening the distance, I, will increase sensitivity of the governor, but if shortened too much it will tend to cause surging or hunting. Therefore, the desired adjustment of this screw is to obtain minimum over-run without inducing a surging condition.

9. Adjusting screw J is used to dampen high-speed surging. Turn this screw in slowly until the surge is just dampened. Then recheck the throttle closed or idle position. If the governor will not allow the throttle to close, back this screw out and readjust sensitivity adjustment as outlined in paragraph 8.

To adjust governor for variable speed, Illustration No. 25.

1. See paragraph 1 above, Illustration No. 24
2. See paragraph 2 above, Illustration No. 24.
3. Back adjusting screws F and G out flush with bracket. Lock screw G in this position.
4. Move throttle linkage to the “Throttle Closed” position. Adjust spring eye bolt E to remove **ALL** tension on spring A, Illustration No. 25.
5. See paragraph 5 above, Illustration No. 24.
6. Turn screw F in stop lever movement and limit engine speed to recommended limit. Tighten lock nut, Illustration No. 25.
7. Return throttle control to “Idle” position and adjust carburetor speed control screw to obtain correct idle speed, Illustration No. 25.
8. See paragraph 8 above, Illustration No. 24.
9. See paragraph 9 above, Illustration No. 24.




Illustration No. 26

### TO REMOVE GOVERNOR

If necessary to inspect or repair governor, it can readily be removed for this purpose. Disconnect governor control rod. Then remove the two cap screws and lift governor cover assembly away from engine. Pull governor shaft and weight assembly forward out of engine, Illustration No. 22 and No. 26.

**NOTE:**—It is not necessary to remove the gear cover to remove the governor gear and weight assembly.

**CAUTION:**—There is a thrust washer between the governor gear and the gear housing. Use care that this washer does not fall into the oil pan when removing the governor gear and weight assembly.

With the governor disassembled to this extent, all of the working parts can be inspected and tested to see that all working parts are free and not binding. If no repairs are necessary, the governor should be washed in kerosene and then oiled before the parts are put back together.

**CAUTION:**—Two combinations of timing gears are used.

For Distributor Ignition		For Magneto Ignition	
Crankshaft Gear .....	25 Teeth	Crankshaft Gear .....	24 Teeth
Camshaft Gear .....	50 Teeth	Camshaft Gear .....	48 Teeth
Governor Drive Gear .....	17 Teeth	Governor Drive Gear .....	16 Teeth

### IGNITION TIMING (Battery)

The distributor is driven from the oil pump gear through a tongue and groove type coupling. The tongue and groove of the coupling parts are slightly off center to prevent incorrect installation of the distributor, as can be seen in Illustration No. 27. The tongue and groove are offset away from the camshaft when the engine is properly spotted at No. 1 cylinder firing position, Illustration No. 28, and the distributor rotor is spotted at the No. 1 tower of the distributor cap, Illustration No. 29.

Should it be necessary to install a new coupling or distributor, it is necessary to turn the rotor to No. 1 cylinder firing position, with the primary terminal away from the engine. Then install the coupling at right angles to the terminal, with the offset to the terminal side of the distributor, and space the coupling so that there is approximately .005" to .008" end clearance. Drill the shaft and install the coupling pin. Pein the pin to insure tightness.




Illustration No. 27




Illustration No. 28

**NOTE:**—Instructions for ignition timing will differ slightly with different makes of electrical equipment, and the following is in the nature of general instructions suitable for any type of battery ignition. If the distributor has been removed or for any reason it becomes necessary to check or reset the ignition timing, proceed as follows, and refer to timing chart, Illustration chart, Illustration No. 28A.

### SPOTTING THE FLYWHEEL

The first step in setting or checking the ignition timing is to locate the "DC" mark on the flywheel and line it up with the mark on the bellhousing, see "Flywheel." To determine whether the engine is in

## GENERAL DESCRIPTION AND MAINTENANCE

firing position for No. 1 cylinder, the engine can be cranked with the spark plugs removed to determine the compression stroke of No. 1 cylinder or the cylinder head cover can be removed and the position of the valves noted. If both rocker arms for No. 1 cylinder are clear, indicating that the valves are closed, and the exhaust valve on No. 4 cylinder (or No. 6 cylinder on a six cylinder engine) is not completely closed, this will indicate approximate firing position for No. 1 cylinder.

Turn the distributor rotor so that it is at approximately the No. 1 cylinder firing position on the cap and insert the distributor into the block and coupling. Illustration No. 29.




Illustration No. 29

With the ignition points clean and making a square contact and set to the gap opening shown in the timing chart, Illustration No. 28A, and with the engine at rest, the points should just start to open  $3/16''$  before the top dead center mark on the flywheel. With the engine idling at the RPM shown in the chart, the distributor should be set at the specified degrees shown in the timing column of the chart. The automatic or manual advance, or combination of the two, whichever is employed, will then advance the spark to the proper position when the engine is running.

There are several methods of checking accurately the exact point of contact opening. One method is by using a test light which, if connected in series with the primary circuit (when the ignition switch is on), will be lighted when the ignition contacts are closed and not lighted when the contacts are open. To change the ignition timing, loosen the clamp screw holding the spark control arm to the distributor and turn the distributor until the correct timing is obtained; then, tighten the clamp screw. If the distributor is being retimed after having been removed, it is now necessary to see if the rotor lines up with the distributor cap segment connected to No. 1 cylinder and that the remaining ones are connected in the order 1 - 2 - 4 - 3 for a four cylinder engine and 1 - 5 - 3 - 6 - 2 - 4 for a six cylinder engine.

TIMING CHART G-3400 & G-3000								
FUEL	COMP. RATIO	HERCULES DISTRIBUTOR PART NUMBER	PURVEYOR DISTRIBUTOR PART NUMBER	TIMING	R.P.M.	SPARK PLUG GAP	NOMINAL POINT GAP	DWELL ANGLE
Gasoline	7.5	250466	DELCO 1112616	0° T.D.C.	500	.028 - .033	.022	31° - 37°
L.P.G.	7.5	250466	DELCO 1112616	0° T.D.C.	500	.028 - .033	.022	31° - 37°
L.P.G.	10	250466 250471	DELCO 1112616-17**	*12° A.T.D.C. ** 0° T.D.C.	450	.028 - .033	.022	31° - 37°
Nat. Gas	7.5	250466	DELCO 1112616	6° B.T.D.C.	500	.028 - .033	.022	31° - 37°
Nat. Gas	10	250466	DELCO 1112616	0° T.D.C.	500	.028 - .033	.022	31° - 37°
Gasoline	7.5	250909	DELCO X-24066	6° B.T.D.C.	500	.028 - .033	.022	31° - 37°
Gasoline	7.5	250910	PRESTOLITE EO-17535	6° B.T.D.C.	500	.028 - .033	.020	42° - 36°
G-2300 & G-2000								
Gasoline	7.5	250468	DELCO 1112625	0° T.D.C.	600	.028 - .033	.021	25° - 34°
L.P.G.	7.5							
L.P.G.	10							
Nat. Gas	7.5							
Nat. Gas	10							
Gasoline	7.5	251028	DELCO 1112475	0° T.D.C.	600	.028 - .033	.022	31° - 37°
Gasoline	7.5	251017	PRESTOLITE EO-17593	2° B.T.D.C.	450	.028 - .033	.020	39° - 45°

Illustration No. 28A

## MAIN BEARINGS

The use of seven main bearings in the six cylinder engine, five main bearings in the four cylinder engine permits a main bearing to be placed on each side of each connecting rod bearings, see Illustration No. 1. This construction helps to eliminate vibration at high speeds. The center main bearing cap is held in position by four alloy steel cap screws  $\frac{1}{2}$ " in diameter while the remaining ones are held in position by two alloy steel cap screws  $\frac{9}{16}$ " in diameter.

The main bearings are removable, precision shell type and the upper shell is not interchangeable with the lower shell for each bearing. No shims are used. Reconditioning of this type bearing is accomplished by replacing the shells. These precision type shells are completely finished before being put in place and no line reaming or scraping is required. This allows renewal of bearings to be easily accomplished. The shells each have a small ear or projection which fits into a recess, which allows the ear to rest against the adjoining case or cap to prevent the shell from rocking or rotating. The bearing metals commonly used in precision, shell type bearings are harder and have a higher melting point than ordinary babbitt metal, and this requires the use of a hardened crankshaft.

### FITTING OF BEARINGS

The bearings in these engines are readily accessible after the oil pan and oil pump are removed. The bearings should never be fitted so tight that they bind or drag, see "**Fits and Tolerances.**" A certain minimum clearance is required at all times to provide an adequate oil film between the shaft and bearing and insure a free running engine. The bearings in these engines are of ample proportion and the full pressure lubrication system employed will give long lasting bearings, provided they are properly installed.

Tightening of the main bearing screws requires some care to prevent too much strain on the parts. For this reason a torque wrench is necessary when installing the bearing caps. The wrench tension value given under "**Fits and Tolerances**" show the correct amount of pull to use on various screws. No attempt should be made to refit these bearings by filing or grinding the caps, as this will ruin the caps so new shells cannot be installed.

### REPLACEMENT OF THE MAIN BEARINGS

It is not necessary to remove the engine from the unit to replace the main bearings unless, of course, the crankshaft is damaged or worn to the extent that it must be replaced.

The following outline may be used as a guide for replacing the bearings when the engine has not been removed from the unit.

1. Disconnect the battery cable at the battery, as a safety measure.
2. If the starter is mounted below the oil pan level and causes interference, disconnect the starter cable and wiring; then remove the starter.
3. Drain the crankcase oil.
4. Remove the oil pan. Remove the tachometer drive, if used.
5. Remove the oil pump.
6. Remove the oil pan adapters.
7. Loosen all main bearing cap screws.
8. Remove one bearing cap at a time and make bearing replacement. To remove the upper shell, a small pin may be inserted in the crankshaft oil hole and the shaft rotated so that the pin will push the bearing out. The new bearing may be inserted in the same manner, see Illustration No. 30.

**CAUTION:**—Be sure to remove the pin before assembling the bearing cap.

9. Assemble the bearing cap and lower shell and tighten the screws. See "**Fits and Tolerances,**" Page 66.
10. After installing new thrust bearings on the center main bearing, check the end thrust Illustration Nos. 31 and 32. See "**Fits and Tolerances.**" It is permissible to draw file the thrust bearings to obtain the proper clearance, if necessary.




Illustration No. 30

11. Install the oil pump.
12. Install the oil pan adapters.
13. Thoroughly recheck the inside of the engine for loose nuts, etc.
14. Install the oil pan, replacing gasket, if required.
15. Install the starter.
16. Connect the starter cables.
17. Connect the battery cable.
18. Fill the crankcase to the FULL mark on the bayonet gauge, see Illustration No. 6, with the proper grade of oil.
19. Start the engine and immediately check the oil pressure. See "Oil Pressure." If sufficient, allow the engine to run for a few minutes while checking for oil leaks, etc.; then, stop the engine and recheck the oil level. Add oil, if necessary.

## MANIFOLDS (Intake and Exhaust)

There are various types of manifolds used on this series of engines; therefore, it is not practical to discuss them at length in this book. Manifolds differ as to the size of carburetor attaching flanges and position. Different exhaust outlets are used on different installations. Different manifolds are also manufactured for use with different types of fuel. From this list of differences, one can readily see the importance of replacing the manifold on the engine with the original type manifold unless the engine is to be applied to a different type of operation.

When installing the manifolds, it is essential to use new gaskets. When tightening the manifold stud nuts, a washer should be used under the nut and the manifold tightened progressively from the center to the end, repeating the operation at least three or four times to make sure that the manifold is tight.

In many instances, a companion flange and gasket are used for the installation of the exhaust pipe. Be sure these are drawn up tight and square with the manifold flange to avoid leaks.




Illustration No. 31




Illustration No. 32

#### TO REMOVE THE INTAKE MANIFOLD

1. Disconnect the fuel lines.
2. Disconnect the carburetor controls. Carefully note how the controls are assembled so they can be re-placed in the correct position.
3. Remove the air cleaner or air cleaner connections.
4. Remove the carburetor and crankcase ventilation tube assembly, if used.
5. Remove the manifold attaching nuts and washers and remove the manifold.

#### TO INSTALL THE INTAKE MANIFOLD

1. Make sure all gasket surfaces are clean, place the manifold gaskets on the attaching studs and assemble the manifold to the engine with the nuts and washers as removed.
2. Tighten the manifold into place. Tighten all nuts lightly; then, starting from the center, work progressively toward the ends of the manifold, repeating until all nuts are tight. See Page 66.
3. Connect the crankcase ventilation tube assembly, if used.
4. Install the carburetor, using a new gasket.
5. Install the air cleaner or connect the air inlet tube.
6. Connect the carburetor controls. Make sure these controls are correctly assembled.
7. Connect the fuel lines.
8. After the engine has been operated a day or more, tighten all manifold and carburetor attaching nuts.

#### TO REMOVE THE EXHAUST MANIFOLD

1. Disconnect the exhaust pipe from the manifold.
2. Remove the manifold attaching nuts and washers and remove the manifold.

#### TO INSTALL THE EXHAUST MANIFOLD

1. Make sure all gasket surfaces are clean, place the gaskets on the attaching studs and assemble the manifold to the engine with the washers and nuts removed.
2. Tighten all nuts lightly; then, starting from the center, work progressively toward the ends of the manifold, repeating until all nuts are tight.
3. Connect the exhaust pipe to the manifold.

### OIL FILTER

The lubrication system is designed for the installation of a full-flow spin-on type oil filter. Engines that do not have a factory installed full-flow filter are equipped with a jumper line to connect the oil outlet from the oil pump to the oil header inlet. (See Illustration No. 33).

To install a full-flow oil filter on the engine, the jumper line must be removed and the installation made as shown in Illustration No. 33. All oil lines must have an I.D. of not less than  $\frac{3}{8}$ ".

**NOTE**—Some earlier model engines were equipped with a by-pass type filter and should this type of filter be desired, installation drawings are available through Hercules' Engineering Department.

All oil filters should receive regular and careful attention. A definite schedule for replacement of the filter can be determined from the observation of the lubricating oil on the application in which the engine is used. (See Lubrication Instructions, page 14).

When a new filter is installed, add sufficient oil to the crankcase so the oil level will be correct after the engine has run long enough to refill the filter.

### OIL PAN

The oil pan serves as a cover for the bottom of the crankcase and, also, as an oil reservoir.

Suitable drain plugs are located in the bottom of the oil pan. The bayonet type oil gauge, used to measure the oil level in the pan, is covered under "Bayonet Gauge," Page 18.

#### TO REMOVE THE OIL PAN

1. Drain the crankcase oil.

## GENERAL DESCRIPTION AND MAINTENANCE




Illustration No. 33

2. Disconnect the starter cable and remove the starter, if mounted below the center line. Disconnect battery terminal for safety.
3. Remove the bayonet gauge assembly.
4. Remove the cap screws from the oil pan and lift the oil pan away from the engine.

### TO INSTALL THE OIL PAN

1. Clean the oil pan thoroughly; also, remove the old gaskets from the oil pan and cylinder block.
2. Inspect the inside of the engine for loose nuts, screws, cotter pins, lock wires, etc; tighten or replace.
3. Remove the front and rear oil pan adapters and clean the gasket surfaces.
4. Cement new oil pan side gaskets to the cylinder block.
5. Install the front and rear oil pan adapters.

**NOTE:**—If new bellhousing or gear housing gaskets have been used, it is necessary to cement the oil pan gaskets in place and install the adapters before tightening the bellhousing and timing gear housing attaching screws.

6. Cement the oil pan front and rear seals in the oil pan with Armstrong No. D-200 adhesive, if available. (Hercules part No. 255215-A) so that each end of the seal extends the same distance above the oil pan attaching flange. (**NOTE:** This adhesive sets quickly and seals should be inserted at once.) **Do not** cut off the ends of the seals.
7. Apply some lubricating oil to the oil pan adapter gasket surfaces, put the oil pan in place and carefully start all screws. Be sure the lock washers are on the screws.
8. Draw up all screws evenly and progressively. This will allow the oil pan to center on the adapter blocks.
9. Install the drain plug.
10. Install the starter motor and connect the cables.
11. Refill with oil to the correct level.
12. Reinstall the bayonet gauge assembly.



## OIL PRESSURE REGULATORS

These engines are generally equipped with two oil pressure regulators. An 80# regulator is attached to the pump and a 40# regulator is set in the block. If either of these regulators is removed to be cleaned or replaced care must be taken to see that when they are re-tightened the pressure relief holes are set in such a way that the oil stream from them will not spray up into a cylinder bore or toward the front or rear oil seals. On some engines a 40# regulator is used alone, and it is mounted on the oil pump.

Since these regulators have two holes that will discharge a substantial stream of oil under certain operating conditions, care must be taken to align them with the engine in the following manner:

The regulator on the oil pump should be turned with drilled passage in the horizontal position so that the oil will spray toward the center of the engine and against the oil pan surface. If oil pressure regulator tightens in the oil pump in undesirable location a shim should be added and the regulator retightened. (Shim part number 205354).

The regulator on the block must be turned with the drilled passage in line with the main bearing cap so that the oil will spray towards the main bearing cap and against the side of the pan. It is important that they not spray up into a cylinder bore, or against the front or rear oil seals.

**NOTE**—Due to modifications in the machining and drilling of the cylinder block for production engines, only one oil pressure regulator is required. This is a 65-lb. regulator mounted on the oil pump. Older blocks can be serviced with the new or old oil pump assemblies in conjunction with the 40-lb. regulator in the cylinder block.

## OIL PUMP

The oil pump is attached to the cylinder block with suitable screws and is driven by a gear solid with the camshaft and located near the center of the camshaft. The lower end of the oil pump extends down into the oil pan, and the oil is drawn into the pump through a large screen, which prevents coarse dirt from being drawn into the system. The oil pump extends into the oil, and therefore needs no priming. After the oil pan is removed, the oil pump is readily removed for inspection or repairs. The various parts of the oil pump are shown in Illustration No. 35.

**NOTE**—Late model four and six cylinder production engines will use the same oil pump with suitable gear for RH or LH camshaft application.




Illustration No. 35

### TO REMOVE THE OIL PUMP

1. Remove the oil pan. See "Oil Pan," Page 39.
2. Turn the 4 & 6 cylinder engine with L H camshaft so that No. 1 piston is in firing position. Turn 4 cylinder R H camshaft so that No. 4 cylinder is at T.D.C. Turn 6 cylinder R H camshaft so that No. 6 cylinder is at T.D.C. This may be noted from the position of the distributor rotor or from the position of the cams on the camshaft.

**NOTE:**—If the engine is equipped with a tachometer drive, this must be removed before attempting to remove the oil pump.

3. Remove the screws from the oil pump attaching flange and pull the oil pump from the engine.

**NOTE:**—When the engine is equipped with a counterbalanced crankshaft, it is necessary to rotate the crankshaft and, at the same time, remove the oil pump with a spiral motion.

### TO DISASSEMBLE THE OIL PUMP

(Letters refer to Illustration No. 35 unless otherwise noted)

1. Remove the drive gear by pulling the gear (I) from the shaft.

**NOTE:**—Puller must be under the gear and not under the distributor drive coupling flange.

2. Remove the screws (A) and washers (B) from the pump gear cover (C) and remove the cover.
3. Remove the gear (D) and shaft (F). The gear (D) may be pressed from its respective shaft, if necessary. Gear (H) is a running fit on shaft (E). Shaft (E) in latest style pump is pressed into pump housing (G).

### TO REASSEMBLE THE OIL PUMP

1. Press the gear (D) on to shaft (F).
2. Assemble the shaft (F) in the pump body; and press the gear (I) on to the shaft. This gear should be pressed on to the shaft to the dimensions shown in Illustration No. 35.
3. Install the idler gear shaft (E) and gear (H).

**NOTE:**—Later pumps have shaft (E) pressed into housing (G) with gear (H) running free on shaft (E).

4. Install the cover (C) with the screws (A) and lock washers (B) as removed.
5. Turn the pump shaft to insure freeness of rotation. If the shaft binds or is otherwise tight, disassemble and ascertain the reason. Correct and reassemble the pump.

### TO INSTALL THE OIL PUMP

1. If the engine has been moved or rotated since removal of the oil pump, it is necessary to spot the engine with No. 1 cylinder in firing position. See Paragraph "To Remove The Oil Pump," Item 2. This may be noted from the position of the valves. See "Ignition Timing."
2. Turn the oil pump drive gear so that the flat on the flange, Illustration No. 36, is to the outside of the pump (the side opposite the pressure relief valve).
3. With the flat towards the camshaft, insert the oil pump into the cylinder block and rotate the oil pump to the correct position for assembling the attaching screws.

**NOTE:**—The oil pump should not be rotated until after the drive gear is meshed with the gear of the camshaft.

**NOTE:**—When the engine is equipped with a counterbalanced crankshaft, proceed as outlined above except that, after the oil pump driven gear teeth have just been engaged in the camshaft gear, it is necessary to rotate the crankshaft and, at the same time, complete the insertion of the oil pump with a spiral motion.

4. Install the oil pump attaching screws.

If the distributor was not removed, care must be exercised that when the oil pump is installed the tongue of the distributor drive coupling properly engages in the groove in the oil pump drive gear, with the distributor rotor in firing position for No. 1 cylinder. If the distributor was removed, a visual inspection of the oil pump drive gear groove will show that it is parallel with the engine when the gear is properly timed, with the crankshaft spotted in No. 1 cylinder firing position, Illustration No. 28.

5. Install the oil pan. See "Oil Pan."
6. Fill the crankcase to the proper level with the correct grade of lubricating oil.

## OIL SEAL

The construction of these engines prevents oil leakage when the gaskets are in proper condition and all bolts and screws are properly tightened. Whenever a shaft extends through the engine case and there is a possibility of oil leakage, an oil seal is used which also acts as a dust seal, preventing dust from entering the engine.

At the flywheel end of the crankshaft a patented type oil seal is used, Illustration No. 37. As can be seen in this illustration, the oil seal is mounted in the bellhousing so that it seals against the flange of the crankshaft.

Oil is also prevented from leaking, at the timing gear end, by the use of the same type of seal. This seal is pressed into the gear cover.

This type of seal requires very little attention; however, at assembly the shaft seal surfaces on which the seal rides must be thoroughly and carefully checked for nicks or scratches which may have a tendency to damage the seal. If any nicks or scratches are found, they should be removed with an oil stone or very fine emery cloth and polished with Crocus cloth. If the shafts have a keyway which might damage the seal during installation, this keyway should be covered with a thin feeler gauge to protect the seal.

No special tools are required to install the seals on the shafts, since the shafts are tapered to allow the seals to easily slip into place. However, a certain amount of care is required in order not to damage the seals. A coating of oil soap on the seal surfaces of the shafts and, also, on the seals themselves will be found beneficial during the run-in period.




Illustration No. 36




Illustration No. 37

## PISTON

The piston is made of aluminum alloy, solid type, having no slot or slit in the skirt. The top of the piston is made thick in order to uniformly transfer the heat from the top of the piston to the various rings and to the skirt of the piston where it can be dissipated to the water jacket and lubricating oil sump.

Either three ring or four ring style pistons are used, depending on the requirements. On the four ring piston, the two upper rings are the compression type, the third and fourth (below the piston pin) are of the oil regulating type. See Illustration No. 39. The three ring piston differs from the four ring style in that the skirt is not the same and not designed for the use of a lower oil control ring. See Illustration No. 40.

The pistons should be fitted to the cylinder bores with the proper clearance. See "Fits and Tolerances." If a feeler ribbon is used, this should be a ribbon of  $\frac{1}{2}$ " wide and of the thickness indicated in the Fits and Tolerances. A scale should be used to obtain the pull indicated.

To remove or install the pistons, see "Connecting Rod," Page 21.




Illustration No. 38




Illustration No. 39

### PISTON PIN

The piston pin is a large diameter pin of the full floating type. This means that the pin can rotate in either the piston bosses or in the bushing at the top end of the connecting rod. But, the fit in the piston is intended to be much tighter than the fit in the connecting rod; consequently, the movement in the piston consists of a light creeping action while the normal rotation of the pin occurs in the bushing at the top end of the connecting rod. The piston pin is prevented from moving endwise and making contact with the cylinder wall by means of snap rings which locate in grooves machined in the bosses of the piston. Piston pins should be fit in the piston bosses with the proper clearance as indicated in the "Fits and Tolerances."

### PISTON RINGS

The piston rings when fitted in the cylinder bore of the engine should have a gap clearance between .015" and .020". The piston ring land clearance is indicated in the "Fits and Tolerances," Page 66.




Illustration No. 40

When installing new piston rings, each ring should be tried in the cylinder bore to see if it has the correct gap of .015" to .020". If necessary to increase the gap, the ring should be held and filed as shown in Illustration No. 38. If the ring is held in a vise, the vise jaws must be covered with some soft metal. The ends of the rings are squeezed together and the file cuts on both sides. This will insure the ends being parallel. When inserting the ring in the cylinder bore to test the gap clearance, push the ring part way through the bore, using the bottom of a piston to square the ring in the bore.

Each new ring should be tried for clearance in the piston groove by rolling the ring all the way around the groove, as shown in Illustration No. 39. If the piston grooves have been carefully cleaned, the rings will be found to fit correctly.

When assembling the piston rings to the piston, if ring spreader tool. Illustration No. 40, is not available, the rings can be slipped over thin strips of metal. Whatever method is used, the rings must be handled carefully in order not to distort or break them.

## SPARK PLUGS

Spark plug performance has a very important part in engine operation and economy. Therefore, it is important that the correct type of spark plug be selected for your particular engine operation.

Spark plugs are made in various types and each type has a definite purpose, which depends on the service required of the engine. For instance, one engine may be operated continually at, or near, full load and would require a colder type spark plug while another engine of the same type, which is operated at part load or with long periods of idling, would require a hot type spark plug. See Illustration No. 41.

Illustration No. 41 shows a comparison of spark plug types. The cold plug has a low insulator seat, which quickly carries the heat away from the insulator and keeps the spark plug insulator and points cooler. This results in longer spark plug life when the engine is in operation for long periods at full loads.

The normal plug has a higher insulator seat, which allows the insulator to retain a normal amount of heat. This type of plug should be used when the engine is operated at intermediate and variable loads and speeds.

The hot plug has a very high insulator seat, which permits the core to retain the maximum amount of heat. This type of spark plug should be used when the engine is operated at part load with intermittent periods of idling.

**Spark plug maintenance is very simple and easily accomplished and should not be neglected.**

After removal of the ignition wires, select the correct size socket wrench and loosen each plug approximately two turns. Then, with compressed air or a brush, clean the dirt from around the spark plug. This is important as the dirt may fall into the cylinders and cause damage when the engine is started.

When the dirt has been removed from around the plugs, remove the plugs from the engine and carefully examine the condition of the points and insulator.

A careful study of the following illustrations and text will explain various spark plug conditions, as well as probable causes.

Illustration No. 42 shows the normal condition of a plug that has been carefully selected for a particular type of service. Notice the dry, light to dark brown, flaky deposits of combustion products which when exhibited on each spark plug of a set, indicate a balanced ignition and combustion condition.

Illustration No. 43 shows a burned or overheated spark plug. These are usually identified by dry, shiny, glassy deposits on the insulator, or cracks in the insulator tip, which results from:

1. Too lean an air-fuel mixture.
2. Dirty, clogged radiator or cylinder block and head (or inefficient engine cooling).
3. Broken or slipping fan belt.
4. Too hot a spark plug for the service.
5. Improper installation of the spark plugs
6. Compression leakage through the spark plug.




Illustration No. 41

Illustration No. 44 shows a gas fouled spark plug. This condition is usually identified by a black, dry, fluffy deposit which results from:

1. Heat range of spark plug too cold for particular service.
2. Prolonged periods of engine idling.
3. Excessive use of the choke or improper adjustment of the automatic choke.
4. Too rich an air-fuel mixture.
5. Spark plug gaps set too close.

## DESCRIPTION AND MAINTENANCE




Illustration No. 42




Illustration No. 43



Illustration No. 44

Illustration No. 45 shows an oil fouled plug. This condition is usually identified by the wet, black shiny deposit. This may be caused by:

1. Heat range of spark too cold for particular type of service.
2. Distributor trouble or faulty ignition cables.
3. Weak coil or battery.
4. Spark plug gaps too close.
5. Worn piston rings or pistons.

Illustration No. 46 shows how the spark plug points wear or corrode with service. The amount of wear indicates the extent of service to which the plug has been subjected. When the plugs become worn to this extent, they should be discarded and replaced.

Before reinstalling the spark plugs, they should be cleaned and have the point gap adjusted. Always adjust the points by bending the ground electrode. Never attempt to bend the center electrode as this may chip or crack the insulator and render the plug inoperative.

When installing spark plugs, be sure the spark plug seat is clean and use a new gasket, if available.

The plug is properly tightened when the gasket is compressed to approximately one-half its original thickness when new. If a spark plug is tightened too tight, the body may become distorted and crack the insulator. Spark plugs should be retightened after a few hours' operation.

If the plug is too loose, it may allow exhaust gases to escape around the threads and, at the same time the heat will not be carried away from the plug fast enough to prevent the plug from becoming damaged from excessive heat.



Illustration No. 45



Illustration No. 46

## STARTING MOTOR

The starting motor is designed to crank the engine when the switch closes the circuit between the storage battery and the motor. It consists of five main sub-assemblies: the frame and field, the armature, the commutator end head, the pinion housing and the Bendix drive. The frame and field consists of the frame which supports the components of the starting motor, the pole pieces and the field coils. The coils supply the path for the magnetic field. Illustration No. 47 is an assembly drawing of a typical starting motor.

The armature consists of a soft iron core, a commutator and the windings which are wound in slots in the core and are connected to the commutator. The commutator consists of a number of copper segments insulated from each other and from the armature shaft.




Illustration No. 47

The commutator end head supports a bearing, brush holders and brushes. The pinion housing is a cast iron housing for the Bendix drive and also provides the motor mounting lugs. The Bendix drive is an automatic clutch that engages the starting motor with the engine flywheel when the motor cranks the engine and disengages when the engine starts. It consists of a threaded sleeve fastened to the armature shaft thru a drive spring and a pinion mounted on the threads of the sleeve. When the starting circuit is closed the armature revolves, turning the sleeve within the pinion and forcing the gear forward, meshing it with the flywheel gear. The sudden shock of meshing is absorbed by the spring. When the engine starts the pinion is driven faster than the sleeve and is forced back along the threads, automatically de-meshing it from the flywheel.

## LUBRICATION

Some starters are provided with an oil cup which should be filled with lubricating oil when the unit is lubricated.

Other starters have no provision for oiling; these are lubricated at the time of overhaul.

After the starting motor has been in service for an extended period it should be removed, dismantled and cleaned. Clean the Bendix drive thoroughly and lubricate sparingly with light oil. Inspect the wiring for loose or corroded connections and for broken leads. Make sure the insulation on the wiring has not become frayed.

We recommend that dismantling, cleaning and repair be done only by experienced maintenance personnel or by authorized service depots.

### THERMOSTAT AND BYPASS

The engines are equipped with a thermostat, Illustration No. 48, so designed that it will not allow water from the radiator to circulate through the engine until the water in the engine is at operating temperature but does bypass a certain amount of water from the cylinder block, which is carried through the bypass tube to the inlet side of the water pump, where it is again circulated through the engine. This is repeated until the water in the engine is heated to operating temperature, when the thermostat begins to open and permits the water from the engine to enter the radiator. This water is, at the same time replaced in the engine by the water pump drawing from the bottom of the radiator. Thus, the water temperature is constantly maintained in the proper heat range.




Illustration No. 48

A defective thermostat of this type must be replaced as it cannot be repaired. Thermostats are usually marked with their normal operating temperature and may be tested by the still water test.

The still water test is as follows:

Place approximately 4" of water in a pan or pail. Insert a thermometer of this heat range in the water and set the thermostat in the water with the bellows submerged. Heat the water slowly and carefully observe when the thermostat valve starts to open. Note the water temperature as indicated by the thermometer; continue to heat the water until the thermostat is fully open and again note the water temperature. Then compare these temperatures with those stamped on the thermostat.

Five degrees above or under those given are permissible.

### VALVES

The intake and exhaust valves are made of special steel and operate in valve guides pressed into the cylinder head. They are held on to their seats by strong steel springs, which are fastened to the valves by suitable spring seats and valve lock arrangement. The valves, being located in the cylinder head, are operated by conventional type tappets with hollow push rods running from the tappets to the rocker arms. The rocker arms are lubricated by means of oil forced through a hollow cylinder head stud into the shaft on which they rotate. Oil is forced out, through small holes in the rocker arms, over the valve stems and push rods. The replacement of valves and valve guides will be found under the subject of "Valve Grinding." The replacement of valve tappets will be found under the subject of "Valve Tappets."

Some engines are equipped with a valve rotacap, which controls the motion of the valve during the lift cycle, but the valve is not located in any way which would prevent turning. The natural vibrations of the valve train and the flow of gases around the valve head cause the valve to rotate slowly, a small fraction of a revolution each lift cycle.

The rotacap requires no special attention other than to see that it is thoroughly cleaned when removed for valve overhaul jobs.

In order to continue to get good performance from an engine, it may be necessary to grind or reseal the valves at varying intervals. The frequency for doing this depends on the care in the operation of the engine. If the air cleaners have been properly cared for; if all connections between the air cleaner and carburetor have been kept air tight; if the lubricating oil has been properly maintained; and if the clearance between the valve stem and rocker arm has been properly adjusted, valve grinding will be necessary very infrequently. Their seating should be tested periodically by rocking the engine against compression. When the engine will not rock, compression is leaking through either the valves, cylinder head gasket or past the piston rings. Check the leak by listening for a "hissing" sound, when the engine is cranked by hand, either at the cylinder head gasket or in the crankcase breather. If at the cylinder head gasket, remove the head and replace the gasket. If in the breather, dismantle the engine and install new parts for those found worn or scored. If no "hissing" is heard at either of these two places, remove the cylinder head and valves. Clean both thoroughly, removing all carbon and oil. Inspect the valve seats and valves. See "Valve Grinding."



### TO REMOVE THE VALVES

1. Remove the cylinder head. See "Cylinder Head."
2. With a clamp type valve spring compressor, compress the valve springs and remove the valve seat locks.
3. Remove the valve springs and seats and lift out the valves. Place the valves in a cardboard or wood block, drilled and numbered so that the valves may be reinstalled in their respective places when grinding or reassembling (do not mark the valves with a file or punch).
4. Clean all carbon from the cylinder head, piston heads, valve seats, valve guides and valves with suitable scraping or buffing tools.

### VALVE GUIDES AND SEATS

Inspect the valve guides for excessive wear. If the valve guides are to be renewed, this should be done before any work is done on the valve seats. This will insure the seat being finished square with respect to the new guide. The exhaust valve guides will usually show the most wear. To drive out the guides, use a drift  $\frac{5}{8}$ " in diameter with a  $\frac{3}{8}$ " diameter pilot. Drive in the new guides to the same depth location as the old guides. After the new guides are driven in, they must be reamed to size on the inside diameter to correct any squeezing in or possible distortion due to being driven into place. This is important in order to get a proper fit and the proper clearance. See "Fits and Tolerances," Page 66.

Inspect the valve seats; and, if they are pitted or if new guides have been installed, the seats should be refinished. Valve seat tools with  $\frac{3}{8}$ " diameter pilots are required. The exhaust valve seats are finished on a 45° angle and should have an even width all the way around. The intake valve seats are also finished on a 45° angle. Reseat the seats with a vibrating angle grinder type reseating tool. Because of the large diameter and surface of the valve seats, it is very difficult to obtain a good reseating job with a reamer type tool. Remove all shoulders and pits from the seat but do not grind any deeper than necessary. Then finish the new or refaced valve to the reseated seat by hand in the usual manner.

Inspect the valves carefully; and, if the stems are badly worn or are not straight or if the valves are deeply pitted, the valves should be replaced by new ones. However, valves that are only slightly pitted can be used by refacing them on a valve grinder. Valves must have an accurately finished face of the correct angle. See "Fits and Tolerances" for the seat width.

If the valves and seats are not deeply pitted or shouldered or have been refaced, grind or lap each valve to its seat. Obtain a light coil spring with enough tension to just hold the valve off the seat. Lubricate the valve stem and apply a thin coating of good quality, medium coarse grinding compound on the valve face. Insert the valve in the valve guide and rotate the valve back and forth, about a quarter of a turn, a few times, pressing firmly on the grinding tool. (Avoid continuous round and round motion that would cut grooves in the valves or seat.) Release the pressure on the tool and the spring should lift the valve from its seat. Rotate the valve 15° or 20° and repeat the grinding process. It will probably be necessary to wipe off and inspect the valve and seat during this process to see what progress is being made; also, the compound may wear off the surface being ground. In either case, reapply another thin coating of compound and continue grinding until inspection shows the surfaces are in contact. Then wipe off all heavy compound and apply a thin coating of "fine" compound and continue the grinding. When the surfaces are "finished" and show a bright, silver-like band of uniform width on both the valve and seat, clean off all traces of the compound. Test each valve for a tight fit by making ten or twelve pencil marks, equally spaced, across the valve seat and firmly rotate the valve in the seat for a part of a turn and again lift out the valve and observe if all the pencil marks are rubbed out on the contact surface. If not, regrind until this test shows a gas tight mating of the valve and seat. **NOTE:**— It is imperative that the valves be assembled in the same seats to which they were ground.

### TO ASSEMBLE THE VALVES

1. Thoroughly clean all traces of the grinding compound off the valves, stems and guides; put a few drops of oil on the valve stems and insert the valves.
2. Using a valve spring compressor, compress the valve springs and insert the valve locks.
3. Turn the head on the exhaust manifold side and pour gasoline in the intake openings. If gasoline seeps out around any valve, remove that valve and regrind. Repeat the test, pouring gasoline in the exhaust openings. If any exhaust valves leak, regrind.

## GENERAL DESCRIPTION AND MAINTENANCE




Illustration No. 49




Illustration No. 50




Illustration No. 51

4. Install the cylinder head and valves on the engine. See "Cylinder Head."
5. **Install Rocker Arm Assembly.** It is imperative that the rocker arm and shaft be correctly assembled and installed on the engine. Illustration No. 49 shows the correct position of the oil holes in the three and four-cylinder model rocker arm shaft. Note that the oil hole is downward toward the camshaft side of the engine. Illustration No. 50 shows the correct position of the oil holes in the six-cylinder model rocker arm shaft. Note that there are two oil holes for each rocker arm, both pointing downward. Illustration No. 51 shows the correct position of the rocker arm spacer or mounting blocks. Note that the mounting hole is off center in some blocks. These blocks must be reassembled exactly as shown. Four-cylinder engines have a one-piece rocker arm shaft. Six-cylinder engines have a two-piece shaft. When removing rocker arms from the six-cylinder engines, it is suggested that a wire be used between the No. 1 and No. 12 rocker arms to hold the two shafts together and prevent accidental disassembly of the shaft and rocker arm assemblies.
6. Adjust the valve tappets to the approximate setting. See "Fits and Tolerances." This may be readily and systematically accomplished in the following manner. Perusal of the following paragraphs and Illustration No. 52 will point out that the spotting of the crankshaft and rocker arms follows the firing order (1 - 2 - 4 - 3 for the four cylinder engine and 1 - 5 - 3 - 6 - 2 - 4 for the six cylinder engine) of the engine (starting from the timing gear end). The valve tappet screws are self-locking and, therefore, no lock nut is used.
  - a. Crank the engine over until the intake valve of No. 1 cylinder just starts to open. Then adjust the tappets on No. 4 cylinder (No. 6 cylinder in a six cylinder engine).
  - b. Crank the engine over until the exhaust valve of No. 2 cylinder just closes and the intake valve of No. 2 cylinder just starts to open. Adjust the tappets on No. 3 cylinder.
  - c. Crank the engine over until the valves of No. 4 cylinder are in the position noted above and adjust the tappets on No. 1 cylinder.




Illustration No. 52

- d. Crank the engine over until the valves on No. 3 cylinder are in the position noted above and adjust the tappets on No. 2 cylinder.

The same outline is applicable to the six cylinder engine except that the six cylinder firing order must be followed; i.e., from a. above, crank the engine over until the exhaust valve of No. 5 cylinder just closes and the intake valve of No. 5 cylinder just starts to open. Adjust the tappets on No 2 cylinder. Complete the adjustment, following the six cylinder engine firing order, as follows: Spot the valves for No. 3 cylinder and adjust No. 4. Spot the valves for No. 6 cylinder and adjust No. 1. Spot the valves for No. 2 cylinder and adjust No. 5. Spot the valves for No. 4 cylinder and adjust No. 3.

The above completes the valve tappet adjustment until after the engine is started and warmed up to operating temperatures, at which time the valve tappets should be readjusted to the correct hot operating clearance.

**NOTE:**—The cylinder head nuts must be retightened and the valve tappet clearance reset after 25 to 40 hours of service.

7. Install the cylinder head cover and any parts that may have been removed.
8. Fill the cooling system with water or a cooling solution. Start the engine and warm up to operating temperatures, then stop the engine and remove the head cover and parts.
9. Readjust the tappets to the correct operating clearance. Reassemble the head cover and parts using new gasket, if required.

**LUBRICATION is your biggest asset to offset your greatest liability . . . . .**

**Unnecessary Repairs**

## VALVE TAPPETS

The valve tappet is of the mushroom type and is hollow to receive the push rods.

### TO REMOVE THE VALVE TAPPETS

1. Remove the camshaft. See "Camshaft," Page 19.
2. Remove the tappets from the cylinder block.
3. Check the tappets for wear and replace any that have excessive clearance.

### TO INSTALL THE VALVE TAPPETS

1. Check each tappet in the cylinder block position to see that it has the correct clearance, see "Fits and Tolerances," and install the tappets.
2. Reassemble the camshaft. See "Camshaft."
3. Adjust the valves. See "Valve Grinding."




Illustration No. 53

## WATER PUMP AND FAN ASSEMBLY

Illustration No. 53 shows a sectional view of the water pump and fan (blade is not shown) as used on these engines. This pump may be readily removed from the engine after the removal of the water inlet hose, bypass hose and fan blade. Then, remove the water pump to cylinder block attaching screws and lift the pump away from the engine, Illustration No. 54.

### TO DISASSEMBLE THE PUMP

(Letters refer to Illustration No. 53.)

1. Remove the snap ring (A) if the pump is assembled with this snap ring. If not, the hub (B) is pressed onto the shaft and can be pulled off with a puller, then remove the snap ring (C).
2. Remove the screws (K) from the water pump to cover plate and remove the plate (I) and gasket (H).




Illustration No. 54

3. Place the front of the pump on a suitable support in an arbor press and press the shaft and bearing assembly out of the pump body (F) and impeller (G).
4. Press the seal (E) out of the pump body.  
The shaft and bearing assembly (D) is one unit and no attempt should be made to disassemble these parts.

Wash and clean all parts thoroughly; inspect for wear and damage. It is advisable to reface the seal surface of the impeller if it is grooved or otherwise marked. **CAUTION:**—Clean seal surfaces of oil or grease before reassembling pump.

#### TO ASSEMBLE THE PUMP

1. Press the new seal (E) into the body (F).

**CAUTION:**—Press on the outer flange of the seal to avoid damaging the seal.

2. Press the shaft and bearing assembly (D) into the body (F).

**CAUTION:**—Press only on the outer bearing face of the bearing and not on the end of the shaft.

3. Install the snap ring (C). Supporting the pump shaft on the outer shaft end, press the impeller (C) on to the shaft.

**NOTE:**—The impeller should be pressed on to a position which permits .010" clearance between a straight edge and the impeller when the straight edge is placed across the rear of the pump body.

4. Using a very coarse grade of emery cloth, roughen the polished pulley surface of the pump shaft.
5. Coat both the shaft and pulley bore with "Loctite" Grade AAV 15-10. (Use per directions supplied with the product.)

**NOTE:**—This product is manufactured by American Sealants Company, 705 No. Mountain Road, (Newington), Hartford, Connecticut, and is sold through local bearing or industrial supply distributors.

6. Support the impeller end of the pump shaft and press the pulley on to the shaft. Install the snap ring.

**CAUTION:**—Be sure the snap ring is seated in the shaft groove!

Allow the Loctite to set for a minimum of six hours before using pump.

7. Install the new cover gasket (H) and pump cover (I), with the screws (K) as removed.
8. Test the rotation of the shaft to see that it does not bind or have any excessive resistance.  
When installing a water pump always use a new gasket and tighten the attaching screws evenly and alternately to prevent possible damage.

#### MINOR ADJUSTMENTS

help to maintain the engine in good condition which  
alleviates major repairs and prolongs its usefulness.

### ELECTRICAL SYSTEMS

#### 1. THE STARTER SYSTEM

Because the starter motor requires a great deal of current to crank the engine, care must be taken to see that the wires from the starter to battery and the battery ground strap are kept clean and tight.

The starter is usually controlled by a magnetic switch or solenoid connected to the ignition switch or a starter button on the control panel. If the starter fails to operate properly when the battery is known to be fully charged, this switch circuit should be checked for loose wires or a poorly grounded magnetic switch.

**NOTE:**—Do not operate the starter motor for more than 15 seconds without allowing at least 15 seconds for it to cool.

#### 2. BATTERY CHARGING SYSTEM

Immediately after the engine is started the ammeter should show a high charge rate that will decrease as the battery recovers, if no accessories are in use, such as lights, fan motors, etc.

If the charge rate remains high and the battery continually boils away its water the voltage regulator should be checked. Consult the manufacturer's literature for procedures and settings.

**NOTE:**—If the unit is equipped with an alternator, care must be taken when using "jumper cables" to see that correct polarity is maintained. Reversing the battery connections, even for an instant, will destroy the alternator's diodes and make it inoperative. It is also important that the battery not be removed while the machine is in operation because this too can destroy the diodes.

#### 3. IGNITION SYSTEM

All wires in this system must be kept in excellent condition to assure full engine efficiency. Even small amounts of corrosion or cracks in the insulation will cause misfiring, especially during damp, cold weather.

The distributor cap should be checked periodically for cracks or carbon traces and replaced if any are found.

When constant hard starting is encountered a check should be made to see if the coil is getting at least 9V. while the starting motor is operating (4V. on a 6V. system). If the coil input voltage is too low, it cannot supply adequate voltage to the spark plugs for easy starting

## ENGINE TROUBLE SHOOTING

This section is devoted to giving the operator and maintenance crew some hints in tracing trouble, these suggestions being based on actual experience of servicing a great number of engines in various types of operation over a long period of time.

### A. ENGINE MISSES INTERMITTENTLY

- Cause: Spark plugs dirty, cracked or shorted by moisture on the electrodes.  
Correction: Clean, if dirty. Replace, if cracked. Dry, if wet or damp.
- Cause: High tension wires broken or shorted.  
Correction: Replace the wires.
- Cause: High tension wires corroded in the distributor cap.  
Correction: Clean the terminals.
- Cause: Faulty distributor points, spark plug points, condenser or coil.  
Correction: Clean and adjust or replace, if necessary, from spares.
- Cause: Valve tappets adjusted too close.  
Correction: Readjust the valve tappets to the correct clearance. See "Fits and Tolerances."
- Cause: Badly worn valve guides.  
Correction: Replace the valve guides.
- Cause: Leaking head gasket.  
Correction: Tighten the cylinder head nuts to the proper tension or replace the gasket, if necessary.
- Cause: Warped or cracked cylinder head usually due to overheating or pouring cold water in an overheated engine.  
Correction: Replace the cylinder head.
- Cause: Cracked valve seat or water jacket, usually indicated by overheating and loss of cooling solution.  
Correction: Replace the cylinder block.
- Cause: Air leak in the intake manifold.  
Correction: Replace the gaskets or manifold, if necessary.

### B. LOSS OF POWER

- Cause: Motor missing intermittently.  
Correction: See part A above for the cause and correct.
- Cause: Motor out of time.  
Correction: Retime the ignition system. See "Ignition Timing."
- Cause: Valves or valve seats worn and leaking.  
Correction: Regrind the valves. See "Valve Grinding."
- Cause: Piston rings broken, stuck in the grooves or worn.  
Correction: Replace the rings and clean the ring grooves in the piston.
- Cause: Tappets sticking or set too close.  
Correction: Readjust the tappets, or if sticking, remove and clean.
- Cause: Worn pistons, rings, et cetera.  
Correction: Replace the worn parts or rebuild the engine.

## TROUBLE SHOOTING

---

- Cause: Spark plugs leaking.  
Correction: Tighten the spark plugs in the head.
- Cause: Worn cylinders.  
Correction: Rebore the cylinders and install new oversize pistons and rings.
- Cause: Worn valve stems or guides.  
Correction: Replace the valves or guides.
- Cause: Valve springs weak or broken.  
Correction: Replace the springs.
- Cause: Valve timing incorrect.  
Correction: Correct the timing. See "Camshaft."
- Cause: Poor carburetor action.  
Correction: Clean or repair the carburetor.
- Cause: Water or sediment in the fuel tank or filter.  
Correction: Clean the fuel system.
- Cause: Air cleaner clogged.  
Correction: Wash the element in a suitable cleaning solution such as gasoline, fuel oil, et cetera.
- Cause: Exhaust pipes or muffler restricted.  
Correction: Clean or replace the exhaust pipe, muffler or tail pipe.

### C. ENGINE KNOCKING

- Cause: Loose or worn main bearings.  
Correction: Replace the main bearings.
- Cause: Loose or worn connecting rod bearings.  
Correction: Adjust or replace the bearings.
- Cause: Loose piston pins.  
Correction: Replace the pins with oversize pins or a piston and pin assembly.
- Cause: Worn cylinder bores and pistons.  
Correction: Rebore the cylinders and install new oversize pistons.
- Cause: Tight piston pins.  
Correction: Fit the pins to the proper clearance. See "Fits and Tolerances."
- Cause: Tight pistons.  
Correction: Fit the pistons to the proper clearance. See "Fits and Tolerances."
- Cause: Overheated engine.  
Correction: Allow the engine to cool, then determine the cause of overheating. See "Cooling System."
- Cause: Lack of lubricating oil.  
Correction: Fill the crankcase with the proper grade and quantity of oil. If the engine still knocks, check and replace the bearings.
- Cause: Loose flywheel.  
Correction: Tighten in place; if worn excessively by running loose, replace.
- Cause: Excessive end play in the camshaft.  
Correction: Adjust with the screw in the gear cover. See "Gear Cover."
- Cause: Idler gear shaft has excessive end play.  
Correction: Adjust with the screw in the gear cover. See "Gear Cover."
- Cause: Bent connecting rod.  
Correction: Check and straighten or replace, if necessary.



#### D. FUEL SYSTEM

1. **Excessive fuel consumption. This is usually accompanied by increased lubricating oil consumption due to dilution of the oil.**

Cause: Carburetor worn or not properly adjusted. Indicated by black smoke in the exhaust  
Correction: Check and repair the carburetor.

Cause: Fuel leaks.  
Correction: Check the fuel tank, lines, connections, et cetera.

Cause: Sticking controls.  
Correction: Oil the controls and eliminate the binding.

Cause: Excessive idling of the engine.  
Correction: Shut off the engine when not in operation..

Cause: Excessive use of the choke.  
Correction: Warm the engine to the operating temperature before applying the load, if possible ; also, keep the choke mechanism properly adjusted.

Cause: Dirty air cleaner accompanied by lack of power.  
Correction: Clean the air cleaner.

Cause: Engine overheating.  
Correction: See Overheating under "Cooling System," paragraph E-1.

Cause: Engine in poor condition and adjustment.  
Correction: Overhaul the engine.

Cause: Poor or weak ignition, indicated by the engine misfiring and puffs of smoke from the exhaust.  
Correction: See "Ignition System," paragraph G-3.

Cause: Dirty and improperly adjusted spark plugs.  
Correction: Clean and adjust

Cause: Engine overcooling.  
Correction: See "Cooling System," paragraph E-2.

2. **Fuel pressure too low.**

Cause: Air leak in the system.  
Correction: Tighten the connections and check the supply lines for leaks ; replace if necessary.

Cause: Fuel pump diaphragm out of order, also causing increased lubricating oil consumption due to oil dilution.  
Correction: Replace the diaphragm. See "Fuel Pump."

Cause: Fuel pump rocker arm linkage worn.  
Correction: Rebuild the fuel pump (see "Fuel Pump") or replace from spares.

Cause: Fuel pump check valves and springs not functioning properly.  
Correction: Clean or replace the valves and springs.

3. **Lack of fuel at the carburetor.**

Cause: Empty fuel tank.  
Correction: Fill the tank with fuel.

Cause: Bent, kinked or broken fuel lines.  
Correction: Straighten or replace the lines

Cause: Dirty filtering screens.  
Correction: Clean the filter screen. When replacing the element in the fuel filter, tightening the clamp nut finger-tight is sufficient.

## TROUBLE SHOOTING

---

- Cause: Fuel leaks.
- Correction: Check the tank, lines, connections, et cetera.
- Cause: Broken fuel pump diaphragm.
- Correction: Replace the diaphragm.
- Cause: Sticking fuel valve in the carburetor.
- Correction: Replace the fuel valve and seat.
- Cause: Loose fuel pump cover plate screws.
- Correction: Tighten the screws.

### 4. Improper idling.

- Cause: Sticking control rods or linkage.
- Correction: Oil the connections and eliminate the binding.
- Cause: Idling screw not properly adjusted.
- Correction: Adjust the screw for even idling.
- Cause: Carburetor fuel and air mixture not properly adjusted.
- Correction: Adjust the carburetor.

## E. COOLING SYSTEM

### 1. Overheating.

- Cause: Lack of cooling solution, water, anti-freeze, et cetera.
- Correction: Refill the system with the proper solution.
- Cause: Fan belt not properly adjusted.
- Correction: Adjust the fan belt for approximately 1" deflection.
- Cause: Carburetor choke valve partly closed.
- Correction: Adjust the choke valve or controls.
- Cause: Thermostat sticking in the closed position.
- Correction: Clean and test or replace.
- Cause: Coating of calcium salts on the cylinders and the inside of the cooling system.
- Correction: Clean and flush the cooling system. The use of a good commercial type inhibitor may be recommended by the manufacturer of the radiator.
- Cause: Dirt or insects in the radiator passages.
- Correction: Clean or blow out with compressed air.
- Cause: Hoses deteriorated. Cannot always be determined by the condition of the outside covering.
- Correction: Replace the hose.
- Cause: Inlet or outlet hoses collapsing.
- Correction: Replace the hoses, using a hose with an inner support, if necessary.
- Cause: Water pump not functioning.
- Correction: Check and replace the drive shaft, impeller, supply lines, et cetera.
- Cause: Exhaust pipes restricted, usually noted by a hissing sound in the exhaust.
- Correction: Clean the pipes and remove the restriction.

### 2. Overcooling.

- Cause: Thermostat sticking open
- Correction: Clean and test or replace the thermostat.
- Cause: Weather or climatic conditions too cold to allow the thermostat to hold temperature.
- Correction: Cover the radiator sufficiently to bring the water temperature into the proper range or use winter front.

**3. Loss of cooling water.**

Cause: Leaks in the radiator core.

Correction: Repair or replace.

Cause: Defective hose connections.

Correction: Tighten the clamps or replace the hose or clamps.

Cause: Radiator tubes clogged.

Correction: Clean or replace.

Cause: Water pump seals defective.

Correction: Replace the seals. See "Water Pump."

Cause: Loose freeze plugs (core plugs) in the cylinder block.

Correction: Tighten or replace the plugs.

Cause: Cracked cylinder head or block. Blown cylinder head gasket.

Correction: Replace.

**F. CLUTCH ASSEMBLY**

**1. Slipping.**

Cause: Improper adjustment.

Correction: Adjust.

Cause: Weak pressure spring.

Correction: Replace the spring.

Cause: Sticking release sleeve.

Correction: Check the sleeve pressure spring.

Cause: Worn facings on the driven disc assembly.

Correction: Replace the facings or the disc assembly.

Cause: Facings saturated with oil.

Correction: Clean the facings and correct the cause. Check the oil seal in the bellhousing, also, the pilot on the flywheel. Do not over-lubricate the clutch shafts, bearings, et cetera.

**2. Chattering.**

Cause: Oil on facings.

Correction: Clean or replace the facings.

Cause: Sticking release sleeve.

Correction: Check the pull back spring. If broken, replace.

**3. Rattling.**

Cause: Loose release fork.

Correction: Tighten the fork.

Cause: Weak or broken pull back spring.

Correction: Replace the spring.

Cause: Improper pedal adjustment.

Correction: Adjust the pedal.

**G. ELECTRICAL SYSTEM**

**1. Starting motor.**

(a) Slow cranking speed may be caused by:

Cause: Crankcase lubricating oil too heavy or cold.

Correction: Change to the correct grade of oil or heat the oil before attempting to start the engine.  
See "Lubrication."

Cause: Loose or dirty cable connection.

Correction: Clean and tighten.

Cause: Worn brushes.

Correction: Replace the brushes.

Cause: Dirty or worn armature.

Correction: Clean, repair or replace the armature.

Cause: Armature rubbing the field coils.

Correction: Replace the starter shaft bushings.

Cause: Low battery voltage.

Correction: Check the generator and regulator, then recharge the battery.

(b) Starter failing to operate may be caused by:

Cause: Battery discharged.

Correction: Recharge the battery.

Cause: Burned circuit breaker.

Correction: Replace the circuit breaker.

Cause: Broken battery cables.

Correction: Replace the cables.

Cause: Poor connections.

Correction: Clean and tighten.

Cause: Burned commutator bars.

Correction: Recut the commutator.

Cause: Open or short circuits in the armature or fields.

Correction: Check and repair.

Cause: Defective starter switch (push button or solenoid.)

Correction: Check and repair the contacts or replace the switch.

## 2. Generator.

(a) Low or no output

Cause: Fully charged battery.

Correction: None. Check the output when the battery is slightly discharged.

Cause: Dry battery.

Correction: Refill the cells with distilled water.

Cause: Burned contacts on the regulator units.

Correction: Clean or replace the contacts.

Cause: Grounded armature wires or terminal posts.

Correction: Replace the wires and insulate the terminals.

Cause: Burned commutator bars.

Correction: Recut the commutator.

Cause: Worn or sticking brushes.

Correction: Clean or replace the brushes.

Cause: Open circuits in the field or armature.

Correction: Repair or replace the defective parts.

Cause: Brush springs weak or improperly adjusted.

Correction: Adjust or replace the springs.

Cause: Rough, dirty or greasy commutator bars.

Correction: Clean the commutator bars.

Cause: High mica on the commutator.  
Correction: Undercut the mica.  
Cause: Commutator out of round.  
Correction: Recut the commutator.

(b) Noisy generator

Cause: Loose mountings.  
Correction: Tighten the mounting bolts.  
Cause: Worn or loose drive pulley.  
Correction: Tighten or replace the pulley.  
Cause: Worn bearings.  
Correction: Replace the bearings.

(c) Excessive output

Cause: Generator field grounded.  
Correction: Check the wires, et cetera, for external ground.  
Cause: Regulator circuit breaker closed.  
Correction: Adjust or repair the circuit breaker. Check the generator for damage.  
Cause: Defective regulator.  
Correction: Replace the regulator.

3. Ignition system—distributor, coil and spark plugs.

(a) Engine will not start

Cause: Breaker points not closing.  
Correction: Check and adjust.  
Cause: Breaker points defective.  
Correction: Check and replace, if necessary.  
Cause: Breaker arm grounded.  
Correction: Replace the arm.  
Cause: Defective cap or rotor.  
Correction: Check and replace.  
Cause: Defective coil.  
Correction: Replace the coil.  
Cause: Defective condenser.  
Correction: Replace the condenser.  
Cause: Loose terminals or grounded wires.  
Correction: Check and tighten or replace.

(b) Engine misses at low speed

Cause: Breaker point gap too small.  
Correction: Check and adjust the gap to the proper setting. See "Ignition Timing."

(c) Engine misses at high speed

Cause: Breaker arm spring tension too weak.  
Correction: Replace the spring or the spring and arm.  
Cause: Breaker point gap too large.  
Correction: Adjust the gap.

## TROUBLE SHOOTING

---

(d) Engine pings excessively under load at high speed

Cause: Timing too far advanced or incorrectly set.

Correction: Check and properly adjust. See "Ignition Timing."

Cause: Inferior grade of fuel.

Correction: If it is impossible to obtain the proper grade of fuel, it may be necessary to retard the spark or distributor timing somewhat to overcome the pinging noise.

(e) Weak spark at plugs

Cause: Breaker contact points worn or defective.

Correction: Examine; repair or replace the points.

Cause: Condenser disconnected or defective.

Correction: Test the connection or replace the condenser.

Cause: Breaker cam worn.

Correction: Install a new cam and stop plate assembly.

(f) Engine lacks speed and overheats

Cause: Breaker cam retarded.

Correction: Readjust the distributor and advance arm.

(g) Timing incorrect or irregular

Cause: Breaker cam loose.

Correction: Examine the distributor governor weights, pivots, springs, shaft, et cetera. Replace, as necessary.

(h) Breaker points pitted or burned

Cause: Grease or dirt on the points.

Correction: Clean, repair or replace.

Cause: Defective condenser.

Correction: Replace the condenser.

(i) Engine misses at all speeds

Cause: Distributor points set too far apart.

Correction: Check and adjust.

Cause: Condenser defective or disconnected.

Correction: Check the connection; replace the condenser, if necessary.

Cause: Breaker point screw lock nut loose.

Correction: Adjust the points and tighten.

Cause: Breaker points burned, oxidized or unevenly spaced.

Correction: Check, clean and adjust; replace, if necessary.

## H. EXCESSIVE SMOKE FROM THE EXHAUST

Cause: Too much oil in the crankcase.

Correction: Fill only to the 4/4 or FULL mark on bayonet gauge.

Cause: Carburetor float sticking or the fuel valve leaking.

Correction: Adjust or replace the fuel valve and seat. Examine the float for leaks.

Cause: Worn pistons, rings or cylinders.

Correction: Replace the worn parts or overhaul the engine.

## I. EXCESSIVE OIL CONSUMPTION

- Cause: Oil leaks at the gaskets, screws, oil seals, et cetera.  
Correction: Tighten or replace the gaskets, et cetera.
- Cause: Inferior grade of oil.  
Correction: Use a good quality oil. See specifications.
- Cause: Overheating.  
Correction: See "Cooling System," paragraph E-1.
- Cause: Ring gaps too great or lined up.  
Correction: Install new rings. If the gaps are lined up, the condition will correct itself.
- Cause: Worn or broken rings.  
Correction: Replace the rings.
- Cause: Cylinder bores out of round or excessive taper.  
Correction: Rebore the cylinders; install new pistons, rings, et cetera.
- Cause: Main or connecting rod bearings loose.  
Correction: Adjust or replace the bearings.
- Cause: Oil ring slots clogged with carbon.  
Correction: Clean the rings. Replace, if necessary.
- Cause: Carburetor fuel mixture too rich.  
Correction: Replace the worn jets and adjust.
- Cause: Piston improperly fitted or installed.  
Correction: Correct or replace the piston. See "Piston, Pin and Rings."
- Cause: Piston rings improperly fitted in the piston grooves or the cylinder bores.  
Correction: Fit the rings properly in the grooves and cylinders. See "Piston, Pin and Rings."
- Cause: Air cleaner not clean, allowing dirt to enter the combustion chamber with resultant wear.  
Correction: Keep the air cleaner clean.

## J. BEARING FAILURES

- Cause: Continuous overspeeding of the engine.  
Correction: Continuous operation at maximum speed, or close to it, is to be avoided. Exercise caution when going downgrade. Do not allow the vehicular speed to exceed the same speed obtainable in the same gear on level terrain.
- Cause: Lack of oil.  
Correction: Keep the oil level at the 4/4 mark on the bayonet gauge.
- Cause: Inferior grade of oil or oil of improper viscosity.  
Correction: Use a good quality oil of the proper viscosity.
- Cause: Low oil pressure.  
Correction: Adjust the oil pressure. See "Oil Pressure Adjustment."
- Cause: Bent connecting rod.  
Correction: Replace the connecting rod.
- Cause: Crankshaft rough or out of round.  
Correction: Regrind or replace the shaft.
- Cause: Restricted oil passages.  
Correction: Clean the oil lines and passages.
- Cause: Bearings loose or improperly fitted.  
Correction: Adjust or replace the main or connecting rod bearings..

## TROUBLE SHOOTING

---

Cause: Dirt or other matter in the lubricating oil.  
Correction: Use clean oil and service the breather air filter regularly. Replace the oil filter cartridges or the elements.

### K. LOW OIL PRESSURE

Cause: Oil pump strainer screen in the oil pan clogged.  
Correction: Clean the screen.

Cause: Oil too hot, resulting in low viscosity.  
Correction: Correct the cause of the overheating.

Cause: Pressure regulator piston worn or clogged with carbon.  
Correction: Clean and adjust properly.

Cause: Excessive main and connecting rod bearing clearance.  
Correction: Adjust or replace the bearings.

Cause: Oil pressure gauge defective.  
Correction: Replace the gauge.

Cause: Oil pressure gauge line bent or clogged.  
Correction: Clean; straighten or replace the line.

### L. RAPID CYLINDER OR PISTON WEAR

Cause: Breather and air cleaner not properly serviced, allowing dirt and abrasives to enter the combustion chambers.  
Correction: Clean frequently and at regular intervals.

Cause: Inferior grade of lubricating oil.  
Correction: Use a good quality oil. See specifications.

Cause: Lack of oil.  
Correction: Keep the oil level at the 4/4 or FULL mark on the bayonet gauge.

Cause: Dirty oil.  
Correction: Replace or change the oil and replace the oil filter elements.

Cause: Piston rings not properly fitted to the cylinders.  
Correction: Replace the piston rings. See "Piston, Pin and Rings."

Cause: Carburetor fuel mixture too rich.  
Correction: Replace the worn jets.

Cause: Cold operation of the engine.  
Correction: Check the thermostat. Warm the engine before applying the load.

### M. VALVES STICKING

Cause: Incorrect valve tappet clearance.  
Correction: Adjust the clearance correctly. See "Valve Tappets."

Cause: Valve springs weak or broken.  
Correction: Replace the springs.

Cause: Valve stems or guides scored, dirty or gummy.  
Correction: Clean; polish or replace.

Cause: Incorrect clearance between the valve stem and the guide.  
Correction: Fit the valve stems to the correct clearance in the guides.

### N. BURNED VALVES OR VALVE SEATS

Cause: Valve tappet clearance adjusted too close  
Correction: Adjust the valves to the proper clearance.



Cause: Weak valve springs.  
Correction: Replace the springs.

Cause: Excessive carbon.  
Correction: Remove the carbon deposits.

Cause: Camshaft not timed correctly.  
Correction: Retime the camshaft. See "Camshaft."

Cause: Lean fuel mixture.  
Correction: Clean and adjust the carburetor.

Cause: Valve seats too narrow.  
Correction: Cut the seats to the correct width.

Cause: Low grade fuel.  
Correction: Use a good quality fuel.

Cause: Valve heads cut too thin when refacing.  
Correction: Replace the valve.

**O. SPARK KNOCK OR PING**

Cause: Excessive accumulation of carbon in the combustion chamber.  
Correction: Clean or remove the carbon deposits.

Cause: Hot spot in the combustion chamber due to a carbon deposit or a clogged water passage.  
Correction: Remove the carbon and open the water passage.

Cause: Motor operating too hot.  
Correction: See "Cooling System," paragraph E-1.

Cause: Inferior type fuel.  
Correction: Use a good quality fuel.

Cause: Ignition timing incorrect.  
Correction: Correct or reset the timing.

Cause: Carburetion or fuel mixture incorrect.  
Correction: Check the carburetor.

Cause: Spark plug gaps too wide.  
Correction: Adjust the gaps correctly.

**P. EXPLOSION IN THE MUFFLER**

Cause: Ignition too late.  
Correction: Correct the ignition timing.

Cause: Weak spark.  
Correction: Check the condenser, distributor, coils, wires, et cetera.

Cause: Exhaust valves holding open.  
Correction: Check the tappet clearance, springs, guides, et cetera.

Cause: Exhaust valves warped.  
Correction: Reface or replace.

**Q. EXPLOSION IN THE CARBURETOR OR AIR CLEANER**

Cause: Fuel mixture too lean.  
Correction: Clean the carburetor; check the fuel level in the bowl.

Cause: Intake valves holding open.  
Correction: Check the tappet clearance, springs, guides, et cetera.

Cause: Intake manifold leaking.  
Correction: Tighten the manifold nuts or replace the gaskets.

## T O O L S

# T O O L S

PART NO.	PART NAME
206238-A .....	Socket— $\frac{7}{16}$ "
11462-A .....	Socket— $\frac{1}{2}$ "
3170-A .....	Socket— $\frac{9}{16}$ "
3171-A .....	Socket— $\frac{5}{8}$ "
3109-A .....	Socket— $\frac{3}{4}$ "
3261-A .....	Socket— $1\frac{3}{16}$ "
3172-A .....	Socket— $\frac{7}{8}$ "
203440-A .....	Deep Socket— $\frac{7}{8}$ "
3168-A .....	Socket Extension— $\frac{1}{2}$ " x 6"
13587-B .....	Square Speeder Handle— $\frac{1}{2}$ "
3189-A .....	Surface Ratchet— $\frac{1}{2}$ "
2252-A .....	Socket Universal
13077-A .....	Open End Wrench— $\frac{1}{2}$ " x $\frac{9}{16}$ "
13078-A .....	Open End Wrench— $\frac{9}{16}$ " x $\frac{5}{8}$ "
13099-A .....	Open End Wrench— $\frac{3}{4}$ " x $\frac{7}{8}$ "
6359-A .....	Manifold Wrench— $\frac{5}{8}$ " x $\frac{5}{8}$ "
11927-A .....	Flex Handle
13171-A .....	Piston Ring Compressor
13096-A .....	Valve Spring Lifter
13098-A .....	Piston Ring Expander
11925-A .....	Screwdriver - $\frac{3}{16}$ " x 5" Blade
13175-A .....	Screwdriver - $\frac{1}{4}$ " x 6" Blade
13095-A .....	Pliers - 9" Heavy Duty
13278-A .....	Adjustable Wrench
11919-A .....	Feeler Gauge Set - 9" Blades
11920-A .....	Lady Foot Pry Bar
11921-A .....	Ball Pein Hammer—12 oz.
3444-A .....	Torque Wrench
6335-A .....	Tool Box

# FITS AND TOLERANCES

Model 4 and 6 cylinder

		MFG'S. TOLERANCES		DESIRED CLEARANCE		Maximum Allowable Wear	Maximum Allowable Clearance
		MINIMUM	MAXIMUM	MINIMUM	MAXIMUM		
A. CYLINDER BLOCK							
.1a	Cylinder bore dia. 3¾" bore	3.7490	3.7510			0.0050	
.1b	Cylinder bore dia. 3⅞" bore	3.8740	3.8760			0.0050	
.1c	Cylinder bore dia. 4" bore	3.9990	4.0010			0.0050	
.2	Cylinder bore out of round		0.0005			0.0030	
.3	Cylinder bore taper		0.0005			0.0020	
.4	Main brg. bore — less bearings	3.0665	3.0670				
.5	Camshaft brg. bore — less brgs.	2.1870	2.1880				
.6	Oil pump bore	2.0000	2.0005				
.7	Valve tappet bore	0.7494	0.7500			0.0030	
.8	Main brg. cap bolt torque ft. lbs.			80 ft. lbs.			
B. CYLINDER SLEEVE							
.1a	Cyl. sleeve length 3¾" bore		8-7/8				
.1b	Cyl. sleeve length 3⅞" bore		8-13/16				
.2	Cyl. sleeve o. d.	3.9990	4.0000				
.3	Cyl. sleeve to block	Selective		Hand push fit			
.4	Cyl. sleeve above block deck	0.0020	0.0040				
C. CRANKSHAFT							
.1	Main brg. journal dia.	2.8734	2.8744			0.0030	
.2	Main brg. journal out of round		0.0003			0.0020	
.3	Main brg. journal taper		0.0003			0.0015	
.4	Main brg. run-out at center		0.0020			0.0030	
.5	Conn. rod journal dia.	2.3730	2.3740			0.0020	
.6	Conn. rod journal out of round		0.0003			0.0020	
.7	Conn. rod journal taper		0.0003			0.0015	
.8	Fillet radii	0.1400	0.1700				
.9	Crankshaft main brg. clearance			0.0009	0.0034		0.0070
.10	Crankshaft thrust clearance			0.0050	0.0100		0.0150
.11	Seal surface dia. — rear	4.3100	4.3150			0.0150	
.12	Seal surface dia. — front	1.8740	1.8750			0.0150	
D. CONNECTING ROD							
.1	Length — c/l to c/l	7.9980	8.0020				
.2	Bearing bore — less bearings	2.5260	2.5270				
.3	Brg. to crankshaft clearance			0.0010	0.0030		0.0050
.4	Conn. rod side clearance			0.0050	0.0120		0.0200
.5	Piston pin bushing bore — less bushing	1.4370	1.4380				
.6	Piston pin bushing bore	1.2503	1.2508			0.0015	
.7	Cap bolt torque ft. lbs.			70 ft. lbs.			
E. CAMSHAFT							
.1	Bearing journal dia. — all	2.0530	2.0540			0.0020	
.2	Lobe diameter — base to tip	1.7200	1.7250			0.0100	
.3	Journal run-out in vee blocks		0.0010			0.0040	
.4	Bearing clearance			0.0015	0.0035		0.0060
.5	End Thrust			0.0015	0.0055		0.0120
.6	Back lash camshaft to crank gear			0.0010	0.0030		
.7	Gear retaining nut torque ft. lbs.			130 ft. lbs.			
F. PISTON							
		(With newly honed bores and new pistons)					
.1	Clearance in cyl. bore — all	5 lb.	8 lb.	Pull on ½ X 0.0030 ribbon			
.2	Piston pin bore	1.2500	1.2502			0.0010	
.3	Width of ring groove — top — comp.	0.0970	0.0980			0.0080	
.4	Width of ring groove — 2nd. — comp.	0.1260	0.1270			0.0050	
.5	Width of ring groove — oil control	0.1880	0.1890			0.0050	

## Model 4 and 6 cylinder (continued)

		MFG'S. TOLERANCES		DESIRED CLEARANCE		Maximum Allowable Wear	Maximum Allowable Clearance
		MINIMUM	MAXIMUM	MINIMUM	MAXIMUM		
G. PISTON PIN							
.1a	Length 3¾" & 3⅞" dia. piston	3.0350	3.0400			0.0020	
.1b	Length 4" dia. piston	3.3600	3.3650				
.2	Diameter	1.2498	1.2499				
.3	Clearance in piston			0.0000	0.0005		0.0020
.4	Clearance in connecting rod			0.0005	0.0012		0.0050
H. PISTON RING							
.1	Clearance in groove — top — comp.			0.0035	0.0050		0.0100
.2	Clearance in groove — 2nd. — comp.			0.0020	0.0035		0.0080
.3	Clearance in groove — oil control			0.0015	0.0030		0.0080
.4	Gap			0.0100	0.0200		0.0400
I. VALVE, INTAKE							
.1	Head diameter	1.6825	1.6925			0.0025	0.0050
.2	Stem diameter	0.3725	0.3735				
.3	Stem to guide clearance			0.0005	0.0025		
.4	Stem to rocker arm clearance — hot			0.0160	0.0170		
.5	Seat diameter in head	1.6510	1.6610			1/8	
.6	Seat width in head		7/64				
.7	Top of valve recessed below cyl. hd. deck	0.0210					
J. VALVE, EXHAUST							
.1	Head diameter	1.4950	1.5050			0.0025	0.0060
.2	Stem diameter	0.3740	0.3750				
.3	Stem to guide clearance			0.0015	0.0035		
.4	Stem to rocker arm clearance — hot			0.0160	0.0170		
.5	Seat diameter in head	1.4640	1.4740			1/8	
.6	Seat width in head		7/64				
.7	Top of valve recessed below cyl. hd. deck	0.0210					
K. VALVE GUIDE							
.1	Length	2.9325	2.9425			0.0030 0.0030	
.2	Outside diameter	0.6265	0.6270				
.3	Bore diameter — intake — ream	0.3740	0.3750				
.4	Bore diameter — exhaust — ream	0.3750	0.3760				
.5	Depth below cyl. head gasket face — Exh.	1.2500	1.2600				
.6	Depth below cyl. head gasket face — Int.	1.3750	1.3850				
L. TAPPET, VALVE LIFTER (PUSH ROD)							
.1	Body diameter	0.7485	0.7490			0.0030	
.2	Overall length	2.2450	2.2550				
.3	Clearance in bore (block)			0.0005	0.0015		0.0050
M. VALVE SPRINGS — INTAKE & EXHAUST							
.1	Free length	1.7960	1.8360				
.2	Total coils	6-1/4					
.3	Diameter wire	0.1770					
.4	Outside diameter	1.2920	1.3020				
.5	Test load at 1.4920 inches lbs.	72	82				
.6	Test load at 1.0820 inches lbs.	163	180				
M.a VALVE SPRING — INTAKE & EXHAUST							
Note — This spring is used in some engines and is not interchangeable							
.1	Free length	1.8630	1.9030				
.2	Total coils	7-1/2					
.3	Diameter wire	.1420					
.4	Outside diameter	1.2300	1.2500				
.5	Test load at 1.5225 inches lbs.	38 lbs.	45 lbs.				
.6	Test load at 1.1725 inches lbs.	80 lbs.	86 lbs.				

## Model 4 and 6 cylinder (continued)

	MFG'S. TOLERANCES		DESIRED CLEARANCE		Maximum Allowable Wear	Maximum Allowable Clearance
	MINIMUM	MAXIMUM	MINIMUM	MAXIMUM		
<b>N. OIL PUMP</b>						
<b>BODY:</b>						
.1 Shaft bore diameter — main	0.6255	0.6265			0.0030	
.2 Shaft bore diameter — idler	0.6255	0.6265			0.0030	
.3 Pump gear bore diameter	1.5005	1.5015			0.0050	
.4 Pump gear bore depth	1.5640	1.5650			0.0040	
<b>SHAFTS:</b>						
.5 Length — main	9.2400	9.2500				
.6 Length — idler	2.7450	2.7550				
.7 Diameter — main	0.6240	0.6245			0.0020	
.8 Diameter — idler	0.6240	0.6245			0.0020	
.9 Shaft clearance in body			0.0010	0.0025		0.0060
<b>GEARS:</b>						
.10 Outside diameter — both	1.4975	1.4985			0.0020	
.11 Length — both	1.5610	1.5620				
.12 Clearance in body bore			0.0020	0.0040		0.0070
.13 End clearance to body			0.0020	0.0040		0.0080
.14 Backlash, drive gear to camshaft			0.0060	0.0120		0.0200
<b>O. FLYWHEEL</b>						
.1 Clutch face run out at 6 in. rad.		0.0080				
.2 Pilot bore eccentricity		0.0050				
<b>P. FLYWHEEL HOUSING</b>						
.1 Clutch attaching face deviation		0.0080				
.2 Clutch housing bore eccentricity		0.0050				
<b>Q. ROCKER ARM MECHANISM</b>						
.1a Rocker shaft length — 4 cyl.	19.4900	19.5100				
.1b Rocker shaft length — 6 cyl.	13.7400	13.7600				
.2 Rocker shaft diameter	0.8590	0.8600			0.0030	
.3 Rocker arm bore diameter	0.8625	0.8635			0.0030	
.4 Rocker arm clearance on shaft			0.0025	0.0045		0.0120
.5 Tappet adj. screw torque ft. lbs.	3	10				
<b>R. GOVERNOR</b>						
.1 Bushing bore — gear housing	0.4365	0.4370				
.2 Shaft diameter — gear end	0.4350	0.4355				
.3 Shaft clearance			0.0010	0.0020		
.4 Gear backlash			0.0010	0.0040		
<b>T. TORQUE VALUES — MISC. FT. LBS.</b>						
.1 Cyl. head nuts 5/8 solid stud			175 ft. lbs.			
.2 Cyl. head nuts 5/8 hollow stud — 6 cyl.			175 ft. lbs.			
.2A Cyl. head nuts 5/8 hollow stud — 4 cyl.			160 ft. lbs.			
.3 Cyl. head nuts 9/16 solid studs			160 ft. lbs.			
.4 Flywheel bolt			80 ft. lbs.			
.5 Manifold — intake & exhaust	30	40	35 ft. lbs.			
.6 All other bolts and nuts to be securely but not excessively tightened.						