SEBP1306

parts

3208 Industrial Engine

Naturally Aspirated

90N52893-UP

QUICK REFERENCE CHARTS

USE THESE CHARTS TO RECORD FREQUENTLY USED MAINTENANCE INFORMATION

MACHINE SERIAL NO.	
EQUIPMENT NO.	

FREQUENTLY REPLACED ITEMS

PART NO.	PART NAME

FLUIDS & LUBRICANTS

WHERE USED	TYPE	AMOUNT

OTHER MAINTENANCE ITEMS

FORM SEBP1306

)NTENTS

'ALPHABETICAL INDEX OF GROUPS__ 3
:ONVERSION EQUIVALENT
TABLES INSIDE BACK COVER
)RDERING PARTS_____ 2
)UICK REFERENCE
CHART INSIDE FRONT COVER
JSING THE PARTS BOOK_____2



PARTS BOOK

3208

NDUSTRIAL ENGINE

SERIAL NUMBER
)0N52893—UP

'UBLISHED DECEMBER 1980
:ATERPILLAR TRACTOR CO.
'UBLICATIONS DIV.—SERVICE G.O.
'EORIA, ILL. U.S.A.

QUICK REFERENCE GUIDE TO MAJOR SECTIONS

BASIC ENGINE
LUBRICATION SYSTEM
COOLING SYSTEM
INTAKE & EXHAUST SYSTEM
FUEL SYSTEM & GOVERNOR
STARTING & ELECTRICAL SYSTEM
SERVICE EQUIPMENT & SUPPLIES

ENGINE IDENTIFICATION Caterpillar engines are identified with SERIAL NUMBERS and A RANGEMENT NUMBERS. In some cases MODIFICATION NUMBE are also used. These numbers are shown on the serial number pl mounted on the engine. The Specification Section at the back of this Parts Book indicates location of the serial number plate.

Caterpillar dealers need all of these numbers to determine which components were incluc on the engine when it was assembled at the factory. This permits accurate identification replacement part numbers.

ORDERING PARTS Quality Caterpillar Replacement parts are available from Caterpillar deal throughout the world. Their parts stocks are up to date and include all pa normally required to protect your investment in Caterpillar engines. Wl ordering parts, your order should specify the quantity, part number, part name and the se number, arrangement number and modification number of the engine for which the parts needed. If in doubt about the part number, please provide your dealer with a compl description of the needed item.

HOW TO USE THE PARTS BOOK Caterpillar Parts Books include illustrations of the groups or assemblies which make up the engine. These illustrations show the standard components plus many of the attachments available for the engine.

The alphabetical index located in the front part of the book should be used to determine the page number on which specific illustrations are shown. Reference to those pages will identify each of the individual serviceable parts.

Captions The caption under each illustration identifies the part number and name of the group or assembly shown. If more than one illustration is included for any group, the caption identifies the specific engine serial numbers to which each illustration applies. In some cases it is not possible to determine the specific engine serial numbers to which different illustrations are applicable. In those cases the caption identifies the illustration as "First Type", "Second Type", etc. Reference to the actual group or assembly is necessary in those cases to determine which illustration should be used.

Captions provide additional information such as page numbers where illustrations of sub assemblies are shown, information reguarding quantities used and other information intended to assist the user in determining parts needs.

Indented Part Names Within each illustration is parts list identifying each viceable part in the illustrati When a part name is indented in this list means that serviceable item is a part of serviceable item under which it is indent

Abbreviations and Symbols

▲ ●	Used to call attention to additic information shown elsewhere w in the illustration.	
R.H. L.H.	Right Hand Left Hand	Refers to the sid the engine as viev from the flywl end.
C	Indicates changes from the previ illustration of the same group assembly.	
O.D.	Outside Diameter	
I.D.	Inside Diameter	
N/S	Not Serviced	
Assem.	Assembly	
in.	Inch	
ft	Foot	
cm	Centimeter	
dm	Decimeter	

Note: Continuing improvement and vancement of product design may ca changes to your engine which may not included in this publication. Each publ tion is reviewed and revised, as required, update and include these changes in la editions.

Whenever a question arises regarding y Caterpillar product, or this publicati please consult your Caterpillar dealer for latest available information.

INDEX

A

Name	Page
Accessory Drive	237
Air Cleaner	143
Air Cleaner Adapter	142
Air Compressor	234
Alternator	210
Alternator Mounting	228
Auxiliary Drive Pulley	134

B

Name	Page
Bearings — Camshaft	80

C

Name	Page
Camshaft	88
Cetane Injection	192
Clutch	232
Clutch — Rear Power Take-Off	231
Connecting Rod & Piston	88
Contactor — Oil Pressure & Water Temperature Alarm	230
Coolant Filter	136
Crankcase Ventilation Valve	144
Crankshaft	84
Crankshaft Bearing Replacements	86
Crankshaft Cover	85
Crankshaft Pulley	87
Crankshaft Seals	85
Cylinder Block	80
Cylinder Block Cover	81
Cylinder Block Panel	82
Cylinder Block Service	81
Cylinder Block Sound Suppression Panel	83
Cylinder Head	90

D

Name	Page
Damper	87

E

Name	Page
Engine Arrangements	4
Element — Air Cleaner	143
Exhaust Elbow	141
Exhaust Fitting	140
Exhaust Manifold	137
Exhaust Pipe	139

F

Name	Page
Fan — Blower	130
Fan — Suction	131
Fan Drive	127
Fan Drive Pulley	129
Filter — Air Cleaner	143
Filter — Coolant	136
Filter — Engine Oil	115
Filter — Fuel	188
Filter — Primary Fuel	189

Name Page

Flywheel 99
Flywheel Housing 102
Flywheel Housing Cover 104
Front Housing 96
Front Housing Cover 97
Fuel Filter 188
Fuel Filter Lines 182
Fuel Injection Lines 180
Fuel Injection Pump 166
Fuel Priming Pump 190
Fuel Pump Boost — Electrical 189
Fuel System Fastener 191

G

Gasket — Oil Pan 107
Gasket — Valve Cover 93
Gasket Kits 246
Governor & Fuel Injection Pump 146
Governor & Fuel Injection Pump — Field Installation 154
Governor & Fuel Pump Drive 143
Governor Control 178
Governor Control — Positive Lock 179

H

Harness — Alternator 212
Heater — Jacket Water 123
Hour Meter 245

I

Inlet Manifold 140

Name Page

Instrument Panel 238

J

Jacket Water Heater 123

K

Kit — Alternator Repair 215
Kit — Starting Motor Repair 200
Kit — Water Pump Rebuild 125

L

Lifting 94

M

Muffler 141

N

Name Plate & Films 246
Nozzle — Fuel Injection 180

O

Oil Cooler — Engine 117
Oil Filter 115

Name Page

Oil Level Gauge 108
Oil Level Gauge Changeover 112
Oil Lines — Engine 115
Oil Pan 107
Oil Pan Shield 106
Oil Pressure & Water Temperature Alarm Contactor 230
Oil Pump 113

P

Piston Rings 88
Positive Crankcase Ventilation Valve ..144
Power Take-Off — Rear Clutch 231
Primary Fuel Filter 189
Pulley — Water Pump 124
Pulley & Damper 87

R

Radiator 135
Regulator — Water Temperature 119
Rockerarm — Valve Mechanism 92

S

Sending Unit — Oil Pressure 238
Short Cylinder Block 84A
Shut-Off — Electric 193
Shut-Off — Solenoid 195
Solenoid Switch — Starting Motor 208

Name Page

Starting Motor — Electric 198
Starting Switch 242
Support — Engine 97
Switch — Oil Pressure 210
Switch — Starter 242
Switch — Starting Motor Solenoid 208

T

Tachometer Drive Adapter 97
Tachometer Mounting & Drive 244
Temperature Compensator Conversion 177
Thermostat — Water Temperature 119
Torque Control 176
Torque Converter Mounting 106

V

Valve — Intake & Exhaust 9
Valve Mechanism 9
Valve Mechanism Cover 9
Vee Belt — Accessory Drive 23
Vee Belt — Alternator 21
Vee Belt — Water Pump Drive 12

W

Water Lines 1
Water Pump 1
Water Pump Drive 1
Water Separator 1

INDEX ALPHABÉTIQUE

Les versions fournies par les usines sont indiquées page 4.

Moteur de base (Page 4)

Désignation	Page
Arbre à cames	88
Bielles et pistons	88
Bloc-cylindres	83
Bloc-cylindres (couvercle)	81
Bloc embiellé	84A
Bride de levage	94
Carter avant	96
Carter avant (couvercle)	97
Carter de volant	102
Carter de volant (couvercle)	104
Carter inférieur	107
Carter inférieur (protecteur)	106
Convertisseur de couple (groupe de montage)	106
Coussinets de rechange de vilebrequin	86
Culasse	90
Joint de vilebrequin	85
Jeanneaux d'isolation	82
Poulie de vilebrequin	87
Poulie et damper	87
Soupapes (couvercle)	93
Soupapes et train de commande	92
Support	97
Vilebrequin	84
Vilebrequin (couvercle)	85
Volant	99

Circuit de graissage (Page 109)

Canalisations d'huile	115
Filtre à huile	115
Jauge de niveau d'huile	108
Jauge de niveau d'huile (groupe de transformation)	112
Pompe à huile	113

Circuit de refroidissement (Page 117)

Désignation	Page
Entraînement de pompe à eau	124
Entraînement de ventilateur	127
Filtre (liquide réfrigérant)	136
Pompe à eau	125
Poulie d'entraînement auxiliaire	134
Poulie de pompe à eau	124
Radiateur	135
Réchauffeur d'eau de cylindres	123
Refroidisseur d'huile	117
Tuyauterie d'eau	119
Ventilateur aspirant	131
Ventilateur soufflant	130

Admission et échappement (Page 137)

Collecteur d'admission	140
Collecteur d'échappement	137
Coude d'échappement	141
Échappement (tuyauterie de raccordement)	140
Filtre à air	143
Filtre à air (groupe de montage)	142
Silencieux d'échappement	141
Soupape d'aération de carter	144
Tuyau d'échappement	139

Alimentation en carburant et régulateur (Page 145)

Canalisations de filtre à carburant	182
Compensateur de température (carburant)	177
Dispositif d'alimentation en cétane	192

Désignation Page

Dispositif de fixation 191
Électropompe à carburant. 189
Entraînement de pompe d'injection et régulateur 145
Filtre à carburant 188
Pompe d'amorçage. 190
Pompe d'injection 190
Régulateur (timonerie extérieure) 178
Régulateur et pompe d'injection 146
Séparateur d'eau 186
Tuyauterie d'injection 180

Circuit électrique et démarrage (Page 193)

Alternateur 210
Alternateur (groupe de montage) 228

Désignation Page

Arrêt à commande électrique. 193
Contacteur d'alarme (pression d'huile et échauffement) 230
Démarreur électrique 193
Solénoïde d'arrêt. 196

Divers (Page 231)

Compresseur d'air 234
Entraînements secondaires 237
Horomètre 245
Jeux de joints. 246
Plaques signalétiques et instructions sur film. 246
Prise de force 231
Tableau d'instruments 238
Tachymètre (groupe de montage et entraînement) 244

INDICE

LA LISTA DE CONJUNTOS DE MOTOR SE EMPIEZA EN LA PAGINA 4.

Motor Básico (Página 4)

Nombre	Página
Arbol de levas	88
Bielas y pistones	88
Bloque del motor	83
Bloque incompleto	84A
Caja delantera	96
Caja del volante	102
Cáncamo	94
Cárter	107
Cigüeñal	84
Cojinetes de bancada de repuesto	86
Cubierta del cárter	106
Culata	90
Mecanismo de las válvulas	92
Montaje del convertidor de par	106
Polea del cigüeñal	87
Polea y amortiguador de vibraciones	87
Sello del cigüeñal	85
Soporte	97
Tablero del bloque del motor	82
Tapa de caja del volante	104
Tapa de la caja delantera	97
Tapa del bloque del motor	81
Tapa del cigüeñal	85
Tapa del mecanismo de las válvulas	93
Volante	99

Sistema de Lubricación (Página 109)

Bomba del aceite	113
Cambio de la varilla indicadora de nivel del aceite	112
Filtro del aceite	115
Tuberías del aceite	115
Varilla indicadora de nivel del aceite	108

Sistema de Enfriamiento (Página 117)

Nombre	Página
Bomba del agua	125
Calentador del agua de las camisas	123
Enfriador del aceite	117
Filtro del refrigerante	136
Mando de la bomba del agua	124
Mando del ventilador	127
Polea de bomba del agua	124
Polea de mando auxiliar	134
Radiador	135
Tuberías del agua	119
Ventilador de succión	131
Ventilador soplador	130

Sistema de Admisión y Escape (Página 137)

Adaptador del filtro de aire	142
Codo de escape	141
Conexiones de escape	140
Filtro de aire	143
Múltiple de admisión	140
Múltiple de escape	137
Silenciador	141
Tubo de escape	139
Válvula de ventilación positiva del cárter	144

Sistema del Combustible y Regulador (Página 145)

Bomba de cebado del combustible	190
Bomba del combustible	190
Bomba eléctrica de combustible	189
Control del regulador	178
Filtro del combustible	188

Nombre Página

Grupo de conversión para compensación de temperatura . 177
Herrajes del sistema del combustible. 191
Inyección de cetano. 192
Regulador y bomba de inyección del combustible. . . . 146
Regulador y mando de bomba del combustible. 145
Separador de agua 186
Tuberías de filtro del combustible 182
Tuberías de inyección del combustible. 180

Sistema de Arranque y Eléctrico (Página 193)

Alternador. 210
Contactor de alarma accionado por la presión del aceite y la temperatura del agua. 230
Montaje del alternador 228
Motor de arranque eléctrico 193
Parada eléctrica. 193
Solenoide de parada. 196

Accesorios y Equipo Diversos (Página 231)

Compresor de aire 234
Juegos de empaquetaduras 246
Mando de accesorios 237
Medidor de servicio 245
Montaje y mando del tacómetro 244
Placas de identificación y calcomanías. 246
Tablero de instrumentos 238
Toma de fuerza. 231

ÍNDICE

OS ARRANJOS DO MOTOR ESTÃO RELACIONADOS A PARTIR DA PÁGINA 4.

Motor básico (Página 4)

Designação	Página
Biela e pistão	88
Blindagem do cárter	106
Bloco do motor	83
Cabeçote	90
Caixa das engrenagens de distribuição	96
Caixa do volante	102
Cárter do motor diesel	107
Eixo de comando de válvulas	88
Grupo básico do motor	84A
Mancais principais do motor	86
Mecanismo das válvulas	92
Olhal de levantamento	94
Painel isolador de som	82
Polia do virabrequim	87
Polia e amortecedor do virabrequim	87
Suporte	97
Suporte do conversor de torque	106
Tampa da caixa do volante	104
Tampa das engrenagens de distribuição	97
Tampa de proteção do virabrequim	85
Virabrequim	84
Volante do motor	99

Sistema de lubrificação (Página 109)

Bomba de óleo	113
Filtro de óleo	115
Tubulações do óleo	115
Vareta de nível do óleo	108
Vareta de nível do óleo – conversão	112

Sistema de arrefecimento (Página 117)

Designação	Página
Aquecedor d'água do motor	123
Arrefecedor de óleo do motor	117
Bomba d'água	125
Comando da bomba d'água	124
Comando do ventilador	127
Filtro do refrigerante	136
Polia da bomba d'água	124
Polia do comando auxiliar	134
Radiador	135
Tubos d'água	119
Ventilador insuflador	130
Ventilador succionador	131

Sistema de admissão e escape (Página 137

Adaptador do purificador de ar	142
Coletor de admissão	140
Coletor de escape	137
Conexões de escapamento	140
Cotovelo de escape	141
Purificador de ar	143
Silenciador	141
Tubo de escape	139
Válvula de ventilação positiva do cárter	144

Sistema de combustível e governador (Página 145)

Bomba de combustível elétrica	189
Bomba de purgação do combustível	190
Bomba do combustível	190
Bomba injetora elétrica	189
Bomba injetora e governador	146

Designação Página

Compensador de temperatura do combustível (grupo de conversão) 177
Controle do governador 178
Filtro de combustível. 188
Fixadores do sistema de combustível 191
Governador e comando da bomba de combustível 145
Injetor de cetano. 192
Separador d'água. 186
Tubos injetores. 180
Tublações do filtro de combustível 182

Sistema elétrico e de partida (Página 193)

Alternador. 210
Interruptor de segurança da pressão do óleo e temperatura d'água 230
Motor de arranque elétrico 193
Parada elétrica 193
Suporte do alternador 228

Acessórios e equipamento para manutenção (Página 231)

Comando de acessórios. 237
Compressor de ar. 234
Decalcomanias e placas de identificação. 246
Horômetro. 245
Jogos de juntas 246
Painel de instrumentos 238
Suporte do tacômetro e comando. 244
Tomada de força. 231

INHALTSVERZEICHNIS

Motorausführungen sind ab Seite 4 aufgeführt

Motor (Seite 4)

Bezeichnung	Seite
Auflager	97
Drehmomentwandler-Aufhängung	106
Huböse	94
Kurbelwelle	84
Kurbelwellendeckel	85
Kurbelwellendichtung	85
Kurbelwellen-Ersatzlager	86
Motorblock	83
Motorblockdeckel	81
Motorverkleidung	82
Nockenwelle	88
Ölwanne	107
Ölwannenschutz	106
Pleuel und Kolben	88
Riemenscheibe der Kurbelwelle	87
Riemenscheibe und Dämpfer	87
Schwungscheibe	99
Schwungscheibengehäuse	102
Schwungscheibengehäusedeckel	104
Skelettmotor	84A
Stirnradgehäuse	96
Stirnradgehäusedeckel	97
Ventildeckel	93
Ventilsteuerung	92
Zylinderkopf	90

Kühlsystem (Seite 117)

Bezeichnung	Seite
Drucklüfter	130
Kühlernetz	135
Kühlmittelfilter	136
Kühlwasserheizung	123
Lüfterantrieb	127
Ölkühler	117
Riemenscheibe des Nebenantriebs	134
Riemenscheibe der Wasserpumpe	124
Sauglüfter	131
Wasserleitungen	119
Wasserpumpe	125
Wasserpumpenantrieb	124

Ansaugg- und Abgasanlage (Seite 137)

Ansaugkrümmer	140
Auspuffanschluß	140
Auspuffbogen	141
Auspuffkrümmer	137
Auspuffrohr	139
Kurbelgehäuse-Explosionskappe	144
Luftreiniger	143
Luftreinigeranschluß	142
Schalldämpfer	141

Schmiersystem (Seite 108)

Ölleitungen	115
Ölmeßstab	108
Ölmeßstab – Umbausatz	112
Schmierfilter	115
Schmierpumpe	113

Kraftstoffanlage und Regler (Seite 145)

Kraftstoffanlagen-Halteteile	191
Kraftstoffeinspritzleitungen	180
Kraftstoffentlüftungspumpe	190
Kraftstoffilter	188
Kraftstoffilterleitungen	182
Kraftstoffpumpe	190

Bezeichnung	Seite
Kraftstoffpumpe, elektr.	189
Kraftstoff-Temperaturregler	177
Regler und Kraftstoffeinspritzpumpe	146
Regler- und Kraftstoffpumpenantrieb	145
Reglersteuerung	178
Wasserabscheider	186
Zündbeschleuniger	192

Anlasser und elektr. Anlage (Seite 193)

Bezeichnung	Seite
Abschaltsolenoid	196
Anlasser, elektr.	193
Drehstromlichtmaschine	210
Lichtmaschinenaufhängung	228
Notabschalter, elektr.	193
Schaltschütz, öldruck- und wassertemperaturabhängig.	230

Wartungsgerät und Zubehör (Seite 231)

Bezeichnung	Seite
Aufkleber und Abziehbilder	246
Dichtungssätze	246
Drehzahlmesseraufhängung und -antrieb	244
Instrumentenbrett	238
Luftkompressor	234
Steuerantrieb	237
Wartungsmesser	245
Zapfwelle	231

		Consists of:	Page
CENTRAL STRUCTURE			
1	9N3761	Cylinder Block Group	80
1	9N728	Single Camshaft Group	88
1	9L6065	Cylinder Block Cover Group	81
1	9N6222	Crankshaft Group	84
8	9N3538	Connecting Rod and Piston Group	88
1	9N542	Crankshaft Seal Group	85
UPPER STRUCTURE			
1	9N730	Valve Mechanism Cover Group	93
1	9N1105	Cylinder Head Group	90
2	9N191	Lifting Group	94
1	9N487	Valve Mechanism Group	92
FRONT STRUCTURE			
1	9N560	Front Housing Cover Group	97
1	9N5590	Pulley and Damper Group	87
1	9N5211	Front Housing Group	96
1	9N5224	Engine Support Group	98
REAR STRUCTURE			
1	9L7861	Flywheel Housing Cover Group	105
1	9N529	Flywheel Housing Group	103
LOWER STRUCTURE			
1	9N565	Oil Pan Group	107

1W318 ENGINE ARRANGEMENT—Part 1
156.6 brake kW (210 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
		LUBRICATION SYSTEM	
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6641	ENGINE OIL LINES GROUP	115
1	1W2206	OIL PUMP GROUP	113
		COOLING SYSTEM	
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
		INTAKE AND EXHAUST SYSTEM	
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
		GOVERNOR AND FUEL SYSTEM	
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR AND FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W318 ENGINE ARRANGEMENT—Part 2
156.6 brake kW (210 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	9N3538	CONNECTING ROD AND PISTON GROUP	88
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	4N5866	FLYWHEEL HOUSING COVER GROUP	104
1	4N5870	FLYWHEEL HOUSING GROUP	104
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W319 ENGINE ARRANGEMENT—Part 1
156.6 brake kW (210 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6641	ENGINE OIL LINES GROUP	115
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
GOVERNOR AND FUEL SYSTEM			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR AND FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W319 ENGINE ARRANGEMENT—Part 2
156.6 brake kW (210 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	9N3538	CONNECTING ROD AND PISTON GROUP	88
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	9L7861	FLYWHEEL HOUSING COVER GROUP	105
1	9N529	FLYWHEEL HOUSING GROUP	103
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W320 ENGINE ARRANGEMENT—Part 1
156.6 brake kW (210 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		Consists of:	Page
LUBRICATION SYSTEM			
1	9N2538	Oil Level Gauge Group	110
1	1W2638	Oil Filter Group	115
1	9N6632	Engine Oil Lines Group	116
1	1W2206	Oil Pump Group	113
COOLING SYSTEM			
1	9N729	Engine Oil Cooler Group	118
1	9N733	Water Lines Group	119
1	9N3654	Water Pump Group	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	Exhaust Manifold Group	137
1	9N555	Inlet Manifold Group	140
1	9N735	Positive Crankcase Ventilation Valve Group	144
GOVERNOR AND FUEL SYSTEM			
1	9L6743	Governor Control Group	178
1	9N740	Governor and Fuel Pump Drive Group	145
1	9L6925	Fuel System Fastener Group	191
1	4N5868	Fuel Filter Group	188
1	9N435	Fuel Filter Lines Group	182
1	9N3880	Fuel Injection Lines Group	180
1	4N4314	Fuel Priming Pump Group	190
1	9N3757	Governor and Fuel Injection Pump Group	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W320 ENGINE ARRANGEMENT—Part 2
156.6 brake kW (210 bhp) engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	9N3538	CONNECTING ROD AND PISTON GROUP	88
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	4N5866	FLYWHEEL HOUSING COVER GROUP	104
1	4N5870	FLYWHEEL HOUSING GROUP	104
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W321 ENGINE ARRANGEMENT—Part 1
156.6 brake kW (210 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6632	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
GOVERNOR AND FUEL SYSTEM			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	8N5639	GOVERNOR AND FUEL INJECTION PUMP GROUP	151B

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W321 ENGINE ARRANGEMENT—Part 2
156.6 brake kW (210 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV V and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	9N3538	CONNECTING ROD AND PISTON GROUP	88
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	9L7861	FLYWHEEL HOUSING COVER GROUP	105
1	9N529	FLYWHEEL HOUSING GROUP	103
LOWER STRUCTURE			
1	4N8853	OIL PAN GROUP	107

1W322 ENGINE ARRANGEMENT—Part 1
56.6 brake kW (210 bhp) Engine with R.H. Oil Level Gauge, Center Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	4N8855	OIL LEVEL GAUGE GROUP	109
1	1W2638	OIL FILTER GROUP	115
1	9N6634	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR & FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W322 ENGINE ARRANGEMENT—Part 2
156.6 brake kW (210 bhp) Engine with R.H. Oil Level Gauge, Center Sump Oil Pa R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	9N3538	CONNECTING ROD AND PISTON GROUP	88
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	4N5866	FLYWHEEL HOUSING COVER GROUP	104
1	4N5870	FLYWHEEL HOUSING GROUP	104
LOWER STRUCTURE			
1	4N8853	OIL PAN GROUP	107

1W323 ENGINE ARRANGEMENT—Part 1
156.6 brake kW (210 bhp) Engine with R.H. Oil Level Gauge Center Sump Oil Pan, R.H. Mounted PCV Valve and Sae No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	4N8855	OIL LEVEL GAUGE GROUP	109
1	1W2638	OIL FILTER GROUP	115
1	9N6634	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR & FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W323 ENGINE ARRANGEMENT—Part 2
156.6 brake kW (210 bhp) Engine with R.H. Oil Level Gauge, Center Sump Oil Pan, R.H. Mounted PCV. Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1N3563	CONNECTING ROD AND PISTON GROUP	89
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	4N5866	FLYWHEEL HOUSING COVER GROUP	104
1	4N5870	FLYWHEEL HOUSING GROUP	104
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W324 ENGINE ARRANGEMENT—Part 1
146.2 brake kW (196 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

CONSISTS OF:			PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6641	ENGINE OIL LINES GROUP	115
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N521	ENGINE OIL COOLER GROUP	117
1	6N466	WATER LINES GROUP	120
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
GOVERNOR AND FUEL SYSTEM			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N6124	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	8N5904	GOVERNOR AND FUEL INJECTION PUMP GROUP	147

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W324 ENGINE ARRANGEMENT—Part 2
146.2 brake kW (196 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1W2200	CONNECTING ROD AND PISTON GROUP	89
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	9L7861	FLYWHEEL HOUSING COVER GROUP	105
1	9N529	FLYWHEEL HOUSING GROUP	103
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W325 ENGINE ARRANGEMENT—Part 1
130.5 brake kW (175 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6641	ENGINE OIL LINES GROUP	115
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
GOVERNOR AND FUEL SYSTEM			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR AND FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W325 ENGINE ARRANGEMENT—Part 2
130.5 brake kW (175 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		Consists of:	Page
CENTRAL STRUCTURE			
1	9N3761	Cylinder Block Group	80
1	9N728	Single Camshaft Group	88
1	9L6065	Cylinder Block Cover Group	81
1	9N6222	Crankshaft Group	84
8	1W2200	Connecting Rod and Piston Group	88
1	9N542	Crankshaft Seal Group	85
UPPER STRUCTURE			
1	9N730	Valve Mechanism Cover Group	93
1	9N1105	Cylinder Head Group	90
2	9N191	Lifting Group	94
1	9N487	Valve Mechanism Group	92
FRONT STRUCTURE			
1	9N560	Front Housing Cover Group	97
1	9N5590	Pulley and Damper Group	87
1	9N5211	Front Housing Group	96
1	9N5224	Engine Support Group	98
REAR STRUCTURE			
1	4N5866	Flywheel Housing Cover Group	104
1	9N5870	Flywheel Housing Group	104
LOWER STRUCTURE			
1	9N565	Oil Pan Group	107

1W326 ENGINE ARRANGEMENT—Part 1
130.5 brake kW (175 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and Sae No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6641	ENGINE OIL LINES GROUP	115
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
GOVERNOR AND FUEL SYSTEM			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR AND FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W326 ENGINE ARRANGEMENT—Part 2
130.5 brake kW (175 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE

		Consists of:	Page
CENTRAL STRUCTURE			
1	9N3761	Cylinder Block Group	80
1	9N728	Single Camshaft Group	88
1	9L6065	Cylinder Block Cover Group	81
1	9N6222	Crankshaft Group	84
8	1W2200	Connecting Rod and Piston Group	88
1	9N542	Crankshaft Seal Group	85
UPPER STRUCTURE			
1	9N730	Valve Mechanism Cover Group	93
1	9N1105	Cylinder Head Group	90
2	9N191	Lifting Group	94
1	9N487	Valve Mechanism Group	92
FRONT STRUCTURE			
1	9N560	Front Housing Cover Group	97
1	9N5590	Pulley and Damper Group	87
1	9N5211	Front Housing Group	96
1	9N5224	Engine Support Group	98
REAR STRUCTURE			
1	9L7861	Flywheel Housing Cover Group	105
1	9N529	Flywheel Housing Group	103
LOWER STRUCTURE			
1	9N565	Oil Pan Group	107

1W327 ENGINE ARRANGEMENT—Part 1
130.5 brake kW (175 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6632	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR & FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W327 ENGINE ARRANGEMENT—Part 2
130.5 brake kW (175 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1W2200	CONNECTING ROD AND PISTON GROUP	88
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	4N5866	FLYWHEEL HOUSING COVER GROUP	104
1	4N5870	FLYWHEEL HOUSING GROUP	104
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W328 ENGINE ARRANGEMENT—Part 1
130.5 brake kW (175 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6632	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR & FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W328 ENGINE ARRANGEMENT—Part 2
130.5 brake kW (175 bhp) Engien with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1W2200	CONNECTING ROD AND PISTON GROUP	88
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	9L7861	FLYWHEEL HOUSING COVER GROUP	105
1	9N529	FLYWHEEL HOUSING GROUP	103
LOWER STRUCTURE			
1	4N8853	OIL PAN GROUP	107

1W329 ENGINE ARRANGEMENT—Part 1
130.5 brake kW (175 bhp) Engine with R.H. Oil Level Gauge, Center Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	4N8855	OIL LEVEL GAUGE GROUP	109
1	1W2638	OIL FILTER GROUP	115
1	9N6634	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR & FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W329 ENGINE ARRANGEMENT—Part 2
130.5 brake kW (175 bhp) Engine with R.H. Oil Level Gauge, Center Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1W2200	CONNECTING ROD AND PISTON GROUP	88
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	4N5866	FLYWHEEL HOUSING COVER GROUP	104
1	4N5870	FLYWHEEL HOUSING GROUP	104
LOWER STRUCTURE			
1	4N8853	OIL PAN GROUP	107

1W330 ENGINE ARRANGEMENT—Part 1
130.5 brake kW (175 bhp) Engine with R.H. Oil Level Gauge, Center Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		Consists of:	Page
LUBRICATION SYSTEM			
1	4N8855	Oil Level Gauge Group	109
1	1W2638	Oil Filter Group	115
1	9N6634	Engine Oil Lines Group	116
1	1W2206	Oil Pump Group	113
COOLING SYSTEM			
1	9N729	Engine Oil Cooler Group	118
1	9N733	Water Lines Group	119
1	9N3654	Water Pump Group	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	Exhaust Manifold Group	137
1	9N555	Inlet Manifold Group	140
1	9N735	Positive Crankcase Ventilation Valve Group	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	Governor Control Group	178
1	9N740	Governor and Fuel Pump Drive Group	145
1	9L6925	Fuel System Fastener Group	191
1	4N5868	Fuel Filter Group	188
1	9N435	Fuel Filter Lines Group	182
1	9N3880	Fuel Injection Lines Group	180
1	4N4314	Fuel Priming Pump Group	190
1	9N3757	Governor & Fuel Injection Pump Group	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W330 ENGINE ARRANGEMENT—Part 2
130.5 brake kW (175 bhp) Engine with R.H. Oil Level Gauge, Center Sump Oil Pan R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		Consists of:	Page
CENTRAL STRUCTURE			
1	9N3761	Cylinder Block Group	80
1	9N728	Single Camshaft Group	88
1	9L6065	Cylinder Block Cover Group	81
1	9N6222	Crankshaft Group	84
8	1N3563	Connecting Rod and Piston Group	89
1	9N542	Crankshaft Seal Group	85
UPPER STRUCTURE			
1	9N730	Valve Mechanism Cover Group	93
1	9N1105	Cylinder Head Group	90
2	9N191	Lifting Group	94
1	9N487	Valve Mechanism Group	92
FRONT STRUCTURE			
1	9N560	Front Housing Cover Group	97
1	9N5590	Pulley and Damper Group	87
1	9N5211	Front Housing Group	96
1	9N5224	Engine Support Group	98
REAR STRUCTURE			
1	9L7861	Flywheel Housing Cover Group	105
1	9N529	Flywheel Housing Group	103
LOWER STRUCTURE			
1	9N565	Oil Pan Group	107

1W333 ENGINE ARRANGEMENT—Part 1
156.6 brake kW (210 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6641	ENGINE OIL LINES GROUP	115
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N521	ENGINE OIL COOLER GROUP	117
1	6N466	WATER LINES GROUP	120
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	9N535	EXHAUST MANIFOLD GROUP	138
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR & FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W333 ENGINE ARRANGEMENT—Part 2
156.6 brake kW (210 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		Consists of:	Page
CENTRAL STRUCTURE			
1	9N3761	Cylinder Block Group	80
1	9N728	Single Camshaft Group	88
1	9L6065	Cylinder Block Cover Group	81
1	9N6222	Crankshaft Group	84
8	9N3538	Connecting Rod and Piston Group	88
1	9N542	Crankshaft Seal Group	85
UPPER STRUCTURE			
1	9N730	Valve Mechanism Cover Group	93
1	9N1105	Cylinder Head Group	90
2	9N191	Lifting Group	94
1	9N487	Valve Mechanism Group	92
FRONT STRUCTURE			
1	9N560	Front Housing Cover Group	97
1	9N5590	Pulley and Damper Group	87
1	9N5211	Front Housing Group	96
1	9N5224	Engine Support Group	98
REAR STRUCTURE			
1	9L7861	Flywheel Housing Cover Group	105
1	9N529	Flywheel Housing Group	103
LOWER STRUCTURE			
1	9N565	Oil Pan Group	107

1W334 ENGINE ARRANGEMENT—Part 1
156.6 brake kW (210 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6632	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	9N535	EXHAUST MANIFOLD GROUP	138
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR & FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W334 ENGINE ARRANGEMENT—Part 2
156.6 brake kW (210 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		Consists of:	Page
CENTRAL STRUCTURE			
1	9N3761	Cylinder Block Group	80
1	9N728	Single Camshaft Group	88
1	9L6065	Cylinder Block Cover Group	81
1	9N6222	Crankshaft Group	84
8	1N3563	Connecting Rod and Piston Group	89
1	9N542	Crankshaft Seal Group	85
UPPER STRUCTURE			
1	9N730	Valve Mechanism Cover Group	93
1	9N1105	Cylinder Head Group	90
2	9N191	Lifting Group	94
1	9N487	Valve Mechanism Group	92
FRONT STRUCTURE			
1	9N560	Front Housing Cover Group	97
1	9N5590	Pulley and Damper Group	87
1	9N5211	Front Housing Group	96
1	9N5224	Engine Support Group	98
REAR STRUCTURE			
1	9L7861	Flywheel Housing Cover Group	105
1	9N529	Flywheel Housing Group	103
LOWER STRUCTURE			
1	9N565	Oil Pan Group	107

1W335 ENGINE ARRANGEMENT—Part 1
156.6 brake kW (210 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6632	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N521	ENGINE OIL COOLER GROUP	117
1	6N466	WATER LINES GROUP	120
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	137
1	9N6124	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	8N5906	GOVERNOR & FUEL INJECTION PUMP GROUP	152

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W335 ENGINE ARRANGEMENT—Part 2
156.6 brake kW (210 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valv and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

CONSISTS OF:			PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	9N3538	CONNECTING ROD AND PISTON GROUP	88
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	9L7861	FLYWHEEL HOUSING COVER GROUP	105
1	9N529	FLYWHEEL HOUSING GROUP	103
LOWER STRUCTURE			
1	4N8853	OIL PAN GROUP	107

1W336 ENGINE ARRANGEMENT—Part 1
146.2 brake kW (196 bhp) Engine with R.H. Oil Level Gauge, Center Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	4N8855	OIL LEVEL GAUGE GROUP	109
1	1W2638	OIL FILTER GROUP	115
1	9N6634	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	9N535	EXHAUST MANIFOLD GROUP	138
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR & FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W336 ENGINE ARRANGEMENT—Part 2
146.2 brake kW (196 bhp) Engine with R.H. Oil Level Gauge, Center Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	9N3538	CONNECTING ROD AND PISTON GROUP	88
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	9L7861	FLYWHEEL HOUSING COVER GROUP	105
1	9N529	FLYWHEEL HOUSING GROUP	103
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W337 ENGINE ARRANGEMENT—Part 1
135 brake kW (181 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		Consists of:	Page
LUBRICATION SYSTEM			
1	9N2538	Oil Level Gauge Group	110
1	1W2638	Oil Filter Group	115
1	9N6641	Engine Oil Lines Group	115
1	1W2206	Oil Pump Group	113
COOLING SYSTEM			
1	9N729	Engine Oil Cooler Group	118
1	9N733	Water Lines Group	119
1	9N3654	Water Pump Group	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	Exhaust Manifold Group	137
1	9N555	Inlet Manifold Group	140
1	9N735	Positive Crankcase Ventilation Valve Group	144
GOVERNOR AND FUEL SYSTEM			
1	9L6743	Governor Control Group	178
1	9N740	Governor and Fuel Pump Drive Group	145
1	9L6925	Fuel System Fastener Group	191
1	4N5868	Fuel Filter Group	188
1	9N435	Fuel Filter Lines Group	182
1	9N3880	Fuel Injection Lines Group	180
1	4N4314	Fuel Priming Pump Group	190
1	8N1046	Governor and Fuel Injection Pump Group	148

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W337 ENGINE ARRANGEMENT—Part 2
135 brake kW (181 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valv and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1N3563	CONNECTING ROD AND PISTON GROUP	89
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	9L7861	FLYWHEEL HOUSING COVER GROUP	105
1	9N529	FLYWHEEL HOUSING GROUP	103
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W338 ENGINE ARRANGEMENT—Part 1
130.5 brake kW (175 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6632	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N521	ENGINE OIL COOLER GROUP	117
1	6N466	WATER LINES GROUP	120
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR & FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W338 ENGINE ARRANGEMENT—Part 2
130.5 brake kW (175 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and No. 2 Flyweel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1W2200	CONNECTING ROD AND PISTON GROUP	89
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	9L7861	FLYWHEEL HOUSING COVER GROUP	105
1	9N529	FLYWHEEL HOUSING GROUP	103
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W339 ENGINE ARRANGEMENT—Part 1
123.8 brake kW (166 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6632	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR & FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W339 ENGINE ARRANGEMENT—Part 2
123.8 brake kW (166 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valv and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1W2200	CONNECTING ROD AND PISTON GROUP	89
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	9L7861	FLYWHEEL HOUSING COVER GROUP	105
1	9N529	FLYWHEEL HOUSING GROUP	103
LOWER STRUCTURE			
1	4N8853	OIL PAN GROUP	107

1W340 ENGINE ARRANGEMENT—Part 1
119.3 brake kW (160 bhp) Engine with R.H. Oil Level Gauge, Center Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	4N8855	OIL LEVEL GAUGE GROUP	109
1	1W2638	OIL FILTER GROUP	115
1	9N6634	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	191
1	8N9280	GOVERNOR & FUEL INJECTION PUMP GROUP	153

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W340 ENGINE ARRANGEMENT—Part 2
119.3 brake kW (160 bhp) Engine with R.H. Oil Level Gauge Center Sump Oil Pan R.H. Mounted PCV Valve and SAE No.2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1W2200	CONNECTING ROD AND PISTON GROUP	89
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	9L7861	FLYWHEEL HOUSING COVER GROUP	105
1	9N529	FLYWHEEL HOUSING GROUP	103
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	105

1W341 ENGINE ARRANGEMENT—Part 1
115.6 brake kW (155 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6641	ENGINE OIL LINES GROUP	115
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
GOVERNOR AND FUEL SYSTEM			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	8N1041	GOVERNOR AND FUEL INJECTION PUMP GROUP	153

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W341 ENGINE ARRANGEMENT—Part 2
115.6 brake kW (155 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1W2200	CONNECTING ROD AND PISTON GROUP	89
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	4N5866	FLYWHEEL HOUSING COVER GROUP	104
1	4N5870	FLYWHEEL HOUSING GROUP	104
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W342 ENGINE ARRANGEMENT—Part 1
115.6 brake kW (155 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6641	ENGINE OIL LINES GROUP	115
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
GOVERNOR AND FUEL SYSTEM			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	8N1041	GOVERNOR AND FUEL INJECTION PUMP GROUP	153

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W342 ENGINE ARRANGEMENT—Part 2
115.6 brake kW (155 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERNG PARTS GIVI ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1W2200	CONNECTING ROD AND PISTON GROUP	89
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	4N5866	FLYWHEEL HOUSING COVER GROUP	104
1	4N5870	FLYWHEEL HOUSING GROUP	104
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W343 ENGINE ARRANGEMENT—Part 1
106 brake kW (142 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

CONSISTS OF:			PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6641	ENGINE OIL LINES GROUP	115
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	8N1046	GOVERNOR & FUEL INJECTION PUMP GROUP	148

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W343 ENGINE ARRANGEMENT—Part 2
106 brake kW (142 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1W2200	CONNECTING ROD AND PISTON GROUP	89
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	9L7861	FLYWHEEL HOUSING COVER GROUP	105
1	9N529	FLYWHEEL HOUSING GROUP	103
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W344 ENGINE ARRANGEMENT—Part 1
106 brake kW (142 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6632	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
FUEL SYSTEM AND GOVERNOR			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	8N1046	GOVERNOR & FUEL INJECTION PUMP GROUP	148

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W344 ENGINE ARRANGEMENT—Part 2
106 brake kW (142 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1W2200	CONNECTING ROD AND PISTON GROUP	89
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	4N5866	FLYWHEEL HOUSING COVER GROUP	104
1	4N5870	FLYWHEEL HOUSING GROUP	104
LOWER STRUCTURE			
1	9N565	OIL PAN GROUP	107

1W345 ENGINE ARRANGEMENT—Part 1
104.4 brake kW (140 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
LUBRICATION SYSTEM			
1	9N2538	OIL LEVEL GAUGE GROUP	110
1	1W2638	OIL FILTER GROUP	115
1	9N6641	ENGINE OIL LINES GROUP	115
1	1W2206	OIL PUMP GROUP	113
COOLING SYSTEM			
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
INTAKE AND EXHAUST SYSTEM			
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
GOVERNOR AND FUEL SYSTEM			
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	9N3757	GOVERNOR AND FUEL INJECTION PUMP GROUP	146

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W345 ENGINE ARRANGEMENT—Part 2
104.4 brake kW (140 bhp) Engine with Front Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
CENTRAL STRUCTURE			
1	9N3761	CYLINDER BLOCK GROUP	80
1	9N728	SINGLE CAMSHAFT GROUP	88
1	9L6065	CYLINDER BLOCK COVER GROUP	81
1	9N6222	CRANKSHAFT GROUP	84
8	1W2200	CONNECTING ROD AND PISTON GROUP	89
1	9N542	CRANKSHAFT SEAL GROUP	85
UPPER STRUCTURE			
1	9N730	VALVE MECHANISM COVER GROUP	93
1	9N1105	CYLINDER HEAD GROUP	90
2	9N191	LIFTING GROUP	94
1	9N487	VALVE MECHANISM GROUP	92
FRONT STRUCTURE			
1	9N560	FRONT HOUSING COVER GROUP	97
1	9N5590	PULLEY AND DAMPER GROUP	87
1	9N5211	FRONT HOUSING GROUP	96
1	9N5224	ENGINE SUPPORT GROUP	98
REAR STRUCTURE			
1	4N5866	FLYWHEEL HOUSING COVER GROUP	104
1	4N5870	FLYWHEEL HOUSING GROUP	104
LOWER STRUCTURE			
1	4N8853	OIL PAN GROUP	107

1W346 ENGINE ARRANGEMENT—Part 1
104.4 brake kW (140 bhp) Engine with R.H. Oil Level Gauge, Center Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

		CONSISTS OF:	PAGE
		LUBRICATION SYSTEM	
1	4N8855	OIL LEVEL GAUGE GROUP	109
1	1W2638	OIL FILTER GROUP	115
1	9N6634	ENGINE OIL LINES GROUP	116
1	1W2206	OIL PUMP GROUP	113
		COOLING SYSTEM	
1	9N729	ENGINE OIL COOLER GROUP	118
1	9N733	WATER LINES GROUP	119
1	9N3654	WATER PUMP GROUP	125
		INTAKE AND EXHAUST SYSTEM	
1	4N5875	EXHAUST MANIFOLD GROUP	137
1	9N555	INLET MANIFOLD GROUP	140
1	9N735	POSITIVE CRANKCASE VENTILATION VALVE GROUP	144
		FUEL SYSTEM AND GOVERNOR	
1	9L6743	GOVERNOR CONTROL GROUP	178
1	9N740	GOVERNOR AND FUEL PUMP DRIVE GROUP	145
1	9L6925	FUEL SYSTEM FASTENER GROUP	191
1	4N5868	FUEL FILTER GROUP	188
1	9N435	FUEL FILTER LINES GROUP	182
1	9N3880	FUEL INJECTION LINES GROUP	180
1	4N4314	FUEL PRIMING PUMP GROUP	190
1	8N9280	GOVERNOR & FUEL INJECTION PUMP GROUP	153

NOTE: REFER TO INDEX FOR PAGE LOCATION OF GASKET KITS

1W346 ENGINE ARRANGEMENT—Part 2
104.4 brake kW (140 bhp) Engine with R.H. Oil Level Gauge, Center Sump Oil Pan R.H. Mounted PCV Valve and SAE No. 3 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER

1	9N529	FLYWHEEL HOUSING GROUP	103
1	4N8850	FLYWHEEL GROUP	99
		LOWER STRUCTURE	
1	9N565	OIL PAN GROUP	107

1W347 ENGINE ARRANGEMENT—Part 1—For Clayson
107.4 brake kW (144 bhp) Engine with Rear Sump Oil Pan, R.H. Mounted PCV Valve and SAE No. 2 Flywheel Housing. NOTE: WHEN ORDERING PARTS GIVE ARRANGEMENT NUMBER AND SERIAL NUMBER