



4L4638 Radiator Assembly parts are shown on Page 77. Refer to chart shown on insert between Pages 68 and 69 for usage

6L3283 RADIATOR GROUP—High Capacity


Effective with Serial No. 62B1869



ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




4L5794 RADIATOR GROUP—High Capacity
4L4638 Radiator Assembly parts are shown on Page 77
Refer to Page 69 for usage



4L4673 RADIATOR ASSEMBLY


Part of 4L5793 Radiator Group shown on Page 74

SEE "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




4L4638 RADIATOR ASSEMBLY
Part of 4L5794 Radiator Group shown on Page 75


ATTACHMENTS




4L3801 BLOWER FAN AND DRIVE GROUP—33 inch—6 Blade
 Refer to Page 69 for usage



4L3798 BLOWER FAN AND DRIVE GROUP—40 inch—8 Blade
 Refer to Page 69 for usage




6L2334 BLOWER FAN AND DRIVE GROUP--33 INCH--6 BLADE




6L2336 BLOWER FAN AND DRIVE GROUP--40 INCH--8 BLADE

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




6L2333 SUCTION FAN AND DRIVE GROUP--33 INCH--6 BLADE




6L2335 SUCTION FAN AND DRIVE GROUP--40 INCH--8 BLADE

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




4L3799 SUCTION FAN AND DRIVE GROUP—33 inch—6 Blade
 Refer to Page 69 for usage




4L3797 SUCTION FAN AND DRIVE GROUP—40 inch—8 Blade
 Refer to Page 69 for usage

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




4L5800 RAW WATER PUMP AND DRIVE GROUP




4L5788 WATER PUMP ASSEMBLY
 Part of 4L5800 Raw Water Pump and Drive Group

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




5L8946 RAW WATER PUMP AND DRIVE GROUP
Effective with Serial No. 62B700
4L5788 Water Pump Assembly parts are shown on Page 80




5L8943 AUXILIARY DRIVE GROUP—R.H.—1.176:1 Ratio
Also part of 5L8946 Raw Water Pump and Drive Group

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




4L5836 AUXILIARY DRIVE GROUP—L.H.—Second Type



4L5788 WATER PUMP ASSEMBLY—Second Type


Part of 4L5800 and 6L3044 Raw Water Pump and Drive Groups shown on Page 80
 and on inserts between Pages 80 and 81




6L3044 RAW WATER PUMP AND DRIVE GROUP—Replaces 5L8946

Effective with Serial No. 62B700

4L5788 Water Pump Assembly parts are shown on Page 80




112044 RAW WATER PUMP AND DRIVE GROUP—Second Type



5L8946 RAW WATER PUMP AND DRIVE GROUP—Second Type


Effective with Serial No. 62B700

4L5788 Water Pump Assembly parts are shown on Page 80




5L8943 AUXILIARY DRIVE GROUP—R.H.—1.176:1 Ratio—Second Type

Also part of 5L8946 Raw Water Pump and Drive Group




4L5799 AUXILIARY DRIVE GROUP—R.H.—1.135:1 Ratio
Also part of 4L5800 Raw Water Pump and Drive Group




4L5836 AUXILIARY DRIVE GROUP—L.H.

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE



4L5798 PULLEY GROUP


For use with 4L5799 Auxiliary Drive Group shown on Page 81
Only separate parts serviced



2L774 EXHAUST FITTING GROUP


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE



4L3332 WATER COOLED EXHAUST MANIFOLD GROUP—First Type
 Serial No. 62B1 to 62B1014 inclusive


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




86513

4L3332 WATER COOLED EXHAUST MANIFOLD GROUP—Second Type
Serial No. 62B1 to 62B1014 inclusive


ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




6L1725 WATER COOLED EXHAUST MANIFOLD GROUP
Effective with Serial No. 62B1015



6L2912 WATER COOLED EXHAUST MANIFOLD GROUP
 Effective with Serial No. 62B1869




5L8601 EXHAUST FLANGE GROUP—6 Inch
Effective with Serial No. 62B1869



6L2927 EXHAUST ELBOW GROUP—6 Inch
Effective with Serial No. 62B1869


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



67731

4L5808 SURGE TANK GROUP
 For use with Heat Exchanger

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE





6L6415 EXPANSION TANK GROUP—Type 2

Effective with Serial No. 62B1869

FOR USE WITH HEAT EXCHANGER AND WATER COOLED MANIFOLD


6L6415 EXPANSION TANK GROUP
Effective with Serial No. 62B1869






90575

6L3924 EXPANSION TANK GROUP
Effective with Serial No. A2R1R49




6L3924 EXPANSION TANK GROUP--TYPE 2
 EFFECTIVE WITH SERIAL NO. 62B1869
 FOR USE WITH HEAT EXCHANGER



5L6414 SURGE TANK GROUP
 Effective with Serial No. 62B375
 For use with Heat Exchanger


ALWAYS GIVE SERIAL NUMBER



67218


7M8165 TURBOCHARGER ASSEMBLY

PERFORMANCE "CATRILLAR" PARTS



ATTACHMENT 3


7M8166 TURBOCHARGER ASSEMBLY



67220


7M8167 TURBOCHARGER ASSEMBLY

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




7M8168 TURBOCHARGER ASSEMBLY

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




8M1557 TURBOCHARGER ASSEMBLY




8M4781 TURBOCHARGER ASSEMBLY

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




9M6420 TURBOCHARGER ASSEMBLY



6L3004 TURBOCHARGER GROUP

Effective with Serial No. 62B1869


2S1885 Turbocharger Assembly parts are shown on insert between Pages 18 and 19




6L3004 TURBOCHARGER GROUP—Second Type

Effective with Serial No. 62B1869


9507A9 Turbocharger Assembly parts are shown between Pages 10 and 11.




5L6918 TURBOCHARGER OIL LINES AND VALVE GROUP—Field Installation
Serial No. 62B1 to 62B275 inclusive




6L2788 AIR CLEANER GROUP—2 Stage—Heavy Duty


6L2610 AIR CLEANER ASSEMBLY—Heavy Duty
Part of 6L2788 Air Cleaner Group




5L4214 AIR FILTER INDICATOR GROUP
For use with Two Stage, Dry Type Air Cleaner




6L3305 AIR CLEANER GROUP—2 Stage—Heavy Duty
Effective with Serial No. 62B1869
6L2610 Air Cleaner Assembly parts are shown on insert between Pages 84 and 85




6L2788 AIR CLEANER GROUP--2 STAGE--HEAVY DUTY--TYPE 2
SERIAL No. 62B1 TO 62B1868 INCLUSIVE, 6L2610 AIR CLEANER
PARTS ARE SHOWN BETWEEN PAGES 84 & 85




7L6784 AIR FILTER INDICATOR GROUP--REPLACES 5L2130
FOR USE WITH DRY TYPE AIR CLEANER

**4L4720 AIR CLEANER ASSEMBLY**


Note: This Assembly provides 50% more paper area and will provide longer element service life

**5L2130 AIR FILTER INDICATOR GROUP**

For use with dry type Air Cleaner




4L8382 PRECLEANER GROUP
For use with Dry Type Air Cleaner




5L4157 PRECLEANER GROUP
Note: This Group cannot be used with Hood and Dash

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




5L4622 PRECLEANER GROUP—Full View
For use with Hood and Dash




4L6190 SAFETY ALARM CONTACTOR GROUP

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE


"CATERPILLAR" D343 ENGINE




5L4157 PRECLEANER GROUP—Second Type
Cannot be used with Hood and Dash



4L6190 SAFETY ALARM CONTACTOR GROUP—Second Type




6L6789 AIR PRECLEANER GROUP--FULL VIEW
EFFECTIVE WITH SERIAL NO. 62B1869




4L4984 ETHER STARTING AID KIT

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE




4L7906 HOOD SIDE DOOR GROUP

For use with 4L7905 Hood and Dash Group shown on Page 88




4L7905 HOOD AND DASH GROUP




80134


4L7905 HOOD AND DASH GROUP—Part One—Second Type
Additional parts are shown on reverse side of this insert

4L7905 HOOD AND DASH GROUP—Part Two—Second Type
Additional parts are shown on front side of this insert






5L9894 INSTRUMENT GROUP—12 Volt





5L9895 INSTRUMENT GROUP—24 and 32 Volt




4L7905 HOOD AND DASH GROUP—Part One—Third Type

4L7905 HOOD AND DASH GROUP—Part Two—Third Type






4L5761 INSTRUMENT PANEL GROUP




3L6651 ELECTRIC TACHOMETER GROUP


For use with 4L5789 Tachometer Drive Group



3F9847 TACHOMETER DUAL DRIVE JOINT



4L5789 TACHOMETER DRIVE GROUP

1M5061 TACHOMETER DRIVE GROUP
Part of 4L5789 Tachometer Drive Group

"CAT" PERFORMANCE

PART NO.	DESCRIPTION	TYPE OF CONTROL							
		RIGHT HAND				LEFT HAND			
		POSITIVE LOCK	REMOTE CABLE	VERNIER	AIR ACTUATOR	POSITIVE LOCK	REMOTE CABLE	VERNIER	AIR ACTUATOR
3L8869	CONTROL GROUP					X	X		X
5L2518	CONTROL GROUP	X	X		X				
4L6804	MOUNTING GROUP					X	X	X	X
4L6811	LEVER GROUP		X	X			X	X	
4L7604	HANDLE GROUP			X				X	
4L9581	LINK GROUP			X				X	
2L6745	ACTUATOR GROUP				X				X
4L7531	SUPPORT ASSEMBLY				X				X
4L7522	SUPPORT			X					
3L2777	BRACKET					X			
4L9665	BRACKET						X		
4L6803	LEVER ASSEMBLY				X				
4L7600	LEVER								X
5L1859	CLIP		X						
4L7514	STRAP				X				X
1A302	SPRING		X			X			
—	HARDWARE - LIST A			X					
—	HARDWARE - LIST B				X				X

LIST A

2 - 1A2029 BOLT 3/8" x 1 1/8"

LIST B

2-1A2029 BOLT 3/8" x 1 1/8"

1-4B3388 BOLT 5/16" x 1 1/8"

4-L1351 BOLT 3/8" x 7/8"

2-S292 BOLT 3/8" x 1"

1-S509 BOLT 3/8" x 3/4"

5-3B4506 LOCKWASHER 3/8"

2-3B4607 COTTER 3/32" x 1/2"

1-5H7295 GASKET-GOVERNOR


1-4L7513 ROD-GOVERNOR CONTROL

1-4F1001 END-YOKE


2-2A4133-PIN-YOKE END

65274

GOVERNOR CONTROL CHART




3L8869 GOVERNOR CONTROL GROUP—L.H.
4L7604 Handle Group parts are shown on Page 94
Refer to Page 92 for usage




5L2518 GOVERNOR CONTROL GROUP—R.H.
4L7604 Handle Group parts are shown on Page 94
Refer to Page 92 for usage


ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE

**4L7604 HANDLE GROUP**

Also part of 3L8869 and 5L2518 Governor Control Groups shown on Page 93
Refer to Page 92 for usage


**4L6811 LEVER GROUP**

Refer to Page 92 for usage



2L6745 ACTUATOR GROUP


Refer to Page 92 for usage




4L9581 LINK GROUP

Refer to Page 92 for usage


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




4L6804 GOVERNOR CONTROL MOUNTING GROUP
Refer to Page 92 for usage




6L4424 GOVERNOR CONTROL MOUNTING GROUP—L.H.
Effective with Serial No. 62B1869



5L3693 GOVERNOR CONTROL GROUP—Remote Mounted
4L7604 Handle Group parts are shown on Page 94




5L4093 GOVERNOR CONVERSION GROUP—3% Regulation at 1500 R.P.M.




5L4092 GOVERNOR CONVERSION GROUP—3% Regulation at 1800 R.P.M.


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS




5L6130 TORQUE SPRING GROUP—1800 to 1900 R.P.M.
Only separate parts serviced



5L6131 TORQUE SPRING GROUP—2000 R.P.M.




5L4714 SERVO GOVERNOR CONVERSION GROUP




90174


5L4714 SERVO GOVERNOR CONVERSION GROUP—Second Type
Effective with Serial No. 62B423




3L6955 GOVERNOR CONVERSION GROUP—10% Regulation—Second Type



5L4714 SERVO GOVERNOR CONVERSION GROUP
Effective with Serial No. 62B423




3L6955 GOVERNOR CONVERSION GROUP—10% Regulation at 1200 R.P.M.




3L6954 GOVERNOR CONVERSION GROUP—10% Regulation at 1200-1300 R.P.M.


FOR THE "OUTER" PERFORMANCE




3L6953 GOVERNOR CONVERSION GROUP—10% Regulation at 1300-1400 R.P.M.



3L6951 GOVERNOR CONVERSION GROUP—10% Regulation at 1500 R.P.M.




3L6952 GOVERNOR CONVERSION GROUP—10% Regulation at 1500-1800 R.P.M.




3L6950 GOVERNOR CONVERSION GROUP—10% Regulation at 1700-1900 R.P.M.

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE

ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS





ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE



4L7537 WOODWARD GOVERNOR GROUP—Second Type

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE






6L2357 MANUAL SHUT-OFF GROUP

Part of 4L7537 Woodward Governor Group shown on Pages 102C and 102E


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



4L7537 WOODWARD GOVERNOR GROUP—Fourth Type

6L2357 Manual Shut-Off Group and 6L3015 Governor Assembly parts are shown on Pages 102D and 102F


ALWAYS GIVE SERIAL NUMBER WHEN ORDERING PARTS



6L3015 WOODWARD GOVERNOR ASSEMBLY

Part of 6L7537 Woodward Governor Group shown on Page 102F

ONLY "CATERPILLAR" PARTS GIVE "CATERPILLAR" PERFORMANCE



96677

7L2491 WOODWARD GOVERNOR DRIVE GROUP—Type I
6L2357 Manual Shut-Off Group parts are shown on Page 102D