


Air cleaner
Filtre d'air
Filtro dell'aria
Filtro de aire

Luftrenare
Luchtfilter
Воздушный фильтр
مرشح الهواء

510 0390 0150-22




Intake manifold
Tuyaux d'admission
Collettori di aspirazione
Tuberías de admisión

**Ingsugningsrör
Luchtaanzuigbuis
Впускной коллектор**

سورة الشفـفـط

سورة الشفـفـط


510 0391 0150-22




Intake manifold
Tuyaux d'admission
Collettori di aspirazione
Tuberías de admisión

Insgugningsrör
Luchtaanzuigbuis
Впускной коллектор
اسورة الشفط

510 0815 0150-22






Reguliergestänge
Injection pump linkage
Tringlerie de régulation
Tiranti di regolazione
Varillaje de regulación

Hastes de regulação
Reglerstang
Regelstang
Тяги регулятора топливного насоса
قضيب الضبط


510 0393 0150-29



Lunpresser
Air compressor
Compresseur d'air
Compressore
Compresor de aire

Compressor de ar
Luftkompressor
Luchtcompressor
Компрессор пневмотормозов
جهاز ضغط الهواء


510 0394 0150-33



Luftpresser
Air compressor
Compressure d'air
Compressore
Compresor de aire

Compressor de ar
Luftkompressor
Luchtcompressor
Компрессор пневмотормозов
جهاز ضغط الهواء


510 0816 0150-33



Armaturenkasten
 Instrument box
 Boîte d'instruments
 Pannello portastrumenti
 Caja de instrumentos

Caja de instrumentos
 Instrumentpanel
 Instrumenten-paneel
 Панель приборов
 صندوق المعدات


510 0395 0150-35



Kühlungsgebläse
Cooling air blower
Soufflante d'air de refroidissement
Soffiante
Ventilador

ventilator
Kylluftfläkt
Koelluchtventilator
Вентилятор системы охлаждения
مروحة الهواء البار


510 0396 0150-39



Kühlungsgebläse
Cooling air blower
Soufflante d'air de refroidissement
Soffiante
Ventilador

Kylluftfläkt
Koelluchtventilator
Вентилятор системы охлаждения
مروحة الهواء البارد


510 0397 0150-39



Cooling air blower
Soufflante d'air de refroidissement
Soffiante
Ventilador

Kylluftfläkt
Koelluchtventilator
Вентилятор системы охлаждения
مروحة الهواء البارد


510 0398 0150-39



Kühlungsgebläse
Cooling air blower
Soufflante d'air de refroidissement
Soffiante
Ventilador

Kylluftfläkt
Koelluchtventilator
Вентилятор системы охлаждения
مروحة الهواء البارد


510 0817 0150-39



Cooling air ducting
 Guidage d'air de refroidissement
 Conduzione d'aria refrigerante
 Conducción del aire refrigerante

Kylluftföring
 Koelluchtvoering
 Кожухи системы воздушного охлаждения
 توجيه هواء التبريد


510 0399 0150-40



Cooling air discharge duct
Evacuation d'air de refroidissement
Deflettore dell'aria
Desviación de aire refrigerante

Кулероводящая
Koelluchtafvoering
Воздухоотводящий кожух
اخراج هواء التبريد


510 0400 0150-40




Cooling air ducting
 Guidage d'air de refroidissement
 Conduzione d'aria refrigerante
 Conducción del aire refrigerante

Kylluftföring
 Koelluchtvoering
 Ножухи системы воздушного охлаждения
 توجيه هواء التبريد

510 0818 0150-40






Exhaust manifold
Tuyau d'échappement
Tubo di scarico
Tubo de escape

Avgasrör
Uitlaat-spruitstuk
Выпускной коллектор
ماسورة الهواء العادم


510 0401 0150-41



Exhaust manifold
Tuyau d'échappement
Tubo di scarico
Tubo de escape

Avgasror
Uitlaat-spruitstuk
Выпускной коллектор
ماسورة الهواء العادم


510 0402 0150-41



Turbocharger
 Turbo-compresseur de suralimentation
 Turbo-compressore a gas di scarico
 Turbo-sobrealimentador


Avgasturbo kompressor
 Afvoergassen-turbine
 Турбоагнетатель
 مروحة دفع العادم

510 04.03 0150-43




Generator
 Generator
 Génératrice
 Dinamo
 Dinamo

Generator
 Generator
 Dynamo
 Электрогенератор



510 0404 0150-44

1




Starter
 Starter
 Démarreur
 Motorino d'avviamento
 Arrancador

Arrancador
 Startmotor
 Startmotor
 Стартёр

الـمـحـركـة


510 0405 0150-44



Motorbefestigung
Engine mounting parts
Fixation du moteur
Accessori per fissaggio motore
Fijación del motor

Motorfästening
Motorbevestiging
Крепление двигателя
مثبتات المحرك

510 0406 0150-46





Elektrische Ausrüstung
Electrical equipment
Équipement électrique
Equipaggiamento elettrico
Equipo eléctrico

Equipamento elettrico
Elektrisk utrustning
Elektr. uitrusting
Электрооборудование

التجهيزات الكهربائية

510 0407 0150-48







Electrical equipment
 Equipement électrique
 Equipaggiamento elettrico
 Equipo eléctrico

Elektrisk utrustning
 Elektr. uitrustning
 Электрооборудование
 التجهيزات الكهربائية

510 04 09 0150-48







Dispositif de virage
Chiave viratore
Dispositivo de viraje

Tornirichtung
Устройство для прокручивания двигателя
جهاز التورن

510 0411 0150-50






Clutch / Coupling
Coupleur / Embrayage
Giunto
Acoplamiento

Koppling
Koppeling
Сцепление
التشبيك


510 0413 0150-52



Shut down device
Dispositif d'arrêt
Arresto
Dispositivo de parada

Anordning for transigring
Motorstop
Устройство для останова двигателя
إيقاف المحرك


510 0414 0150-56



Shut down device
Dispositif d'arrêt
Arresto
Dispositivo de parada

Anordning för fränslagning
Motorstop
Устройство для останова двигателя
إيقاف المحرك


510 0820 0150-56



v-belt guard
Couvre-courroie
Protezione per cinghie trapeziodali
Protección de correa trapezoidal

V-snaar-bescherming
Защитный кожух приводного ремня
غطاء حماية السيور



510 0415 0150-57



Intercooler
 Refroidisseur d' air de suralimentation
 Refr. aria sovral.
 Refrigerador para aire de sobrealimentación

Laddningsluftkylare
 Vulluchtkoeler
 Холодильник наддувочного воздуха
 مبرد هواء الشحن


510 0416 0150-58



Ladeluftkühler
Intercooler
Refroidisseur d' air de suralimentation
Refr. aria sovral.
Refrigerador para aire de sobrealimentación

Radiator do superalimentador
Laddningsluftkylare
Vulluchtkoeler
Холодильник наддувочного воздуха
مبرد هوا الشحن


510 0821 0150-58



Cooling air discharge duct
Evacuation d'air de refroidissement
Deflettore dell'aria
Desviación de aire refrigerante

Кулунтаведаре
Koelluchtafvoering
Воздухоотводящий кожух
إخراج هواء التبريد

510 0417 0150-61




Starting aid
Assistance de demarrage
Assistenza di avviamento
Piloto de arranque

Startnjaip
Starthulp
Устройство для облегчения пуска

مساعدة التوقيت


510 0418 0150-63



Exhaust brake
Frein d'échappement
Freno motore
Freno de escape

Avgas broms
Uitlaatrem
Моторный тормоз
فرملة ماسورة العادم


510 0419 0150-70



Heating system
Chauffage
Riscaldamento
Calefacción

Uppvärmning
Verwarming
Oöorpes
التهوية

510 0420 0150-75



Hydraulic pump
 Pompe hydraulique
 Pompa hidraulica
 Bomba hidráulica

Hydraulpump
 Hydraulische pomp
 Гидравлический насос
 مضخة الهيدروليكية

510 0421 0150-83

