






GOVERNOR - MECHANICAL
6-71 ENGINE (12.5120)



[illegible]



FUEL

FUEL LINES

12.0420 LINE - Fuel

60-65 1 5126336 6-71, 6V, 8V-71 --- Fuel return cross over

12.0440 BRACKET - Fuel Line

62-65 1 5124631 6-71 ----- Extension elbow

12.0450 BRACKET - Fuel Line Junction

62-64 1 5114622 6-71, 6V, 8V-71 --- Fuel manifold and return line junction. Repl 5188634

12.0510 CONNECTOR - Fuel Manifold

60-65 AR 5117369 6-71, 6V, 8V-71 --- W/integral fuel manifold

12.0512 CONNECTOR - Fuel Lines

62-64 1 5188635 6-71 ----- Fuel return line to junction brkt.

12.0520 ELBOW - Fuel Line

60-65 1 5128927 6-71, 6V, 8V-71 --- .08. Restricted 0.080

60-64 1 5112892 6-71, 6V, 8V-71 --- .11. Restricted 0.106

12.0540 EXTENSION - Engine Fuel Outlet Manifold Elbow

60-65 1 5128522 6V, 8V-71 -----

63-65 1 5129845 6-71 ----- Repl 5123074

12.0655 PLUG - Fuel Manifold

60-65 AR 5121182 6-71, 6V, 8V-71 --- 1/4 hex socket pipe. Repl 5125237

12.0770 TEE - Fuel Line

60-63 1 5124232 6V, 8V-71 ----- Fuel return crossover line

12.0800 WASHER - Fuel Manifold Connector

60-65 AR 5125108 6-71, 6V, 8V-71 --- W/integral fuel manifold

FUEL PUMP

12.1610 PUMP - Fuel

62-65 1 5184532 6-71 ----- Gear type

60-65 1 5184531 6V, 8V-71 ----- Gear type

12.1612 KIT - Repair, Fuel Pump

60-65 1 5195078 6-71, 6V, 8V-71 ---

12.1630 BOLT - Fuel Pump To Engine

60-65 3 5118219 6-71, 6V, 8V-71 --- Incl seal washer. 5/16-18 X 7/8

12.1655 COVER - Fuel Pump

60-65 1 5174962 6-71, 6V, 8V-71 --- Bolt 1/4-20 X 3/4. Pin 1/4 X 5/8

12.1660 DISC - Fuel Pump Coupling

60-65 1 5154401 6-71, 6V, 8V-71 --- Part of blower assy. Bolt 1/2-20 X 1-1/4

12.1680 FORK - Fuel Pump Coupling

60-65 1 5150199 6-71, 6V, 8V-71 ---

FUEL

12.1690 GASKET - Fuel Pump			
60-65	1	5150193	6-71, 6V, 8V-71 ---
12.1705 GASKET - Fuel Pump Retaining Screw			
60-65	1	5161003	6-71, 6V, 8V-71 ---
12.1715 GEAR - Fuel Pump			
60-65	2	5174975	6-71, 6V, 8V-71 ---
12.1723 PLUG - Fuel Pump			
60-65	2	5661400	6-71, 6V, 8V-71 ---
12.1725 PLUG - Fuel Pump Valve			
60-65	1	5174971	6-71, 6V, 8V-71 ---
12.1750 SEAL - Oil, Fuel Pump			
60-65	2	5230007	6-71, 6V, 8V-71 ---
12.1753 SHAFT - Driven, Fuel Pump			
60-65	1	5181747	6-71, 6V, 8V-71 --- Gear
12.1757 SHAFT - Drive, Fuel Pump			
60-65	1	5181746	6-71, 6V, 8V-71 --- Incl gear
60-65	1	5178700	6-71, 6V, 8V-71 --- Shaft only
12.1759 SPACER - Fuel Pump Drive			
60-65	1	5117778	6V, 8V-71 -----
12.1770 SPRING - Fuel Pump Valve			
60-65	1	5184530	6-71, 6V, 8V-71 ---
12.1790 VALVE - Fuel Pump			
60-65	1	5174973	6-71, 6V, 8V-71 ---
12.1810 WASHER - Fuel Pump Lock Bolt			
60-65	1	5154398	6-71, 6V, 8V-71 ---
BLOWER INLET			
12.4003 CAM - Blower Air Shut-off			
60-65	1	5122623	6-71, 6V, 8V-71 --- Valve release
12.4026 HANDLE - Blower Air Shut-off Cam Pin			
60-64	1	5114974	6V, 8V-71 -----
12.4030 HOUSING - Blower Air Inlet			
63-65	1	5118166	6-71 ----- Incl valve, shaft spring & washer
12.4031 LATCH - Blower Air Shut-off Handle			
60-64	1	5114727	6-71, 6V, 8V-71 --- Pin 1/8 X 1-1/2 SLTD spring
12.4100 PLATE - Blower Air Inlet Shut-off Valve Striker			
63-65	1	5155482	6-71 -----

FUEL

12. 4130 SEAL - Blower Air Inlet Shut-off Valve Shaft

60-65 2 5182977 6-71, 6V, 8V-71 --- Ring

12. 4140 SHAFT - Blower Air Inlet Shut-off Valve

62-65 1 5128593 6-71 ----- Pin 1/8 X 5/8 SLTD spring. Repl 5112971

12. 4153 SPACER - Blower Air Inlet Shut-off Valve

60-65 1 5113633 6-71, 6V, 8V-71 --- Cam and latch. 17/64 ID, 7/16 OD X 7/8

12. 4170 VALVE - Blower Air Inlet Shut-off

62-65 2 5172031 6-71 -----

63-65 2 5182977 6-71 -----

GOVERNOR

12. 5120 GOVERNOR - Diesel Engine

60-63 1 5133824 6V-71 ----- Road Speed. Repl 5117768

62-63 1 5133687 6-71 ----- Mechanical. Repl 5117902

62-63 1 5119864 6-71 ----- Road Speed.

64-65 1 5111200 6-71 ----- Mechanical.

60-65 1 5133687 6V, 8V-71 ----- Mechanical. Repl 5117902

12. 5128 BEARING - Governor Operating Lever

60-65 2 442629 6V, 8V-71 ----- #B-660-H

12. 5130 BEARING - Governor Operating Shaft

60-64 1 457187 6V, 8V-71 ----- Mechanical

60-65 1 954987 6V, 8V-71 -----

65 1 9420900 6V, 8V-71 ----- Upper

12. 5140 BEARING - Governor Throttle Shaft

60-65 2 148444 6-71 ----- #B-88-OH. Mechanical

12. 5150 BEARING - Governor Weight Shaft

60-65 1 954716 All models ----- #H-20301. End. Mechanical

60-65 1 451905 All models ----- #6824. Thrust. Mechanical

12. 5160 BOLT - Governor Housing Cover

60-65 2 5183701 6V, 8V-71 -----

12. 5170 BOLT - Governor To Blower

60-65 6 5118219 All models ----- Incl seal washer. 5/8-18 X 7/8. 6V, 8V-71 prior to 1965.

12. 5172 BOLT - Governor To Cylinder Head

60-65 2 186601 All models ----- 6V, 8V-71 prior to 1965

12. 5178 BUSHING - Governor Operating Shaft

60-65 1 5188611 All models ----- Mechanical. 6V, 8V-71 prior to 1965

12. 5179 BUSHING - Governor Weight

60-65 1 5110665 All models ----- High speed

12. 5180 CAM - Governor

60-65 1 5110659 All models ----- Incl shaft. Top of cover

FUEL

12. 5190 CAP - Governor Low Speed Spring

60-65	1	5117931	6V, 8V-71 -----
62-65	1	5150899	6-71 ----- Mechanical

12. 5200 CAP - Governor

62-65	1	5183268	6-71 -----
60-65	1	5117297	6V, 8V-71 -----

12. 5210 CARRIER - Governor Weight

60-65	1	5184336	All models ----- Less shaft
60-65	1	5183624	6V, 8V-71 ----- Incl shaft less weights
62-65	1	5183630	6-71 ----- Incl shaft and weights. Mechanical
62-65	1	5183626	6-71 ----- Incl shaft less weights. Mechanical

12. 5226 CLIP - Lock, Governor Control Lever Shaft

60-65	1	5122263	6V, 8V-71 ----- Screw #10-24 X 7/16.
-------	---	---------	--------------------------------------

12. 5230 COVER - Governor Control Housing

60-65	1	5117898	6V, 8V-71 ----- Incl throttle shaft and shut down shaft
62-65	1	5110652	6-71 ----- Less shaft. Mechanical
62-65	1	5110654	6-71 ----- Incl throttle shaft and shut down shaft

12. 5240 COVER - Governor High Speed Spring

60-63	1	5123949	All models ----- Road speed governor
-------	---	---------	--------------------------------------

12. 5250 COVER - Governor Hole

60-65	AR	5150268	All models -----
-------	----	---------	------------------

12. 5260 COVER - Governor Weight Housing

60-65	1	5176837	All models ----- Mechanical. 6V, 8V-71 prior to 1965
-------	---	---------	--

12. 5265 ELBOW - Governor

62-65	1	5166265	6-71 -----
-------	---	---------	------------

12. 5270 FORK - Governor Operating

60-65	1	5185605	All models -----
-------	---	---------	------------------

12. 5280 GASKET - Governor Control Housing Cover

60-65	1	5117899	6V, 8V-71 -----
62-65	1	5150889	6-71 ----- Mechanical.

12. 5290 GASKET - Governor High Speed Spring Cover

60-65	1	5152944	All models ----- 2 req'd. w/road speed governor
-------	---	---------	---

12. 5300 GASKET - Governor Hole Cover

60-65	AR	5123812	All models ----- Repl 5150269
-------	----	---------	-------------------------------

12. 5310 GASKET - Governor Shaft Bearing Cap

60-65	1	5165221	All models ----- Mechanical
-------	---	---------	-----------------------------

12. 5320 GASKET - Governor To Blower

62-65	1	5150246	6-71 -----
60-65	1	5126499	6V, 8V-71 -----

12. 5330 GASKET - Governor To Cylinder Head

60-65	1	5123812	All models ----- Repl 5150269
-------	---	---------	-------------------------------

FUEL

12. 5340 GASKET - Governor Weight Housing			
62-65	1	5150890	6-71 ----- Mechanical.
12. 5345 GUIDE - Governor High Speed Spring			
60-64	1	5124551	All models -----
12. 5347 HOSE - Governor Control Link Cover Tube			
60-65	2	5124355	6V, 8V-71 -----
12. 5350 HOUSING - Governor Control			
60-65	1	5124426	6V, 8V-71 ----- Mechanical & road speed
62-65	1	5110754	6-71 ----- Incl operating shaft. Mechanical.
62-65	1	5183314	6-71 ----- Less operating shaft. Mechanical.
12. 5355 HOUSING - Governor Spring			
60-65	1	5182559	6-71, 6V, 8V-71 --- Mechanical.
60-64	1	5113868	All models ----- Road speed governor
12. 5360 HOUSING - Governor Weight			
62-65	1	5183612	6-71 ----- Incl carrier and bearing. Mechanical
62-65	1	5183286	6-71 ----- Less carrier. Mechanical
12. 5380 LEVER - Governor Differential			
62-65	1	5110666	6-71 ----- Incl pin. Mechanical
60-65	1	5117930	6V, 8V-71 ----- Incl pin
12. 5390 LEVER - Governor Operating			
62-64	1	5154422	6-71 ----- Mechanical
60-65	1	5122150	6V, 8V-71 ----- Incl bearing. Control link
65	1	5132747	6V, 8V-71 ----- On operating shaft
12. 5400 LEVER - Governor Shaft Control			
60-65	1	5126992	6V, 8V-71 ----- On engine
60-63	1	5154448	6V, 8V-71 ----- On governor
60-65	1	5183042	6V, 8V-71 -----
62-65	1	5186064	6-71 -----
62-65	1	5183042	6-71 ----- 1-3/4 C/L to C/L.
12. 5410 LINK - Control, Governor			
60-65	1	5117210	6V, 8V-71 ----- Operating lever.
60-65	1	5117191	6V, 8V-71 ----- Short
60-65	1	5117942	6V, 8V-71 ----- Long
62-65	1	5150996	6-71 ----- Short. Mechanical
12. 5413 NUT - Governor Buffer Screw			
65	1	5174286	6V, 8V-71 -----
12. 5415 NUT - Governor High Speed Adjustment			
62-65	1	5182558	6-71, 6V, 8V-71 --- Mechanical. 6V, 8V-71. Eff. w/1965
12. 5420 PIN - Dowel, Governor Weight Housing			
60-65	AR	5150942	All models -----
12. 5430 PIN - Governor Control Link			
60-65	1	5150265	All models -----

FUEL

12. 5440 PIN - Governor Differential Lever			
62-65	1	5110648	6-71 ----- Mechanical
60-65	1	5117929	6V, 8V-71 -----
12. 5450 PIN - Governor Fulcrum Lever			
62-65	1	5174428	6-71 ----- Mechanical
12. 5460 PIN - Governor Operating Lever			
60-65	1	5150943	All models -----
60-65	1	5122147	6V, 8V-71 ----- 5/16 X 2-9/16
60-65	1	5117693	6V, 8V-71 ----- 1/4-28 X 1
12. 5465 PIN - Governor Throttle Arm			
60-65	1	5117927	6V, 8V-71 -----
12. 5480 PIN - Governor Weight			
60-65	2	5183632	All models -----
12. 5485 PIN - Swivel, Governor Stop Lever Cable			
60-65	1	5161464	All models -----
12. 5487 PISTON - Governor High Speed Air Cylinder			
60-63	1	5125603	All models ----- Road speed governor
12. 5490 PLUNGER - Governor			
60-65	1	5182555	All models ----- Mechanical
60-63	1	5126135	All models ----- Road speed governor
12. 5500 RETAINER - Governor High Speed Spring			
60-65	1	5182557	All models ----- Mechanical
60-63	1	5113867	All models ----- Road speed governor
12. 5510 RETAINER - Governor Packing Washer			
60-65	1	5153060	All models ----- 33/64 ID X 1 OD X .0312. Mechanical
12. 5520 RISER - Governor			
60-65	1	5117193	6V, 8V-71 -----
62-65	1	5154503	6-71 ----- Mechanical
12. 5522 RING - Blocking, Governor Housing			
60-64	1	5127189	All models -----
12. 5523L RING - Retainer, Governor Operating Lever Pin			
60-65	2	274574	6V, 8V-71 -----
12. 5523M RING - Retaining, Governor Throttle Shaft			
60-65	1	5178581	All models -----
12. 5524 RING - Seal, Governor High Speed Piston			
60-63	1	5114167	All models ----- Road speed governor
12. 5524H RING - Seal, Governor Housing Cover			
60-65	1	5174429	All models ----- .463 ID X .062 thk

FUEL

12. 5540 SCREW - Adjusting, Governor

60-64	1	5150898	All models -----	
60-65	1	5182556	6V, 8V-71 -----	Low speed spring. Mechanical.
60-63	1	5124313	6-71, 6V-71 -----	Piston. Road speed governor.
60-63	1	5150891	6-71, 6V-71 -----	Low speed spring. Road speed governor.
65	1	5132962	6V, 8V-71 -----	Operating shaft.

12. 5550 SCREW - Governor Buffer Spring

62-65	1	5152987	6-71 -----	Repl 5119852.
60-65	1	5117952	6V, 8V-71 -----	Incl pin. Repl 5126664.

12. 5570 SCREW - Governor Weight Shaft Bearing Retainer

60-65	1	5150884	All models -----	
-------	---	---------	------------------	--

12. 5580 SCREW - Set, Governor Weight

60-65	2	5151059	All models -----	Mechanical. 6V, 8V-71 prior to 1965.
-------	---	---------	------------------	--------------------------------------

12. 5587 SEAL - Governor

60-65	2	5182977	All models -----	. 312 ID X . 568 OD
-------	---	---------	------------------	---------------------

12. 5590 SEAT - Governor Low Speed Spring

60-65	1	5150892	All models -----	
-------	---	---------	------------------	--

12. 5610 SHAFT - Governor Operating

60-65	1	5122157	6C, 8V-71 -----	Operating link.
62-65	1	5158820	6-71 -----	Incl fork and lever.
62-65	1	5154438	6-71 -----	Incl lever less fork.
62-64	1	5154435	6-71 -----	Mechanical. Shaft only.
60-65	1	5133795	6V, 8V-71 -----	Incl lever, less fork. Repl 5117925. Also use 5133686 spacer prior to 1965.
65	1	5133680	6V, 8V-71 -----	Less lever and fork.

12. 5620 SHAFT - Governor Throttle

60-65	1	5117928	6V, 8V-71 -----	Incl arm and pins.
62-65	1	5110661	6-71 -----	Incl spacer. When repl 5110711 use 2-5153060 retainer, 1-5174429 ring.

12. 5630 SHAFT - Governor Weight

60-65	1	5150923	6V, 8V-71 -----	Shaft only.
62-65	1	5150925	6-71 -----	Shaft only.

12. 5635 SHIM - Governor High Speed Piston

60-63	10	5123922	6-71, 6V-71 -----	. 010. Road speed governor.
60-63	4	5123923	6-71, 6V-71 -----	. 100. Road speed governor.

12. 5646 SLEEVE - Governor High Speed Piston

60-63	1	5125604	All models -----	Road speed governor. When repl 5113871 use 1-5125603 piston, 10-5123922 shims, 4-5123923 shims.
-------	---	---------	------------------	---

12. 5650 SPACER - Governor

62-65	1	5150512	6-71 -----	
65	1	5133686	6V, 8V-71 -----	Operating lever shaft.

12. 5660 SPRING - Governor

62-65	1	5183704	6-71 -----	Two yellow stripes. Mechanical. Low speed.
60-65	1	5151604	6V, 8V-71 -----	Green stripe. Low speed.
60-64	1	5125096	6V, 8V-71 -----	Two yellow stripes. High speed. Road speed governor.
60-65	1	5122269	6V, 8V-71 -----	Wide brown stripe. Mechanical.

FUEL

12. 5660 SPRING - Governor - Cont'd.

62-65	1	5111196	6-71	-----	Blue stripe. Mechanical. High speed.
62-63	1	5177082	6-71	-----	Buffer spring screw. Part of 5119852.
62-65	1	5152929	6-71	-----	Buffer spring screw. Part of 5152987 screw.
62-63	1	5119570	6-71	-----	One red and yellow stripe. Road speed governor. High speed.

12. 5665 SUPPORT - Governor Stop Control Wire

62-65	1	5184200	6-71	-----	
-------	---	---------	------	-------	--

12. 5666 TUBE - Governor Control Link Cover

60-65	2	5124333	6V, 8V-71	-----	At engine.
60-65	2	5124332	6V, 8V-71	-----	At governor weight housing.

12. 5667 TUBE - Oil, Governor Weight Housing

62-65	1	5176834	6-71	-----	Oil supply.
-------	---	---------	------	-------	-------------

12. 5678 WASHER - Governor Hole Cover Bolt

60-65	12	5179709	6V, 8V-71	-----	
-------	----	---------	-----------	-------	--

12. 5680 WASHER - Governor Lever Pin

60-65	2	5150941	All models	-----	
-------	---	---------	------------	-------	--

12. 5690 WASHER - Governor Lever Shaft

60-65	1	5150941	All models	-----	Diff. lever
60-65	4	5151487	All models	-----	Weight shaft

12. 5700 WASHER - Governor Operating Shaft Bearing

60-64	1	5159080	All models	-----	
-------	---	---------	------------	-------	--

12. 5705 WASHER - Governor Stop Control Wire Swivel Pin

60-65	1	5150941	All models	-----	Pin to lever. 5/16 ID, 35/64 OD X 1/16
-------	---	---------	------------	-------	--

12. 5708 WASHER - Governor To Blower Bolt

60-65	2	5155596	All models	-----	Repl 274854
-------	---	---------	------------	-------	-------------

12. 5710 WASHER - Governor Weight Pin

65	2	5150885	6V, 8V-71	-----	
----	---	---------	-----------	-------	--

12. 5720 WASHER - Governor Weight Shaft Bearing

60-65	1	5150897	All models	-----	
60-65	1	5150941	All models	-----	Ret. screw

12. 5730 WASHER - Packing, Governor Housing Cover

60-65	1	5176557	6V, 8V-71	-----	
-------	---	---------	-----------	-------	--

12. 5735 WEIGHT - Governor

62-65	1	5183631	6-71	-----	Low speed.
60-65	1	5117737	All models	-----	Incl bushing. High speed
60-65	2	5122162	6V, 8V-71	-----	Low speed.

12. 5740 WEIGHT SET - Governor

62-65	1	5196937	6-71	-----	Repl 5193214. W/6-71 Eng.
-------	---	---------	------	-------	---------------------------

FUEL

FUEL INJECTOR

12. 6120 INJECTOR - Fuel

60-61	8	5228521	8V-71 -----	#S55. 55 MM.
60-63	6	5228522	6-71, 6V, 8V-71 ---	#S60. 60 MM.
64-65	8	5228785	8V-71 -----	N55. 55 MM. Has line under letters GM on tag. Repl 5228655 which has no line.
64-65	AR	5228760	6-71, 6V, 8V-71 ---	N60. 60 MM. Has line under letters GM on tag. Repl 5228610 which has no line.
64-65	6	5228765	6-71 -----	N65. 65 MM. Has line under letters GM on tag. Repl 5228685 which has no line.

12. 6130 KIT - Injector Overhaul

60-63	1	5193221	All models -----	W/S55, S60 injectors. Incl 2 gaskets, 1 ring and 2 elements.
64-65	1	5228701	All models -----	W/N55, N60, N65 injectors. Incl. 2 gaskets, 1 seal, 2 elements and 2 caps.

12. 6135 KIT - Fuel Injector Valve

60-63	AR	5228313	All models -----	W/S55, S60 injectors. Incl 1 valve, 1 seat and 1 spring.
64	AR	5228706	All models -----	W/N55, N60, N65 injectors w/out line under letters GM on tag. Incl 1 spring and 1 seat.
64-65	AR	5228769	6-71, 6V, 8V-71 ---	W/N55, N60, N65 injectors w/line under letters GM on tag.

12. 6140 KIT - Repair, Fuel Injector Spray Tip And Valve

60-63	AR	5228491	All models -----	W/S55, S60 injectors. Incl 1 stop, 1 spring, 1 tip and 1 valve.
-------	----	---------	------------------	---

12. 6150 BODY - Fuel Injector

60-63	AR	5228509	All models -----	W/S55, S60 injectors. 1 req'd. per injector.
64-65	AR	5228583	All models -----	W/N55, N60, N65 injector. 1 req'd. per injector.

12. 6160 BRACKET - Fuel Injector Rack Control Tube

60-65	2	5120687	6V, 8V-71 -----	Incl bearing and cover.
-------	---	---------	-----------------	-------------------------

12. 6165 CAGE - Fuel Injector Check Valve

64-65	AR	5228696	All models -----	W/N55, N60 & N65 injector, 1 req'd. per injector. Repl 5228664.
-------	----	---------	------------------	---

12. 6167 CAGE - Fuel Injector Valve

60-63	AR	5228294	All models -----	W/S55, S60 injectors. 1 req'd. per injector
64-65	AR	5228594	All models -----	W/N55, N60 & N65 injector, 1 req'd. per injector

12. 6170 CAP - Fuel Injector Filter Element

60-63	AR	5226413	All models -----	W/S55, S60 injectors. 2 req'd. per injector.
64-65	AR	5228588	All models -----	W/N55, N60 & N65 injectors. 2 req'd. per injector.

12. 6180 CLAMP - Fuel Injector

60-65	AR	5121259	All models -----	1 req'd. per injector.
-------	----	---------	------------------	------------------------

12. 6183 CONTAINER - Fuel Injector

60-64	AR	5197725	All models -----	1 req'd. per injector. Repl 5193171.
-------	----	---------	------------------	--------------------------------------

12. 6190 DEFLECTOR - Spill, Fuel Injector

60-65	AR	5228109	All models -----	1 req'd. per injector
-------	----	---------	------------------	-----------------------

12. 6200 ELEMENT - Filter, Fuel Injector

60-63	AR	5228013	All models -----	W/S55, S60 injector. 2 req'd. per injector.
60-65	AR	5228587	All models -----	W/N55, N60 and N65 injector. 2 req'd. per injector.

FUEL

12. 6210 FOLLOWER - Fuel Injector			
60-65	AR	5228104	All models ----- 1 req'd. per injector
12. 6220 GASKET - Fuel Injector Filter Element Cap			
60-65	AR	5226186	All models ----- 2 req'd. per injector
12. 6230 GEAR - Fuel Injector Rack			
60-65	AR	5226400	All models ----- 1 req'd. per injector
12. 6250 LEVER - Fuel Injector Control Tube			
60-65	2	5150263	All models ----- 1 req'd. w/6-71.
12. 6260 LEVER - Fuel Injector Rack Control			
60-65	AR	5115322	All models ----- Lever only. 1 req'd. per injector
12. 6270 NUT - Fuel Injector			
60-63	AR	5228102	All models ----- W/S55, S60 injector. 1 req'd. per injector.
64-65	AR	5228601	All models ----- W/N55, N60 & N65 injector. 1 req'd. per injector.
12. 6273 PIN - Fuel Injector Body			
60-65	AR	5226416	All models ----- 1 req'd. per injector.
12. 6275 PIN - Fuel Injector Control Tube End			
60-65	1	5150259	All models ----- Short. 2 req'd. 6V, 8V-71.
12. 6285 PIN - Fuel Injector Plunger			
60-65	AR	5226393	All models ----- 1 req'd. per injector
12. 6290 PIN - Injector Follower Stop			
60-65	AR	5226608	All models ----- 1 req'd. per injector. Repl 5228512.
12. 6297 PLUG - Fuel Injector Body			
60-65	AR	5226912	All models ----- 1 req'd. per injector
12. 6300 PLUNGER - Fuel Injector			
60-63	AR	5228528	8V-71 ----- W/S55 injector. Incl. bushing & pin. 1 req'd. per injector.
60-63	AR	5228306	All models ----- W/S60 injectors. Incl. bushing & pin. 1 req'd. per injector except 1960, 1 model DF, DFW71
64-65	AR	5228668	8V-71 ----- W/N55 injector. 1 req'd. per injector.
64-65	AR	5228656	6-71, 6V-71 ----- W/N60 injector. 1 req'd. per injector.
64-65	AR	5228658	All models ----- W/N65 injector. 1 req'd. per injector.
12. 6310 RACK - Fuel Injector			
60-65	AR	5226719	All models ----- Incl. coupling. 1 req'd. per injector.
12. 6320 RETAINER - Fuel Injector			
60-63	AR	5226567	All models ----- W/S55, S60 injector.
64-65	AR	5228586	All models ----- W/N55, N60 & N65 injector. 1 req'd. per injector
12. 6330 RING - Seal, Fuel Injector Body			
60-65	AR	5226564	All models ----- 1 req'd. per injector
12. 6340 RING - Seal, Fuel Injector Hole Tube			
60-65	AR	5160037	All models ----- 1 req'd. per injector

FUEL

12. 6350 SCREW - Adjusting, Injector Rack Control Lever

60-65 AR 5176228 All models ----- 2 req'd. per lever.

12. 6355 SEAT - Fuel Injector Spray Tip Valve

60-63 AR 5228106 All models ----- W/S55, S60 injector. 1 req'd. per injector.
 64 AR 5228597 All models ----- W/N55, N60 & N65 injector w/out line under letters GM on tag. 1 req'd. per injector.
 64-65 AR 5228766 6-71, 6V, 8V-71 --- W/N55, N60, N65 injector w/line under letters GM on tag. 1 req'd. per injector.

12. 6370 SPACER - Fuel Injector Control Tube Lever

60-65 2 5150843 All models -----

12. 6390 SPRING - Fuel Injector Control Tube

60-65 2 5124142 6V, 8V-71 -----
 62-65 1 5115922 6-71 -----

12. 6400 SPRING - Fuel Injector Filter Element

60-64 AR 5226415 All models ----- 2 req'd. per injector

12. 6410 SPRING - Fuel Injector Plunger

60-65 1 5228511 All models ----- 1 req'd. per injector. W/S or N type injector

12. 6420 SPRING - Fuel Injector Spray Tip Valve

60-63 AR 5227210 All models ----- W/S55, S60 injector. 1 req'd. per injector
 64-65 AR 5228596 All models ----- W/N55, N60 & N65 injector. 1 req'd. per injector

12. 6430 STOP - Fuel Injector Valve

60-64 AR 5227318 All models ----- 1 req'd. per injector

12. 6445 TAG - Identification, Fuel Injector

60-61 8 5228529 8V-71 ----- #S55.
 60-63 AR 5228518 All models ----- #S60.1 Req'd per injector.
 64 8 5228673 8V-71 ----- N55 injector w/out line under letters GM.
 64 AR 5228603 6-71, 6V, 8V-71 --- N60 injector w/out line under letters GM.
 64 6 5228674 6-71 ----- N65 injector w/out line under letters GM.
 64-65 8 5228776 8V-71 ----- N55 injector w/line under letters GM.
 64-65 AR 5228779 6-71, 6V, 8V-71 --- N60 injector w/line under letters GM.
 64-65 6 5228781 6-71 ----- N65 injector w/line under letters GM.

12. 6450 TIP - Spray, Fuel Injector

60-63 AR 5228473 All models ----- W/S55, S60 injector. 1 req'd. per injector
 64-65 AR 5228768 All models ----- W/N55, N60 & N65 injector. Also use 1-5228766 seat for injectors w/out line under letter GM on tag. Repl. 5228591.

12. 6460 TUBE - Fuel Injector Rack Control

60-65 1 5197425 6V-71 ----- Incl bracket. RH. Repl 5196565.
 60-65 1 5197426 6V-71 ----- Incl bracket. LH. Repl 5196566.
 60-65 1 5197427 6V-71 ----- Incl bracket. RH. Repl 5196567.
 60-65 1 5197428 6V-71 ----- Incl bracket. LH. Repl 5196568.
 62-65 1 5195527 6-71 ----- Incl lever.

12. 6470 TUBE - Fuel Injector Hole

60-65 AR 5150041 All models ----- 1 req'd. per injector.

12. 6480 VALVE - Check, Fuel Injector Spray Tip

60-63 AR 5226411 All models ----- W/S55, S60 injector. Flat. 1 req'd. per injector.

FUEL

12. 6480 VALVE - Check, Fuel Injector Spray Tip - Cont'd.

64-65 AR 5228694 All models ----- W/N55, N60 & N65 injector. 1 req'd. per injector.
Repl 5228663, 5228746.

12. 6500 WASHER - Fuel Injector Clamp

60-65 AR 5150250 All models ----- 1 req'd. per injector. W/6-71. 2 req'd. per injector
w/6V, 8V-71.

NUMERICAL INDEX

PART NO.	GROUP NO.	PART NO.	GROUP NO.	PART NO.	GROUP NO.	PART NO.	GROUP NO.	PART NO.	GROUP NO.
030205	07.2790	1114019	07.2000	1915717	07.6150	1945514	07.2290	5109976	08.3005C
030707	07.3270	1114068	07.2000	1916272	07.2435	1945517	07.2520	5110083	08.3295C
032898	07.2777	1114105	07.2000	1916320	07.2296	1945518	07.2520	5110306	08.1540C
037077	07.3720	1114107	07.2000	1916439	07.2830	1945740	07.3290	5110648	12.5440
053688	08.2970C	1119879	07.5960	1916439	07.2830	1945924	07.6030	5110652	12.5230
103647	08.4403C	1543853	08.3070C	1916439	07.2830	1945928	07.3290	5110654	12.5230
103905	08.3705C	1543857	08.3230C	1916529	07.6142	1945930	07.3290	5110659	12.5180
105451	08.0470C	1544255	08.2995C	1917241	07.2830	1946003	07.6190	5110661	12.5620
114631	08.2806C	1555476	08.2940C	1918047	07.2623	1946095	07.2330	5110665	12.5179
117244	08.0510C	1835457	07.3320	1918687	07.2350	1946406	07.3150	5110666	12.5380
117244	08.0510C	1847238	07.6220	1918690	07.2115	1946631	07.3310	5110754	12.5350
117244	08.1640C	1849235	07.6220	1918714	07.2270	1946753	07.2520	5110799	08.2790C
118536	06.2130	1858490	07.2765	1919849	07.2540	1946754	07.2520	5110894	08.2050C
118831	07.2570	1861076	07.6230	1919850	07.2430	1946765	07.2115	5111196	12.5660
118831	08.0510C	1861785	07.2670	1919851	07.2830	1947262	07.2345	5111200	12.5120
124549	08.3705C	1861791	07.2790	1919853	07.2220	1948274	07.3460	5111332	06.1830
141346	08.1815C	1866760	07.3460	1920676	07.3506	1948276	07.3310	5111337	08.0760C
142507	06.2250	1867938	07.3590	1920677	07.3506	1948284	07.3600	5111338	08.0740C
143194	07.2570	1868835	07.2350	1920680	07.3609	1948394	07.3350	5111339	08.0820C
143968	08.0510C	1872057	07.3720	1920691	07.3268	1948396	07.3065	5111339	08.1132C
143968	08.0660C	1872411	07.3110	1920729	07.3240	1948400	07.3350	5111340	08.0850C
143980	08.0510C	1872618	07.3720	1920730	07.3240	1948401	07.3320	5111343	08.0850C
148444	12.5140	1874495	07.3720	1921660	07.2130	1948402	07.3480	5111369	08.4953C
180122	08.2010C	1874846	07.2520	1921805	07.2435	1948403	07.3250	5111422	08.1220C
181636	08.1490C	1874847	07.2530	1922457	07.2790	1948407	07.3720	5111422	08.1220C
181643	08.2160C	1874848	07.2520	1923484	07.2130	1948533	07.2490	5111423	08.1290C
186601	12.5172	1874851	07.2520	1923484	07.2130	1948536	07.2615	5111424	08.1430C
186624	08.3490C	1877962	07.2130	1923837	07.3506	1948537	07.2615	5111715	08.2640C
186625	08.3505C	1878503	07.6010	1923935	07.6230	1948656	07.6099	5111798	08.0510C
186627	08.1495C	1880642	07.2430	1926461	07.3060	1948917	07.3290	5111798	08.2095C
186650	08.4400C	1902746	07.3720	1926464	07.3290	1949109	07.2210	5111881	08.2585C
186677	08.3525C	1904370	07.3580	1926465	07.3250	1949594	07.3480	5112373	08.3050C
186679	08.2010C	1904982	07.2460	1926968	07.6230	1952015	07.3290	5112390	08.1580C
186689	08.2190C	1904982	07.2590	1927964	07.3620	1952020	07.3320	5112401	08.4420C
187424	07.3580	1904983	07.2460	1928032	07.3080	1952037	07.3060	5112528	06.1830
189307	08.2532C	1904983	07.2590	1929232	07.3395	1954861	07.6050	5112892	12.0520
190770	08.2010C	1904998	07.6220	1929959	07.3574	1954873	07.3460	5112899	08.5110C
274574	12.5523L	1905125	07.3720	1930611	07.2615	1955303	07.2570	5112904	08.2855C
274746	06.2290	1906046	07.2115	1930611	07.6142	1955358	07.2630	5113061	07.3300
442629	12.5128	1906053	07.6080	1931673	07.6090	1955376	07.2006	5113061	08.2040C
443344	07.3430	1906909	07.2110	1931893	07.3460	1955386	07.2002	5113214	06.1546
443603	08.0870C	1906909	07.2110	1934477	07.2650	1955389	07.2695	5113633	12.4153
444867	08.0660C	1906979	07.3150	1934478	07.2650	1955391	07.2004	5113814	08.2130C
444867	08.0660C	1906979	07.3150	1934478	07.2650	1955404	07.2680	5113817	08.2140C
444867	08.3735C	1907467	07.2520	1935137	07.3240	1955411	07.2008	5113867	12.5500
446072	08.2180C	1907495	07.2765	1935138	07.3240	1957292	07.3290	5113868	12.5355
451905	12.5150	1907768	07.3070	1935334	07.3650	1957294	07.3460	5113936	08.4450C
453302	07.3581	1909496	07.2540	1935334	07.3720	1957296	07.3642	5113953	08.0530C
454650	08.1910C	1909514	07.2290	1936466	07.2765	1957297	07.3250	5113958	06.2150
454992	08.2190C	1909521	07.2320	1937115	07.2730	1957299	07.3310	5114011	06.2140
457187	12.5130	1909523	07.2520	1937116	07.2115	1957670	07.3160	5114019	08.1420C
672303	07.3600	1909527	07.2520	1937117	07.2210	1957847	07.2330	5114022	06.2620
807736	07.2787	1909531	07.2298	1937121	07.2210	1958135	07.3060	5114031	08.1440C
809062	07.2440	1909550	07.2030	1937419	07.3060	1958218	07.6120	5114036	08.1300C
809062	07.3450	1909553	07.2293M	1937612	07.2210	1958219	07.6190	5114167	12.5524
809593	07.2440	1909560	07.2830	1937616	07.2020	1959206	07.3290	5114212	06.2450
810794	07.2770	1909601	07.2330	1937837	07.2765	1959207	07.3290	5114335	08.1670C
811381	07.3720	1909654	07.2830	1938010	07.2280	1960177	07.3290	5114413	08.4380C
811912	07.2790	1909829	07.6180	1942256	07.2572	1960230	07.3290	5114442	08.2580C
812410	07.2155	1909982	07.3620	1942257	07.2100	1960232	07.3240	5114455	08.4455C
825196	07.3270	1909984	07.3240	1942260	07.2690	1960653	07.3265	5114458	08.4430C
825197	07.3720	1909986	07.3240	1942282	07.2572	1960653	07.3480	5114459	08.4420C
825260	07.3310	1909988	07.3680	1942969	07.5987	1960655	07.3290	5114475	08.2390C
826462	07.2140	1909989	07.3350	1942995	07.2150	1960657	07.3290	5114500	08.3972C
901304	06.2460	1909993	07.3350	1943242	07.2675	1960848	07.3290	5114502	08.1530C
903204	06.2100	1909995	07.3190	1944836	07.6090	1960848	07.3290	5114515	08.3290C
903304	06.2100	1910011	07.3080	1945356	07.2570	1961320	07.2020	5114523	08.1550C
905304	08.2490C	1910014	07.3310	1945402	07.6170	1961872	07.3160	5114528	08.2680C
907054	07.3090	1910033	07.3650	1945409	07.6120	1964184	07.3240	5114622	12.0450
907055	07.3090	1910035	07.3250	1945468	07.2250	2088510	08.5110C	5114712	08.0413C
907196	07.3090	1911644	07.2765	1945469	07.2298	2157781	08.4440C	5114726	08.2610C
907351	07.3090	1912501	07.3250	1945470	07.2360	2224977	08.0560C	5114727	12.4031
908505	06.2460	1912502	07.3110	1945472	07.2640	2355555	08.1650C	5114746	08.2740C
908605	07.3090	1912728	07.2590	1945475	07.2312	2436167	07.2818	5114749	08.2740C
954418	08.2490C	1912728	07.2590	1945476	07.2294	3221863	08.4960C	5114904	08.3110C
954685	07.3090	1913080	07.2770	1945477	07.2293M	3385336	07.2615	5114974	12.4026
954716	12.5150	1913128	07.2615	1945478	07.2545	5017850	07.3580	5115087	08.0930C
954987	12.5130	1913534	07.2350	1945479	07.2350	5024654	07.3410	5115164	08.2580C
1106107	07.3000	1913743	07.3720	1945480	07.2560	5100147	08.4960C	5115214	06.1865
1106108	07.3000	1913960	07.2620	1945484	07.2390	5108870	06.1556	5115214	06.1865
1106109	07.3000	1914123	07.3720	1945487	07.2280	5108871	06.1556	5115214	06.1870
1106110	07.3000	1914373	07.2435	1945490	07.2270	5108876	08.2160C	5115214	06.2267
1106904	07.3000	1914750	07.3590	1945496	07.2210	5109027	08.0790C	5115214	08.0510C
1106927	07.3000	1914842	07.2765	1945496	07.2822	5109300	08.4880C	5115214	08.0510C
1106928	07.3000	1914869	07.2615	1945499	07.2730	5109389	08.2835C	5115321	12.6260
1106931	07.3000	1915172	07.3430	1945509	07.2150	5109470	08.0505C	5115393	08.4880C
1106944	07.3000	1915258	07.3290	1945510	07.2345	5109689	08.3295C	5115454	08.1670C

PART NO.	GROUP NO.	PART NO.	GROUP NO.	PART NO.	GROUP NO.	PART NO.	GROUP NO.	PART NO.	GROUP NO.
5115454	08.1670C	5117737	12.5735	5122162	12.5735	5125604	12.5646	5133120	06.1800
5115539	08.0658C	5117753	07.5860	5122219	08.2020C	5125668	08.2900C	5133121	06.1556
5115572	08.1380C	5117757	07.5700	5122227	07.3300	5125670	08.2900C	5133124	06.1556
5115578	08.0450C	5117778	12.1759	5122227	08.2040C	5125752	08.3530C	5133128	06.1556
5115656	08.2620C	5117786	06.1660	5122227	08.3220C	5125752	08.3530C	5133280	06.1556
5115898	08.2630C	5117823	08.4450C	5122263	12.5226	5125755	08.4770C	5133281	06.1556
5115922	12.6390	5117847	06.2385	5122269	12.5660	5125784	06.2063	5133282	06.2047
5116353	08.1780C	5117853	08.1200C	5122281	08.2020C	5125905	08.0450C	5133341	08.3440C
5116357	08.0470C	5117854	08.1200C	5122286	06.1580	5126135	12.5490	5133342	08.3470C
5116476	08.1385C	5117857	08.1200C	5122317	08.0439C	5126139	08.3430C	5133357	06.2020
5116485	08.1397C	5117858	08.1200C	5122321	08.1940C	5126140	08.3380C	5133358	06.2020
5117003	08.0600C	5117898	12.5230	5122341	08.0620C	5126280	08.4480C	5133450	06.1660
5117005	08.1830C	5117899	12.5280	5122348	08.1940C	5126319	08.4672C	5133680	12.5610
5117010	08.1760C	5117905	08.1310C	5122348	08.1940C	5126319	08.4675C	5133686	12.5650
5117011	08.1760C	5117920	08.1392C	5122393	08.3380C	5126320	08.4809C	5133687	12.5120
5117016	08.0470C	5117927	12.5465	5122445	08.0900C	5126327	08.3840C	5133795	12.5610
5117020	08.3690C	5117928	07.5700	5122486	08.1200C	5126336	12.0420	5133824	12.5120
5117023	08.1870C	5117928	12.5620	5122529	08.2890C	5126487	08.1980C	5134040	06.2385
5117024	08.1840C	5117929	12.5440	5122530	08.2537C	5126499	08.2610C	5134042	06.2080
5117025	08.1840C	5117930	12.5380	5122623	12.4003	5126499	12.5320	5134340	08.2740C
5117028	08.1840C	5117931	12.5190	5122866	08.4960C	5126570	08.0353C	5134341	08.2740C
5117031	08.0460C	5117935	08.2640C	5122895	08.3880C	5126840	06.2203	5134888	08.3972C
5117058	08.2020C	5117942	12.5410	5122896	08.3880C	5126903	06.2412	5134890	08.3972C
5117059	08.2040C	5117949	08.0345C	5122914	08.2650C	5126904	06.2203	5150013	08.0655C
5117061	08.2040C	5117950	06.2150	5122915	08.2700C	5126910	06.1556	5150013	08.0655C
5117067	08.2740C	5117952	12.5550	5122918	08.2630C	5126911	06.2220	5150014	08.0510C
5117072	08.2740C	5117957	08.3795C	5122937	08.2530C	5126978	08.4880C	5150014	08.0510C
5117081	08.2535C	5117958	08.0460C	5122983	08.1700C	5126992	12.5400	5150020	08.0470C
5117082	08.2820C	5117960	08.1300C	5123010	08.0500C	5127189	12.5522	5150041	12.6470
5117102	08.2130C	5117962	06.2300	5123091	08.0341C	5127199	06.1810	5150042	08.0510C
5117116	08.0341C	5117965	08.1450C	5123115	07.3560	5127230	08.0345C	5150042	08.0510C
5117116	08.2588C	5117966	08.1450C	5123150	06.2340	5127231	08.3430C	5150054	08.2030C
5117173	08.2030C	5117972	06.2240	5123159	08.0510C	5127232	08.3380C	5150060	08.0500C
5117186	08.0660C	5117973	08.3880C	5123183	06.2220	5127274	08.4770C	5150087	08.1330C
5117187	08.2728C	5117975	06.2190	5123239	08.0494C	5127307	08.3530C	5150087	08.1332C
5117191	12.5410	5117983	06.2330	5123250	08.1110C	5127484	08.3430C	5150087	08.2290C
5117193	12.5520	5117984	08.1220C	5123257	08.2570C	5127508	08.3365C	5150117	08.2930C
5117210	12.5410	5117993	06.1660	5123296	08.2620C	5127677	08.3395C	5150130	08.0510C
5117225	08.2060C	5117997	06.1800	5123297	08.2620C	5127794	08.4880C	5150132	08.0660C
5117230	08.2930C	5117998	06.2110	5123383	08.1384C	5127795	08.4880C	5150140	08.1890C
5117231	08.2930C	5118166	12.4030	5123402	08.1367C	5127796	08.4954C	5150147	08.3350C
5117242	08.4690C	5118219	06.2120	5123439	08.2580C	5127805	08.1367C	5150154	08.4420C
5117243	08.1312C	5118219	12.1630	5123442	06.2047	5128033	08.2585C	5150155	08.4430C
5117269	08.3630C	5118219	12.5170	5123468	08.2690C	5128071	08.2900C	5150174	08.1680C
5117297	12.5200	5118264	06.2020	5123497	08.2380C	5128208	08.3295C	5150181	08.1550C
5117299	07.5860	5118302	08.3610C	5123564	08.1300C	5128234	06.1859	5150182	06.2390
5117362	08.3070C	5119570	12.5660	5123570	06.1660	5128311	08.4770C	5150188	06.2190
5117369	12.0510	5119781	08.3430C	5123622	06.2220	5128312	08.3530C	5150191	06.1920
5117419	08.2640C	5119864	12.5120	5123638	08.1310C	5128522	12.0540	5150193	06.2180
5117438	06.1660	5119972	08.0515C	5123700	08.0910C	5128593	12.4140	5150193	12.1690
5117458	08.2690C	5119973	08.0515C	5123812	12.5300	5128633	08.2635C	5150199	12.1680
5117466	08.3815C	5119974	08.0515C	5123812	12.5330	5128640	08.1070C	5150220	08.2770C
5117467	08.4380C	5119992	08.0750C	5123862	08.0510C	5128927	12.0520	5150230	08.0355C
5117476	06.1650	5120223	08.4960C	5123922	12.5635	5128938	08.3430C	5150238	08.2860C
5117498	08.0500C	5120224	08.4960C	5123923	12.5635	5129025	08.3380C	5150246	12.5320
5117523	08.3335C	5120224	08.4960C	5123932	08.4055C	5129031	08.3380C	5150250	12.6500
5117524	08.3240C	5120501	08.0341C	5123949	12.5240	5129101	08.1085C	5150259	12.6275
5117535	08.4420C	5120501	08.2537C	5124019	06.1556	5129111	07.2710	5150263	12.6250
5117546	06.1800	5120602	08.4243C	5124020	06.1556	5129111	08.2104C	5150265	12.5430
5117561	08.0820C	5120645	08.2552C	5124022	06.1556	5129516	08.3295C	5150268	12.5250
5117561	08.0820C	5120687	12.6160	5124142	12.6390	5129604	08.3285C	5150271	08.2170C
5117562	08.0800C	5120740	08.4330C	5124232	12.0770	5129845	12.0540	5150279	08.2650C
5117562	08.0800C	5120753	08.2085C	5124313	12.5540	5129884	08.2840C	5150281	08.2870C
5117563	08.0740C	5121182	08.0660C	5124332	12.5666	5129919	08.0750C	5150285	08.2480C
5117563	08.0740C	5121182	12.0655	5124333	12.5666	5130135	08.2250C	5150286	08.2590C
5117564	08.0965C	5121259	12.6180	5124355	12.5347	5130295	08.2790C	5150298	08.0960C
5117564	08.0965C	5121459	08.0491C	5124397	08.3440C	5130352	08.2905C	5150302	08.1110C
5117565	08.0895C	5121466	08.2010C	5124426	12.5350	5130488	08.0680C	5150303	08.1050C
5117591	08.2585C	5121659	08.2930C	5124519	08.2727C	5130750	08.0492C	5150311	08.0900C
5117599	08.3734C	5121714	08.3640C	5124520	08.2885C	5130752	08.0512C	5150312	08.1190C
5117629	08.1900C	5121716	08.4450C	5124521	08.2706C	5130753	08.0512C	5150314	08.1000C
5117636	08.3200C	5121731	08.2390C	5124551	12.5345	5130769	06.1580	5150318	08.0900C
5117649	08.1384C	5121733	08.2390C	5124631	12.0440	5130959	06.2330	5150322	08.1120C
5117693	12.5460	5121753	08.1310C	5124988	08.1825C	5131147	08.3440C	5150324	08.0890C
5117700	08.0274C	5121814	08.2860C	5125036	08.1870C	5131147	08.3440C	5150325	08.0880C
5117700	08.2480C	5121815	08.2120C	5125038	08.0620C	5131148	08.3470C	5150327	08.0630C
5117704	08.0356C	5121815	08.2120C	5125096	12.5660	5131258	08.4450C	5150328	08.0630C
5117704	08.2890C	5121816	08.2110C	5125108	12.0800	5131380	08.3050C	5150329	08.0630C
5117717	08.2855C	5121816	08.2120C	5125140	08.3470C	5131502	08.3430C	5150333	08.0690C
5117718	08.2855C	5121835	08.0460C	5125142	08.3440C	5131503	08.3380C	5150344	08.2560C
5117720	08.0356C	5121894	08.3220C	5125153	07.5740	5131719	08.2360C	5150345	08.2850C
5117720	08.2890C	5121905	08.2860C	5125153	07.5740	5131989	06.2063	5150346	08.2780C
5117722	08.2840C	5121970	08.2380C	5125445	08.3470C	5132155	06.1907	5150348	08.2540C
5117727	08.0343C	5122069	06.2140	5125592	08.4954C	5132606	08.1940C	5150349	08.2710C
5117727	08.2670C	5122147	12.5460	5125598	06.1619	5132747	12.5390	5150350	08.2500C
5117733	08.0450C	5122150	12.5390	5125599	06.1905	5132962	12.5540	5150361	06.1710
5117734	08.0470C	5122157	12.5610	5125603	12.5487	5133118	06.1800	5150362	06.1960

PART NO.	GROUP NO.	PART NO.	GROUP NO.	PART NO.	GROUP NO.	PART NO.	GROUP NO.	PART NO.	GROUP NO.
5150372	08.2800C	5154398	12.1810	5173730	06.1640	5183624	12.5210	5192902	08.1840C
5150431	08.4515C	5154401	12.1660	5174286	12.5413	5183626	12.5210	5192903	08.1840C
5150512	12.5650	5154422	12.5390	5174428	12.5450	5183630	12.5210	5192904	08.1760C
5150542	08.2680C	5154435	12.5610	5174429	12.5524H	5183631	12.5735	5192905	08.1760C
5150568	06.2070	5154438	12.5610	5174962	12.1655	5183632	12.5480	5192906	08.1840C
5150568	08.2107C	5154448	12.5400	5174971	12.1725	5183701	12.5160	5192907	08.1840C
5150843	12.6370	5154453	08.0660C	5174973	12.1790	5183704	12.5660	5192908	08.1760C
5150855	08.2800C	5154453	08.0660C	5174975	12.1715	5184200	12.5665	5192909	08.1760C
5150856	08.2800C	5154503	12.5520	5175408	08.1300C	5184336	12.5210	5192910	08.1840C
5150884	12.5570	5154538	08.4350C	5175641	08.1630C	5184484	08.0485C	5192911	08.1840C
5150885	12.5710	5154669	08.2020C	5175944	08.3890C	5184530	12.1770	5193221	12.6130
5150889	12.5280	5155482	12.4100	5175984	08.3440C	5184531	12.1610	5193316	08.0485C
5150890	12.5340	5155596	08.0470C	5176035	08.3720C	5184532	12.1610	5193605	06.2095
5150891	12.5540	5155596	12.5708	5176066	08.3010C	5185325	08.1940C	5193606	06.2090
5150892	12.5590	5155765	08.3840C	5176119	08.3825C	5185605	12.5270	5193719	08.2690C
5150897	12.5720	5155815	08.1300C	5176228	12.6350	5186050	08.1580C	5193732	08.0530C
5150898	12.5540	5155816	07.5770	5176557	12.5730	5186064	12.5400	5193733	08.0530C
5150899	12.5190	5155816	08.1310C	5176653	08.3025C	5186383	06.2020	5193734	08.0530C
5150900	08.3200C	5155818	07.5870	5176668	08.0442C	5186493	06.2100	5193735	08.0530C
5150923	12.5630	5155819	07.5700	5176729	08.4880C	5186571	06.2330	5194073	08.0485C
5150925	12.5630	5155831	08.1420C	5176834	12.5667	5186572	06.2295	5194074	08.0485C
5150941	12.5680	5155839	08.1925C	5176837	12.5260	5186574	06.2110	5194163	08.0485C
5150941	12.5690	5155861	07.5860	5176998	08.2350C	5186576	06.2080	5194164	08.0485C
5150941	12.5705	5156521	08.3570C	5176999	08.2280C	5186577	08.0515C	5194543	08.1930C
5150941	12.5720	5156528	08.3690C	5177082	12.5660	5186577	08.0515C	5194801	08.3453C
5150942	12.5420	5156532	08.3690C	5177241	06.1540	5186579	08.0515C	5194805	08.2410C
5150943	12.5460	5156683	08.3700C	5177528	08.1600C	5186579	08.0515C	5194825	08.1290C
5150996	12.5410	5156770	06.1910	5177651	08.1230C	5186762	06.1830	5194858	08.1220C
5151059	12.5580	5156815	08.3840C	5177769	08.1425C	5186840	06.1477	5194859	08.1220C
5151122	08.0510C	5156816	08.3750C	5177769	08.1426C	5186841	06.1477	5195078	12.1612
5151272	08.0510C	5156819	08.3880C	5177772	08.4233C	5186858	08.1130C	5195167	08.0700C
5151272	08.1020C	5156955	08.3600C	5177772	08.4470C	5187308	08.4310C	5195220	08.1080C
5151277	08.1360C	5157192	08.0670C	5177777	08.4348C	5187308	08.4310C	5195527	12.6460
5151277	08.1360C	5157194	08.0603C	5177777	08.4500C	5187309	08.4247C	5195735	08.1920C
5151344	08.1520C	5157274	08.1880C	5177778	08.4327C	5187310	08.4275C	5195739	08.0020C
5151370	08.3660C	5157930	08.1740C	5177778	08.4490C	5188129	06.2063	5195742	08.0580C
5151370	08.4690C	5157933	08.2680C	5177786	08.1386C	5188273	08.5150C	5195781	08.1920C
5151430	08.3390C	5158673	08.1390C	5177798	08.0460C	5188405	08.1960C	5195782	08.1920C
5151444	08.2310C	5158674	08.1790C	5178036	08.1570C	5188406	08.1930C	5195783	08.1920C
5151487	12.5690	5158820	12.5610	5178061	06.2670	5188611	12.5178	5196022	08.1205C
5151576	08.0495C	5158901	08.2890C	5178062	06.2650	5188635	12.0512	5196023	08.1205C
5151576	08.0495C	5159080	12.5700	5178381	08.0620C	5189041	06.2350	5196024	08.1205C
5151576	08.2080C	5159353	08.1830C	5178382	08.0620C	5189060	06.2510	5196025	08.1205C
5151601	08.0990C	5159384	08.3760C	5178383	08.0620C	5189729	08.2060C	5196026	08.1205C
5151601	08.0993C	5159388	08.4770C	5178581	12.5523M	5189966	08.2720C	5196027	08.1205C
5151604	12.5660	5159714	08.2860C	5178700	12.1757	5189967	08.2720C	5196028	08.1205C
5152149	08.1780C	5160037	12.6340	5178976	08.0660C	5189970	08.2790C	5196029	08.1205C
5152613	08.3750C	5160302	08.1500C	5178976	08.0660C	5189973	08.2880C	5196119	08.2885C
5152804	08.2670C	5160380	08.1730C	5178997	08.0474C	5190566	07.5770	5196146	08.0400C
5152878	08.0500C	5160408	07.3570	5178998	08.0510C	5192108	08.3450C	5196314	08.2415C
5152904	08.4480C	5160542	08.1830C	5179017	08.2720C	5192111	08.1830C	5196317	08.1790C
5152929	12.5660	5160629	08.3425C	5179046	08.2795C	5192234	08.2410C	5196319	08.1770C
5152944	12.5290	5161003	12.1705	5179068	08.1450C	5192496	08.1665C	5196320	08.1860C
5152987	12.5550	5161464	12.5485	5179133	08.1530C	5192497	08.1960C	5196321	08.2410C
5153060	12.5510	5162860	08.2790C	5179588	08.1717C	5192751	08.2430C	5196322	08.0400C
5153117	08.0450C	5164286	07.3360	5179630	08.1760C	5192776	08.1670C	5196323	08.0400C
5153144	08.1520C	5164312	08.0555C	5179631	08.1760C	5192796	08.2450C	5196330	08.1770C
5153147	08.3550C	5165221	12.5310	5179632	08.1850C	5192821	08.2435C	5196331	08.1760C
5153154	08.3550C	5165289	08.0510C	5179633	08.1850C	5192864	08.1940C	5196332	08.1760C
5153154	08.3560C	5165289	08.2705C	5179709	12.5678	5192874	08.1770C	5196333	08.1770C
5153247	08.3880C	5166265	12.5265	5179732	08.4495C	5192875	08.1770C	5196334	08.1760C
5153260	08.3680C	5167220	08.4826C	5179836	08.1940C	5192876	08.1770C	5196335	08.1760C
5153284	08.3770C	5167380	08.4690C	5179954	08.0840C	5192877	08.1770C	5196336	08.1770C
5153286	08.3780C	5167714	08.2367C	5180273	08.0459C	5192878	08.1770C	5196337	08.1760C
5153309	08.3800C	5167727	08.2730C	5181746	12.1757	5192879	08.1760C	5196338	08.1760C
5153310	08.3810C	5168001	08.3400C	5181747	12.1753	5192880	08.1760C	5196339	08.1770C
5153311	08.3590C	5169193	08.3470C	5182512	08.4635C	5192881	08.1850C	5196340	08.1760C
5153313	08.3650C	5169195	08.3870C	5182555	12.5490	5192882	08.1850C	5196341	08.1760C
5153313	08.4690C	5169197	08.3890C	5182556	12.5540	5192883	08.1760C	5196342	08.1860C
5153617	08.3680C	5169460	08.2900C	5182557	12.5500	5192884	08.1760C	5196343	08.1840C
5153623	08.1468C	5169478	06.1660	5182558	12.5415	5192885	08.1850C	5196344	08.1840C
5153623	08.1495C	5169481	08.4770C	5182559	12.5355	5192886	08.1850C	5196345	08.1860C
5153627	08.4690C	5171922	07.3360	5182977	12.4175	5192887	08.1760C	5196346	08.1840C
5153902	06.1670	5172031	12.4170	5182977	12.5587	5192888	08.1760C	5196347	08.1840C
5153902	06.1670	5172052	08.2910C	5183008	08.4405C	5192889	08.1840C	5196348	08.1860C
5153902	08.4410C	5172347	08.2380C	5183042	12.5400	5192890	08.1840C	5196349	08.1840C
5153911	08.2980C	5172566	06.1560	5183042	12.5400	5192891	08.1760C	5196350	08.1840C
5153914	08.2260C	5172734	08.2330C	5183256	08.0510C	5192892	08.1760C	5196351	08.1860C
5153938	08.2800C	5172865	08.2750C	5183268	12.5200	5192893	08.1840C	5196352	08.1840C
5153986	08.2950C	5172874	06.1830	5183286	12.5360	5192894	08.1840C	5196353	08.1840C
5154199	08.3630C	5173139	08.3530C	5183305	08.0473C	5192895	08.1860C	5196363	08.1950C
5154215	08.4410C	5173362	08.2530C	5183305	08.0515C	5192896	08.1860C	5196364	08.1950C
5154252	08.3590C	5173363	08.2530C	5183314	12.5350	5192897	08.1860C	5196365	08.1950C
5154319	08.0510C	5173364	08.2810C	5183329	08.0680C	5192898	08.1860C	5196366	08.1950C
5154332	08.1840C	5173365	08.2700C	5183329	08.0680C	5192899	08.1860C	5196367	08.0410C
5154360	08.1910C	5173482	08.3170C	5183330	08.0457C	5192900	08.1760C	5196380	08.0580C
5154398	08.2880C	5173695	08.2550C	5183612	12.5360	5192901	08.1760C	5196381	08.0580C

NUMERICAL INDEX

PART NO. GROUP NO.	PART NO. GROUP NO.	PART NO. GROUP NO.	PART NO. GROUP NO.	PART NO. GROUP NO.
5196383 08.2450C	5228668 12.6300			
5196384 08.2440C	5228673 12.6445			
5196385 08.2440C	5228674 12.6445			
5196532 08.2920C	5228694 12.6480			
5196533 08.2920C	5228696 12.6165			
5196602 08.3454C	5228701 12.6130			
5196602 08.3454C	5228706 12.6135			
5196603 08.3454C	5228760 12.6120			
5196708 08.0020C	5228765 12.6120			
5196710 08.0020C	5228766 12.6355			
5196753 08.1830C	5228768 12.6450			
5196754 08.1830C	5228769 12.6135			
5196782 08.1080C	5228776 12.6445			
5196843 08.0965C	5228779 12.6445			
5196937 12.5740	5228781 12.6445			
5196988 06.1820	5228785 12.6120			
5197159 08.1675C	5230007 12.1750			
5197236 08.1220C	5571024 08.4080C			
5197237 08.1220C	5573960 08.4150C			
5197238 08.1220C	5574008 08.4280C			
5197279 06.2225	5574736 08.4248C			
5197420 08.0570C	5575088 08.4348C			
5197421 08.0570C	5575091 08.4310C			
5197422 08.0570C	5575680 08.4327C			
5197425 12.6460	5576067 08.4030C			
5197426 12.6460	5661400 12.1723			
5197427 12.6460	7451054 08.2490C			
5197428 12.6460	7451142 08.2150C			
5197489 08.1940C	8514600 08.4370C			
5197505 08.0790C	8528885 08.4370C			
5197508 06.2090	9174746 08.5000C			
5197509 06.2090	9409011 08.3512C			
5197534 08.0410C	9409028 08.2010C			
5197545 08.1920C	9409028 08.2175C			
5197546 08.1920C	9409035 08.2170C			
5197547 08.1920C	9409037 08.2160C			
5197548 08.1920C	9409961 08.0510C			
5197563 08.2140C	9411488 08.2532C			
5197565 08.0530C	9412015 08.2000C			
5197569 08.1220C	9414268 08.1250C			
5197613 08.1220C	9415235 07.2574			
5197725 12.6183	9416777 07.3440			
5197920 08.1920C	9417889 08.3520C			
5197933 08.1950C	9420900 12.5130			
5197934 08.0410C	9421423 07.2785			
5226186 12.6220				
5226393 12.6285				
5226400 12.6230				
5226411 12.6480				
5226413 12.6170				
5226415 12.6400				
5226416 12.6273				
5226564 12.6330				
5226567 12.6320				
5226719 12.6310				
5226912 12.6297				
5227210 12.6420				
5227318 12.6430				
5228013 12.6200				
5228102 12.6270				
5228104 12.6210				
5228106 12.6355				
5228109 12.6190				
5228294 12.6167				
5228306 12.6300				
5228313 12.6135				
5228473 12.6450				
5228491 12.6140				
5228509 12.6150				
5228511 12.6410				
5228518 12.6445				
5228521 12.6120				
5228522 12.6120				
5228528 12.6300				
5228529 12.6445				
5228583 12.6150				
5228586 12.6320				
5228587 12.6200				
5228588 12.6170				
5228594 12.6167				
5228596 12.6420				
5228597 12.6355				
5228601 12.6270				
5228603 12.6445				
5228608 12.6290				
5228656 12.6300				
5228658 12.6300				

ALPHABETICAL INDEX

Description	Group No.	Description	Group No.
A			
ADAPTER - Crankcase Breather-----	8. 3005C	BOLT - Governor to Cylinder Head-----	12. 5172
ADAPTER - Engine Cylinder Block Water Hole -	8. 0413C	BOLT - Mounting, Blower-----	8. 2532C
ADAPTER - Engine Oil Cooler-----	8. 4380C	BOLT - Oil Pan Plate or Sump-----	8. 2910C
ADAPTER - Engine Oil Filter-----	8. 3972C	BOLT - Oil Pump End Plate-----	8. 3512C
ADAPTER - Engine Oil Level Indicator Tube--	8. 3390C	BOLT - Oil Pressure Regulator-----	8. 3525C
ADAPTER - Engine Oil Pan-----	8. 2905C	BOLT - Retaining, Blower Rotor Gear-----	8. 2535C
ADAPTER - Tachometer Drive-----	7. 5700	BOOT - Starting Motor Lever Link-----	7. 2100
ARM - Adjusting, Fan Idler Pulley-----	6. 2450	BOLT - Thru, Generator-----	7. 3110
ARM - Rocker, Fuel Injector-----	8. 0840C	BOLT - Valve Rocker Shaft Bracket-----	8. 0880C
ARM - Rocker, Valve-----	8. 0850C	BOLT - Water Pump-----	6. 2120
ARMATURE - Generator-----	7. 3060	BRACE - Accessory Drive Belt Guard-----	8. 0341LC
ARMATURE - Starting Motor-----	7. 2020	BRACKET - Engine Oil Level Indicator Tube -	8. 3395C
B		BRACKET - Engine Oil Pump Screen-----	8. 3530C
BAFFLE - Engine Oil Filler Breather-----	8. 3010C	BRACKET - Fuel Injector Rack Control Tube -	12. 6160
BAFFLE - Generator-----	7. 3070	BRACKET - Fuel Line-----	12. 0440
BAND - Cover, Starting Motor-----	7. 2030	BRACKET - Fuel Line Junction-----	12. 0450
BAND - Generator Cover-----	7. 3080	BRACKET - Valve Rocker Arm Shaft-----	8. 0890C
BEARING - Accessory Drive-----	8. 0274C	BREATHER - Engine Crankcase-----	8. 3050C
BEARING - Blower Drive Support-----	8. 2480C	BRIDGE - Valve-----	8. 0895C
BEARING - Blower Rotor-----	8. 2490C	BRUSH - Generator-----	7. 3150
BEARING - Camshaft and Balance Shaft-End--	8. 1220C	BRUSH - Starting Motor-----	7. 2110
BEARING - Engine Connecting Rod-----	8. 1850C	BUSHING - Accessory Drive Gear-----	8. 0341GC
BEARING - Engine Idler Gear-----	8. 2150C	BUSHING - Blower Drive Gear-----	8. 2537C
BEARING - Fan Belt Idler Pulley Shaft-----	6. 2460	BUSHING - Camshaft and Balance Shaft-----	8. 1290C
BEARING - Generator-----	7. 3090	BUSHING - Engine Connecting Rod-----	8. 1880C
BEARING - Governor Operating Lever-----	12. 5128	BUSHING - Engine Oil Pump Drive Shaft-----	8. 3550C
BEARING - Governor Operating Shaft-----	12. 5130	BUSHING - Engine Oil Pump Driven Gear-----	8. 3560C
BEARING - Governor Throttle Shaft-----	12. 5140	BUSHING - Engine Oil Pump Idler Gear-----	8. 3570C
BEARING - Governor Weight Shaft-----	12. 5150	BUSHING - Engine Piston Pin-----	8. 1925C
BEARING - Main, Engine Crankshaft-----	8. 1760C	BUSHING - Generator-----	7. 3160
BEARING SET - Camshaft-----	8. 1205C	BUSHING - Governor Operating Shaft-----	12. 5178
BEARING SET - Engine Connecting Rod-----	8. 1860C	BUSHING - Governor Weight-----	12. 5179
BEARING SET - Main, Engine Crankshaft-----	8. 1770C	BUSHING - Insulator, Generator Terminal Stud	7. 3190
BEARING - Water Pump-----	6. 2100	BUSHING - Rocker Arm-----	8. 0900C
BEARING CAP - Engine Crankshaft-----	8. 1790C	BUSHING - Solenoid Terminal Plate-----	7. 5987
BEARING CONE (See Cone)		BUSHING - Starting Motor Armature CE-----	7. 2150
BEARING CUP (See Cup)		BUSHING - Starting Motor Armature DE-----	7. 2150
BLOCK - Engine Cylinder-----	8. 0400C	BUSHING - Starting Motor Center Bearing---	7. 2130
BLOWER - Engine-----	8. 2390C	BUSHING - Starting Motor Drive-----	7. 2155
BLOWER ROTOR-----	8. 2740C	BUSHING - Starting Motor Insulating-----	7. 2115
BODY - Engine Oil Pump-----	8. 3470C	BUSHING - Valve and Injector Push Rod Yoke -	8. 0910C
BODY - Fuel Injector-----	12. 6150	C	
BODY - Water Pump-----	6. 2110	CAGE - Fuel Injector Check Valve-----	12. 6165
BOLT - Baffle to Cylinder Block-----	8. 3025C	CAGE - Fuel Injector Valve-----	12. 6167
BOLT - Balance Weight Cover-----	8. 1230C	CAM - Blower Air Shut-Off-----	12. 4003
BOLT - Blower Drive Coupling-----	8. 2500C	CAM - Blower Drive Coupling-----	8. 2540C
BOLT - Blower Rotor Gear Hub-----	8. 2530C	CAM - Governor-----	12. 5180
BOLT - Cam or Balance Weight-----	8. 2160C	CAMSHAFT - Engine-----	8. 1200C
BOLT - Cam Roller Guide-----	8. 0870C	CAP - Engine Crankshaft Bearing-----	8. 1790C
BOLT - Camshaft End Bearing-----	8. 1250C	CAP - Engine Crankshaft End-----	8. 1500C
BOLT - Engine Connecting Rod Cap-----	8. 1870C	CAP - Engine Oil Filler-----	8. 3070C
BOLT - Engine Crankshaft Damper-----	8. 1470C	CAP - Fuel Injector Filter Element-----	12. 6170
BOLT - Engine Crankshaft End Cap-----	8. 1468C	CAP - Governor-----	12. 5200
BOLT - Engine Crankshaft Front Cover-----	8. 1490C	CAP - Governor Low Speed Spring-----	12. 5190
BOLT - Engine Crankshaft Gear-----	8. 2170C	CAP - Valve Spring-----	8. 0740C
BOLT - Engine Crankshaft Pulley-----	8. 1495C	CARRIER - Governor Weight-----	12. 5210
BOLT - Engine Cylinder Head-----	8. 0600C	CLAMP - Blower Drive Cover Seal-----	8. 2550C
BOLT - Engine Cylinder Head Cover-----	8. 0603C	CLAMP - Blower Housing Cover-----	8. 2552C
BOLT - Engine Idler Gear-----	8. 2175C	CLAMP - Engine Cylinder Block Cover-----	8. 0439C
BOLT - Engine Idler Gear Bearing Retainer---	8. 2180C	CLAMP - Fuel Injector-----	12. 6180
BOLT - Engine Idler Gear Hub-----	8. 2190C	CLAMP - Solenoid Terminal-----	7. 6010
BOLT - Engine Oil Cooler Housing-----	8. 4400C	CLAMP - Water By-Pass Tube Hose-----	6. 1477
BOLT - Engine Oil Pump Cover-----	8. 3490C	CLIP - Air Drain Box Hose-----	8. 0442C
BOLT - Engine Oil Pump Gear-----	8. 3505C	CLIP - Crankcase Ventilator Breather Pipe---	8. 3110C
BOLT - Engine Oil Pump Screen-----	8. 3520C	CLIP - Engine Oil Level Indicator Tube-----	8. 3400C
BOLT - Engine Oil Pump Screen Cover-----	8. 3520C	CLIP - Lock, Governor Control Lever Shaft -	12. 5226
BOLT - Flywheel-----	8. 2000C	COCK - Drain, Engine Cylinder Block-----	8. 0442C
BOLT - Flywheel Housing-----	8. 2010C	COCK - Drain, Engine Oil Cooler-----	8. 4403C
BOLT - Fuel Pump to Engine-----	12. 1630	COCK - Drain, Water Pump-----	6. 2130
BOLT - Governor Housing Cover-----	12. 5160	COIL - Field, Starting Motor-----	7. 2210
BOLT - Governor to Blower-----	12. 5170	COIL - Generator Field-----	7. 3240
		COIL - Solenoid-----	7. 6030
		COLLAR - Generator-----	7. 3250

ALPHABETICAL INDEX

Description	Group No.	Description	Group No.
COLLAR - Starting Motor Armature-----	7. 2220	FRAME - Starting Motor Commutator End----	7. 2290
CONE - Engine Crankshaft Damper-----	8. 1520C	FUEL INJECTOR -----	12. 6120
CONNECTING ROD - Engine -----	8. 1840C	FUEL PUMP-----	12. 1610
CONNECTOR - Air Compressor Oil Line-----	8. 4635C		
CONNECTOR - Fuel Lines-----	12. 0512	G	
CONNECTOR - Fuel Manifold-----	12. 0510	GASKET - Accessory Drive Support-----	8. 0341SC
CONNECTOR - Oil Cooler Housing Water-----	6. 1540	GASKET - Blower Air Inlet Housing-----	8. 2585C
CONNECTOR - Starting Motor-----	7. 2250	GASKET - Blower Drive Gear-----	8. 2588C
CONNECTOR - Water, Cylinder Head-----	6. 1546	GASKET - Blower Drive Support-----	8. 2590C
CONTACT - Solenoid-----	7. 6050	GASKET - Blower Housing End Plate Cover--	8. 2610C
CONTAINER - Fuel Injector-----	12. 6183	GASKET - Blower Mounting-----	8. 2620C
CONTROL - Solenoid-----	7. 6050	GASKET - Camshaft and Balance Shaft	
COOLER - Oil, Engine-----	8. 4370C	Weight Cover-----	8. 1310C
COUPLING - Flexible Blower Drive-----	8. 2560C	GASKET - Camshaft Bearing-----	8. 1312C
COUPLING - Water Pump-----	6. 2140	GASKET - Compression, Engine Cylinder	
COVER - Blower Drive-----	8. 2570C	Liner-----	8. 0457C
COVER - Blower Housing End Plate-----	8. 2580C	GASKET - Crankcase Breather-----	8. 3170C
COVER - Camshaft and Balance Shaft Weight--	8. 1300C	GASKET - Crankcase Ventilator Breather	
COVER - Engine Crankshaft-----	8. 1530C	Pipe-----	8. 3200C
COVER - Engine Cylinder Block Opening-----	8. 0450C	GASKET - Engine Crankshaft Cover-----	8. 1550C
COVER - Engine Cylinder Head-----	8. 0620C	GASKET - Engine Cyl. Block Air Tube Flange	8. 0459C
COVER - Engine Oil Pump-----	8. 3590C	GASKET - Engine Cylinder Block Cover-----	8. 0470C
COVER - Engine Oil Pump Pad-----	8. 3600C	GASKET - Engine Cylinder Block End Plate---	8. 0460C
COVER - Engine Oil Pump Screen-----	8. 3610C	GASKET - Engine Cylinder Block Hole-----	8. 0473C
COVER - Fan Belt Idler Pulley-----	6. 2510	GASKET - Engine Cyl. Block Opening Cover -	8. 0470C
COVER - Fuel Pump-----	12. 1655	GASKET - Engine Cylinder Block Plug-----	8. 0474C
COVER - Generator-----	7. 3268	GASKET - Engine Cylinder Head Cover-----	8. 0630C
COVER - Governor Control Housing-----	12. 5230	GASKET - Engine Manifold-----	8. 4960C
COVER - Governor High Speed Spring-----	12. 5240	GASKET - Engine Oil Cooler-----	8. 4410C
COVER - Governor Hub-----	12. 5250	GASKET - Engine Oil Cooler Adapter-----	8. 4420C
COVER - Governor Weight Housing-----	12. 5260	GASKET - Engine Oil Cooler Housing-----	8. 4430C
COVER - Hole, Flywheel Housing-----	8. 2020C	GASKET - Engine Oil Cooler Valve-----	8. 4440C
COVER - Manifold-----	8. 4953C	GASKET - Engine Oil Cooler Water Inlet-----	6. 1650
COVER - Oil Cooler Housing-----	8. 4405C	GASKET - Engine Oil Filler Cap-----	8. 3230C
COVER - Tachometer Drive-----	7. 5740	GASKET - Engine Oil Filter Cover-----	8. 4080C
COVER - Thermostat Housing-----	6. 1556	GASKET - Engine Oil Filter Stud-----	8. 4150C
COVER - Water Pump-----	6. 2150	GASKET - Engine Oil Pan-----	8. 2930C
CRAB - Exhaust Manifold-----	8. 4953C	GASKET - Engine Oil Pan Drain Plug-----	8. 2940C
CRANKSHAFT - Engine-----	8. 1450C	GASKET - Engine Oil Pan Plate or Sump-----	8. 2950C
CUP - Generator Washer Retainer-----	7. 3270	GASKET - Engine Oil Pump-----	8. 3640C
CUP - Starting Motor Drive-----	7. 2270	GASKET - Engine Oil Pump Cover-----	8. 3650C
CYLINDER HEAD - Engine-----	8. 0570C	GASKET - Engine Oil Pump Pad-----	8. 3660C
		GASKET - Engine Thermostat Housing-----	6. 1660
D		GASKET - Engine Water By-Pass Tube-----	6. 1670
DAMPER - Vibration, Engine Crankshaft-----	8. 1540C	GASKET - Engine Water Outlet Manifold-----	6. 1710
DEFLECTOR - Engine Thermostat Housing-----	6. 1560	GASKET - Flywheel Housing-----	8. 2030C
DEFLECTOR - Spill, Fuel Injector-----	12. 6190	GASKET - Flywheel Housing Hole Cover-----	8. 2040C
DISC - Fuel Pump Coupling-----	12. 1660	GASKET - Fuel Injector Filter Element Cap --	12. 6220
DRIVE - Starting Motor-----	7. 2280	GASKET - Fuel Pump-----	12. 1690
E		GASKET - Fuel Pump Retaining Screw-----	12. 1705
ELBOW - Engine Water Outlet Manifold-----	6. 1580	GASKET - Generator Adapter-----	7. 3300
ELBOW - Exhaust Manifold-----	8. 4954C	GASKET - Generator Ball Bearing Retaining	
ELBOW - Fuel Line-----	12. 0520	Plate-----	7. 3310
ELBOW - Governor-----	12. 5265	GASKET - Generator Cover Plate-----	7. 3320
ELEMENT - Engine Oil Filter-----	8. 4030C	GASKET - Governor to Blower-----	12. 5320
ELEMENT - Filter, Fuel Injector-----	12. 6200	GASKET - Governor Control Housing Cover--	12. 5280
EXHAUST VALVE-----	8. 0700C	GASKET - Governor to Cylinder Head-----	12. 5330
EXTENSION - Engine Fuel Outlet Manifold Elbow	12. 0540	GASKET - Governor High Speed Spring Cover-	12. 5290
		GASKET - Governor Hole Cover-----	12. 5300
F		GASKET - Governor Shaft Bearing Cap-----	12. 5310
FERRULE - Oil Line Connector Nut-----	8. 4672C	GASKET - Governor Weight Housing-----	12. 5340
FLANGE - Engine Oil Cooler Water Outlet----	6. 1619	GASKET - Oil Filler Adapter-----	8. 3220C
FLANGE - Oil Inlet-----	8. 4675C	GASKET - Oil Filter Adapter-----	8. 4055C
FLANGE - Water Pump Outlet-----	6. 1640	GASKET - Oil Filter Stud-----	8. 4150C
FLYWHEEL-----	8. 1980C	GASKET - Oil Pressure Regulator-----	8. 3630C
FLYWHEEL HOUSING-----	8. 2060C	GASKET - Oil Pump-----	8. 3640C
FOLLOWER - Fuel Injector-----	12. 6210	GASKET - Oil Pump Pipe-----	8. 4690C
FOLLOWER - Valve and Injector Push Rod Cam	8. 0930C	GASKET - Oil Pump to Crankcase-----	8. 3640C
FORK - Fuel Pump Coupling-----	12. 1680	GASKET SET - Engine Cyl. Head Overhaul--	8. 0580C
FORK - Governor Operating-----	12. 5270	GASKET SET - Engine Oil Pan-----	8. 2920C
FRAME - Generator-----	7. 3290	GASKET SET - Engine Overhaul-----	8. 0020C
		GASKET SET - Oil Pump Overhaul-----	8. 3450C
		GASKET - Solenoid Terminal Plate-----	7. 6080
		GASKET - Starting Motor-----	7. 2293
		GASKET - Starting Motor Drive Housing-----	7. 2294

ALPHABETICAL INDEX

Description	Group No.	Description	Group No.
GASKET - Starting Motor Lever Housing Plug --	7. 2296	KIT - Oil Pump Overhaul -----	8. 3453C
GASKET - Starting Motor Terminal Stud-----	7. 2298	KIT - Repair, Blower-----	8. 2450C
GASKET - Tachometer Drive Adapter -----	7. 5770	KIT - Repair, Fuel Injector Spray Tip and Valve-----	12. 6140
GASKET - Water Pump-----	6. 2180	KIT - Repair, Fuel Pump-Diesel-----	12. 1612
GASKET - Water Pump Cover-----	6. 2190	KIT - Repair, Water Pump-----	6. 2090
GEAR- Accessory Drive-----	8. 0341TC	KIT - Replacement, Water Pump Seal-----	6. 2095
GEAR - Drive, Blower-----	8. 2630C	KIT - Rotor Shaft & Water Pump Shaft-----	8. 2435C
GEAR - Engine Balance Shaft-----	8. 2110C	KIT - Starting Motor Drive Clutch-----	7. 2004
GEAR - Engine Camshaft-----	8. 2120C	KIT - Starting Motor Drive Pinion-----	7. 2006
GEAR - Engine Crankshaft-----	8. 2130C	KIT - Starting Motor Drive Stop Nut-----	7. 2008
GEAR - Engine Idler-----	8. 2140C		
GEAR - Engine Oil Pump-----	8. 3680C	L	
GEAR - Engine Oil Pump Drive-----	8. 3690C	LATCH - Blower Air Shut-Off Handle-----	12. 4031
GEAR - Engine Oil Pump Drive Idler-----	8. 3700C	LEAD - Generator Brush-----	7. 3395
GEAR - Fuel Injector Rack-----	12. 6230	LEAD - Starting Motor Brush-----	7. 2360
GEAR - Fuel Pump-----	12. 1715	LEVER - Fuel Injector Control Tube-----	12. 6250
GEAR - Ring, Flywheel, Engine-----	8. 2050C	LEVER - Fuel Injector Rack Control-----	12. 6260
GEAR SET - Blower Rotor-----	8. 2410C	LEVER - Governor Differential-----	12. 5380
GEAR SET - Oil Pumps-----	8. 3454C	LEVER - Governor Operating-----	12. 5390
GEAR - Water Pump-----	6. 2203	LEVER - Governor Shaft Control-----	12. 5400
GENERATOR-----	7. 3000	LEVER - Starting Motor Shift-----	7. 2390
GOVERNOR - Diesel Engine-----	12. 5120	LINE - Fuel-----	12. 0420
GUIDE - Engine Valve-----	8. 0750C	LINE - Oil Blower Drive Support Bearing---	8. 4515C
GUIDE - Governor High Speed Spring-----	12. 5345	LINK - Control Governor-----	12. 5410
GUIDE - Starting Motor Plunger Rod-----	7. 2312	LOCK - Engine Idler Gear Bearing Retainer Bolt-----	8. 2280C
GUIDE - Valve-----	8. 0750C	M	
GUIDE - Valve and Injector Cam Roller-----	8. 0960C	MANIFOLD - Engine Water Outlet-----	6. 1820
GUIDE - Valve Bridge-----	8. 0965C	MANIFOLD - Exhaust-----	8. 4880C
H		MOTOR - Starting-----	7. 2000
HANDLE - Blower Air Shut-Off Cam Pin-----	12. 4026	N	
HEAD - Engine Cylinder-----	8. 0570C	NOZZLE - Engine Connecting Rod Piston Spray-----	8. 1890C
HOLDER - Generator Brush-----	7. 3350	NOZZLE - Engine Cylinder Head Water-----	6. 1830
HOLDER - Starting Motor Brush Holder-----	7. 2320	NUT - Accessory Drive Gear-----	8. 0343LC
HOSE - Blower Drive Cover-----	8. 2635C	NUT - Balance Weight-----	8. 1330C
HOSE - Governor Control Link Cover Tube-----	12. 5347	NUT - Camshaft Gear-----	8. 1332C
HOUSING - Blower-----	8. 2640C	NUT - Engine Camshaft and Balance Shaft Gear	8. 2290C
HOUSING - Blower Air Inlet-----	12. 4030	NUT - Engine Connecting Rod Cap Bolt-----	8. 1900C
HOUSING - Crankcase Breather Element-----	8. 3240C	NUT - Engine Cylinder Block End Plate-----	8. 0491C
HOUSING - Engine Oil Cooler-----	8. 4450C	NUT - Engine Cylinder Head to Block Stud---	8. 0655C
HOUSING - Engine Thermostat-----	6. 1800	NUT - Engine Manifold Stud-----	8. 5000C
HOUSING - Flywheel-----	8. 2060C	NUT - Fuel Injector-----	12. 6270
HOUSING - Governor Spring-----	12. 5355	NUT - Generator Brush Holder Screw-----	7. 3410
HOUSING - Governor Control-----	12. 5350	NUT - Generator Shaft-----	7. 3430
HOUSING - Governor Weight-----	12. 5360	NUT - Governor Buffer Screw-----	12. 5413
HOUSING - Starting Motor Drive-----	7. 2330	NUT - Governor High Speed Adjustment-----	12. 5415
HOUSING - Starting Motor Lever-----	7. 2345	NUT - Lock, Blower Drive Gear Hub-----	8. 2670C
HUB - Blower Drive Gear-----	8. 2650C	NUT - Solenoid Terminal Plate-----	7. 6099
HUB - Engine Crankshaft Pulley-----	8. 1570C	NUT - Valve and Injector Push Rod Lock----	8. 0990C
HUB - Engine Crankshaft Vibration Damper---	8. 1580C	NUT - Valve Bridge Adj. Screw-----	8. 0993C
HUB - Engine Idler Gear-----	8. 2250C	NUT - Water Pump Shaft-----	6. 2240
HUB - Generator-----	7. 3360	O	
I		OIL COOLER - Engine-----	8. 4370C
IMPELLER - Water Pump-----	6. 2220	OILER - Generator-----	7. 3440
INDICATOR - Engine Oil Level-----	8. 3380C	OILER - Starting Motor-----	7. 2430
INJECTOR - Fuel-----	12. 6120	ORIFICE - Engine Connecting Rod-----	8. 1910C
INLET - Engine Oil Cooler Water-----	6. 1810	"O" RING - Starting Motor Lever Housing---	7. 2435
INSERT - Engine Cylinder Liner-----	8. 0485C	OUTLET - Engine Oil Cooler-----	8. 4455C
INSERT - Water Pump Impeller-----	6. 2225	P	
INSULATION - Starting Motor-----	7. 2350	PAD - Crankcase Breather-----	8. 3285C
INSULATOR - Solenoid Terminal-----	7. 6090	PAD - Cylinder Block Breather Cavity-----	8. 0492C
K		PAN - Oil, Engine-----	8. 2900C
KEY - Engine Camshaft & Balance Shaft Gear--	8. 2260C	PIN - Cam Pocket Drain Hole-----	8. 0494C
KEY - Oil Pump Gear-----	8. 3705C	PIN - Dowel, Blower Housing End Plate-----	8. 2680C
KEY - Valve Spring Cap-----	8. 0760C		
KIT - Blower Rotor Gear Hub-----	8. 2430C		
KIT - Engine Oil Filler Cap Spring-----	8. 2995C		
KIT - Fuel Injector Valve-----	12. 6135		
KIT - Injector Overhaul-----	12. 6130		
KIT - Installation, Blower-----	8. 2440C		

ALPHABETICAL INDEX

Description	Group No.	Description	Group No.
PIN - Dowel, Engine Crankshaft -----	8. 1600C	PULLEY - Engine Crankshaft-----	8. 1650C
PIN - Dowel, Engine Crankshaft Brg. Cap-----	8. 1815C	PULLEY - Idler, Fan Belt-----	6. 2620
PIN - Dowel, Engine Crankshaft Vibration Damper-----	8. 1630C	PUMP - Engine Oil-----	8. 3440C
PIN - Dowel, Engine Cylinder Block-----	8. 0495C	PUMP - Engine Water-----	6. 2080
PIN - Dowel, Engine Idler Gear Hub & Spacer -	8. 2310C	PUMP - Fuel-----	12. 1610
PIN - Dowel, Flywheel Housing -----	8. 2080C		
PIN - Dowel, Generator-----	7. 3450		
PIN - Dowel, Governor Weight Housing-----	12. 5420		
PIN - Dowel, Starting Motor-----	7. 2440		
PIN - Engine Oil Pump Body-----	8. 3720C		
PIN - Engine Piston-----	8. 1930C		
PIN - Fuel Injector Body-----	12. 6273		
PIN - Fuel Injector Control Tube End-----	12. 6275		
PIN - Fuel Injector Plunger-----	12. 6285		
PIN - Governor Control Link-----	12. 5430		
PIN - Governor Differential Lever-----	12. 5440		
PIN - Governor Fulcrum Lever-----	12. 5450		
PIN - Governor Operating Lever-----	12. 5460		
PIN - Governor Throttle Arm-----	12. 5465		
PIN - Governor Weight-----	12. 5480		
PIN - Injector Follower Stop-----	12. 6290		
PIN - Starting Motor Brush Hinge-----	7. 2460		
PINION- Starting Motor Drive-----	7. 2490		
PIN - Swivel, Governor Stop Lever Cable-----	12. 5485		
PIN - Valve and Injector Push Rod Yoke-----	8. 1000C		
PIN - Water Pump Shaft-----	6. 2250		
PIPE - Crankcase Ventilator Breather-----	8. 3290C		
PIPE - Engine Oil Filler-----	8. 3295C		
PIPE - Oil Pump-----	8. 4770C		
PISTON - Engine-----	8. 1920C		
PISTON - Governor High Speed Air Cylinder--	12. 5487		
PLATE - Blower Air Inlet Shut-Off Valve Striker	12. 4100		
PLATE - Blower Housing End-----	8. 2690C		
PLATE - End, Oil Pump-----	8. 3734C		
PLATE - Engine Cylinder Block End-----	8. 0500C		
PLATE - Flywheel Bolt-----	8. 2085C		
PLATE - Generator Ball Bearing Retainer-----	7. 3460		
PLATE - Generator Commutator End Cover-----	7. 3480		
PLATE - Generator Terminal-----	7. 3506		
PLATE - Lock, Cylinder Block Hand Hole Cover	8. 0505C		
PLATE - Lock, Flywheel to Crankshaft Bolt--	8. 2095C		
PLATE - Solenoid Terminal-----	7. 6120		
PLATE - Spring, Blower Rotor Gear Hub-----	8. 2700C		
PLATE - Starting Motor Brush Holder Support -	7. 2530		
PLATE - Starting Motor Brush Plate-----	7. 2520		
PLATE - Starting Motor Center Bearing-----	7. 2540		
PLATE - Starting Motor Cover-----	7. 2545		
PLATE - Valve Adjustment Instruction-----	8. 0658C		
PLUG - Blower Rotor Cup-----	8. 2705C		
PLUG - Camshaft-----	8. 1360C		
PLUG - Drain, Engine Oil Pan-----	8. 2970C		
PLUG - Engine Crankshaft-----	8. 1640C		
PLUG - Engine Cylinder Block-----	8. 0510C		
PLUG - Engine Cylinder Head-----	8. 0660C		
PLUG - Engine Oil Cooler Bypass Valve Spg.---	8. 4470C		
PLUG - Engine Oil Filter Valve-----	8. 4233C		
PLUG - Engine Oil Pump-----	8. 3735C		
PLUG - Flywheel-----	8. 2095C		
PLUG - Fuel Injector Body-----	12. 6297		
PLUG - Fuel Manifold-----	12. 0655		
PLUG - Fuel Pump-----	12. 1723		
PLUG - Oil Pressure Regulator-----	8. 3750C		
PLUG - Oil Pump-----	8. 3735C		
PLUG - Pipe-----	6. 1865		
PLUG - Fuel Pump Valve-----	12. 1725		
PLUG - Starting Motor-----	7. 2570		
PLUG - Thermostat Housing-----	6. 1870		
PLUG - Valve Rocker Arm Shaft-----	8. 1020C		
PLUG - Water Pump-----	6. 2267		
PLUNGER - Fuel Injector-----	12. 6300		
PLUNGER - Governor-----	12. 5490		
PLUNGER - Starting Motor Solenoid-----	7. 2560		
PULLEY - Accessory Drive-----	8. 0345C		
PULLEY - Camshaft-----	8. 1367C		
</			

ALPHABETICAL INDEX

Description	Group No.	Description	Group No.
SCREW - Starting Motor -----	7. 2615	SPACER - Governor -----	12. 5650
SCREW - Starting Motor Brush Holder-----	7. 2590	SPACER - Oil Level Indicator Clip-----	8. 3425C
SCREW - Starting Motor Pole Shoe -----	7. 2620	SPRING - Diesel Governor -----	12. 5660
SEAL - Blower Air Inlet Shut-Off Valve Shift--	12. 4130	SPRING - Engine Oil Cooler Bypass Valve---	8. 4490C
SEAL - Blower Drive Cover-----	8. 2750C	SPRING - Engine Oil Filter -----	8. 4310C
SEAL - Camshaft-----	8. 1385C	SPRING - Engine Oil Filter Valve-----	8. 4327C
SEAL - Camshaft Cover-----	8. 1386C	SPRING - Exhaust Valve -----	8. 0820C
SEAL - Engine Oil Filter Spring Retainer----	8. 4275C	SPRING - Fuel Injector Control Tube-----	12. 6390
SEAL - Governor-----	12. 5587	SPRING - Fuel Injector Filter Element-----	12. 6400
SEAL - Oil, Blower Rotor Shaft-----	8. 2770C	SPRING - Fuel Injector Plunger-----	12. 6410
SEAL - Oil Cooler Water Outlet Flange-----	6. 1905	SPRING - Fuel Injector Spray Tip Valve-----	12. 6420
SEAL - Oil, Engine Crankshaft-----	8. 1670C	SPRING - Fuel Pump Valve-----	12. 1770
SEAL - Oil, Fuel Pump-----	12. 1750	SPRING - Generator Brush-----	7. 3650
SEAL - Oil, Generator Drive-----	7. 3600	SPRING - Oil Pressure Regulator-----	8. 3840C
SEAL - Oil, Starting Motor Lever Housing----	7. 2623	SPRING - Solenoid-----	7. 6170
SEAL - Thermostat Housing Cover-----	6. 1907	SPRING - Starting Motor Brush Holder-----	7. 2670
SEAL - Water Pump-----	6. 2330	SPRING - Starting Motor Drive -----	7. 2675
SEAL - Water Pump-----	6. 1910	SPRING - Starting Motor Lever Return-----	7. 2690
SEAL - Water Pump Outlet -----	6. 1920	SPRING - Starting Motor Meshing-----	7. 2680
SEAT - Blower Drive Coupling Spring-----	8. 2780C	SPRING - Valve -----	8. 0820C
SEAT - Exhaust Valve Spring-----	8. 0800C	SPRING - Valve and Injector Push Rod Follower-----	8. 1130C
SEAT - Fuel Injector Spray Tip Valve -----	12. 6355	SPRING - Valve Bridge-----	8. 1132C
SEAT - Governor Low Speed Spring-----	12. 5590	STARTING MOTOR-----	7. 2000
SEAT - Oil Pressure & Relief Valve Spring----	8. 3795C	STOP - Fuel Injector Valve -----	12. 6430
SEAT - Valve & Injector Push Rod Follower----	8. 1110C	STOP - Oil Inlet Screen -----	8. 4809C
SEAT - Valve Spring-----	8. 0800C	STOP - Starting Motor Pinion-----	7. 2695
SHAFT - Balance -----	8. 1390C	STRAINER - Blower End Plate-----	8. 2835C
SHAFT - Blower Air Inlet Shut-Off Valve----	12. 4140	STRAINER - Engine Oil Filler Pine-----	8. 3350C
SHAFT - Blower Drive-----	8. 2790C	STRAP - Solenoid Terminal-----	7. 6180
SHAFT - Blower Rotor-----	8. 2795C	STUD - Balance Weight Cover -----	8. 1420C
SHAFT - Camshaft Pulley-----	8. 1392C	STUD - Starting Motor Mounting -----	7. 2710
SHAFT - Drive, Fuel Pump-----	12. 1757	STUD - Engine Cylinder Head Cover-----	8. 0670C
SHAFT - Driven, Fuel Pump-----	12. 1753	STUD - Engine Cylinder Head to Block-----	8. 0680C
SHAFT - Drive, Tachometer-----	7. 5860	STUD - Engine Manifold -----	8. 5110C
SHAFT - Engine Oil Pump-----	8. 3800C	STUD - Engine Oil Cooler-----	8. 4495C
SHAFT - Engine Oil Pump Drive Gear-----	8. 3810C	STUD - Engine Oil Filter-----	8. 4330C
SHAFT - Engine Oil Pump Driven Gear-----	8. 3815C	STUD - Engine Water Outlet Manifold-----	6. 1960
SHAFT - Fan Belt Idler Pulley-----	6. 2650	STUD - Flywheel Housing-----	8. 2104FC
SHAFT - Governor Operating -----	12. 5610	STUD - Generator Terminal-----	7. 3680
SHAFT - Governor Throttle-----	12. 5620	STUD - Solenoid Terminal-----	7. 6190
SHAFT - Governor Weight-----	12. 5630	STUD - Starting Motor Terminal-----	7. 2730
SHAFT - Oil Pump Driven Gear -----	8. 3815C	STUD - Water Pump-----	6. 2385
SHAFT - Rocker Arm-----	8. 1120C	STUD - Water Pump Cover-----	6. 2390
SHAFT - Starting Motor Drive -----	7. 2630	SUMP - Engine Oil Pan -----	8. 2980C
SHAFT - Starting Motor Shift Lever-----	7. 2640	SUPPORT - Accessory Drive -----	8. 0353C
SHAFT - Water Pump-----	6. 2340	SUPPORT - Blower Drive -----	8. 2840C
SHELL - Engine Oil Filter-----	8. 4280C	SUPPORT - Blower Drive Coupling Spring----	8. 2850C
SHIELD - Generator Terminal-----	7. 3609	SUPPORT - Engine Oil Pump Idler Gear----	8. 3870C
SHIM - Blower Rotor Gear-----	8. 2800C	SUPPORT - Governor Stop Control Wire-----	12. 5665
SHIM - Engine Oil Pump to Bearing Cap-----	8. 3825C		
SHIM - Governor High Speed Piston-----	12. 5635		
SHOE - Pole, Generator-----	7. 3620		
SHOE - Starting Motor Pole -----	7. 2650		
SLEEVE - Ball, Blower Drive Support -----	8. 2806C		
SLEEVE - Engine Crankshaft Oil Seal-----	8. 1675C		
SLEEVE - Engine Cylinder-----	8. 0530C		
SLEEVE - Governor High Speed Piston-----	12. 5646		
SLEEVE KIT - Engine Cylinder-----	8. 0410C		
SLINGER - Oil, Engine Crankshaft-----	8. 1680C		
SLINGER - Oil, Water Pump Bearing-----	6. 2350		
SLINGER - Tachometer-----	7. 5870		
SOLENOID-----	7. 5960		
SPACER - Blower Air Inlet Shut-Off Valve----	12. 4153		
SPACER - Blower Rotor Gear Hub-----	8. 2810C		
SPACER - Blower Rotor Shaft-----	8. 2820C		
SPACER - Camshaft-----	8. 1397C		
SPACER - Crankcase Breather-----	8. 3335C		
SPACER - Engine Idler Gear-----	8. 2360C		
SPACER - Engine =Oil Cooler Adapter-----	8. 4480C		
SPACER - Engine Vibration Damper Cone-----	8. 1717C		
SPACER - Fan Belt Idler Pulley Shaft Bearing -	6. 2670		
SPACER - Fuel Injector Control Tube Lever--	12. 6370		
SPACER - Fuel Pump Drive -----	12. 1759		
SPACER - Generator Ventilating Fan-----	7. 3642		
		T	
		TAG - Identification, Fuel Injector -----	12. 6445
		TEE - Air Compressor Oil Hose -----	8. 4826C
		TEE - Engine Cylinder Block-----	8. 0555C
		TEE - Fuel Line-----	12. 0770
		THERMOSTAT - Engine-----	6. 2020
		TIP - Spray, Fuel Injector-----	12. 6

ALPHABETICAL INDEX

Description	Group No.	Description	Group No.
VALVE - Engine Oil Cooler-----	8. 4500C		
VALVE - Engine Oil Filter-----	8. 4348C		
VALVE - Exhaust (Engine)-----	8. 0700C		
VALVE - Fuel Pump-----	12. 1790		
VALVE - Oil Pressure Regulator-----	8. 3880C		
W			
WASHER - Accessory Drive Pulley Bolt-----	8. 0355MC		
WASHER - Balance Weight Nut-----	8. 1425C		
WASHER - Blower Air Shut-Off Valve-----	12. 4175		
WASHER - Blower Housing Bolt-----	8. 2860C		
WASHER - Camshaft Gear Nut-----	8. 1426C		
WASHER - Engine Crankshaft Bearing Cap Bolt-----	8. 1825C		
WASHER - Engine Crankshaft End Cap Bolt---	8. 1730C		
WASHER - Engine Crankshaft Pulley or Hub--	8. 1740C		
WASHER - Engine Cylinder Head Bolt-----	8. 0690C		
WASHER - Engine Idler Gear Hub Bolt-----	8. 2367C		
WASHER - Engine Manifold Stud-----	8. 5150C		
WASHER - Engine Oil Filter-----	8. 4350C		
WASHER - Engine Oil Pump Idler Gear-----	8. 3890C		
WASHER - Flywheel Housing Cover Bolt-----	8. 2107C		
WASHER - Fuel Injector Clamp-----	12. 6500		
WASHER - Fuel Manifold Connector-----	12. 0800		
WASHER - Fuel Pump Lock Bolt-----	12. 1810		
WASHER - Generator-----	7. 3720		
WASHER - Governor Hole Cover Bolt-----	12. 5678		
WASHER - Governor Lever Pin-----	12. 5680		
WASHER - Governor Lever Shaft-----	12. 5690		
WASHER - Governor Operating Shaft Bearing---	12. 5700		
WASHER - Governor Stop Control Wire Swivel Pin-----	12. 5705		
WASHER - Governor Weight Pin-----	12. 5710		
WASHER - Governor Weight Shaft Bearing----	12. 5720		
WASHER - Insulating, Solenoid Terminal Stud -	7. 6230		
WASHER - Lock, Blower Drive Gear Hub-----	8. 2870C		
WASHER - Packing, Governor Housing Cover--	12. 5730		
WASHER - Retaining, Blower Rotor Gear-----	8. 2880C		
WASHER - Seal, Blower End Plate Cover-----	8. 2885C		
WASHER - Solenoid-----	7. 6220		
WASHER - Starting Motor-----	7. 2765		
WASHER - Thermostat Housing Bolt-----	6. 2070		
WASHER - Thrust, Blower Drive Gear Hub----	8. 2890C		
WASHER - Thrust, Camshaft & Balance Shaft -	8. 1430C		
WASHER - Thrust, Engine Crankshaft Rear Bearing-----	81830C		
WEIGHT - Balance, Camshaft and Balance Shaft-----	8. 1440C		
WEIGHT - Balance, Water Pump Gear-----	6. 2412		
WEIGHT - Engine Camshaft or Balance Shaft Gear-----	8. 2380C		
WEIGHT - Governor-----	12. 5735		
WEIGHT SET - Governor-----	12. 5740		
WICK - Oil, Starting Motor-----	7. 2830		
Y			
YOKE - Rocker Arm Push Rod-----	8. 1190C		