

WARNING: PINCH POINT AREAS


USE CAUTION WHEN OPERATING NEAR CHAIN AND SPROCKETS.

Where chain guards are furnished, the reels should not be operated with them removed.

NOTE:


OSHA indicates the appropriate guarding of chains and sprockets is at least partly the responsibility of the final installer of equipment, based on the fact that equipment can be installed in so many different positions and so many different degrees of accessibility to the operator.

Please make sure that you have thoroughly reviewed this issue when making the installation of the reel.




USE CAUTION WHEN GUIDING HOSE OR CABLE BACK ONTO POWER REELS.

Keep the hand guiding the hose back onto the reel several inches away from the drum so that there is no possibility of trapped or pinched fingers.



KEEP HANDS AWAY FROM SPOKED DISCS WHEN TURNING.




INSTRUCTIONS FOR SAFE FLUID HANDLING

USE A HOSE REEL AND HOSE PROPERLY RATED FOR THE JOB.

Never exceed the pressure rating (psi) specified for a particular reel and hose. Also, make sure that the size and material of both the reel and hose are designed for the intended use.

USE A FLEXIBLE CONNECTOR BETWEEN A SWIVEL JOINT AND INLET PIPING.



CHECK FOR POSSIBLE LEAKS AT FLUID CONNECTIONS PRIOR TO USE.

RELEASE PRESSURE IN HOSE BEFORE REMOVING FITTINGS OR PERFORMING ANY MAINTENANCE.


BEFORE WINDING COLLAPSIBLE HOSE ONTO A LIVE REEL, HOSE MUST BE EVACUATED OF ALL FLUID.

POWER REWIND REELS

USE CIRCUIT BREAKERS FOR ELECTRIC REWIND MOTORS.

Make sure that the circuit breaker is properly sized for the motor. Also, check all electrical connections for proper installation prior to use.

REMOVE AUXILIARY CRANK REWIND HANDLE WHEN USING POWER REWIND.




DISCONNECT POWER SOURCE BEFORE PERFORMING MAINTENANCE.

This applies to both electric and air-powered reels. Also, disconnect electrical power before removing junction box covers or collector ring housings.

SPRING REWIND REELS

USE CAUTION WHEN SPRING REEL RATCHET ASSEMBLY LOCK IS DISENGAGED.



When the lock is disengaged, always hold onto the hose and guide it onto the reel as it rewinds.

ON SPRING REELS, NEVER REMOVE THE COVER CONTAINING THE SPRING.

Coiled springs are under tension and removal of cover can result in severe personal injury.

