

WATER PUMP, ALTERNATOR AND DYNAMO
POMPE A EAU, ALTERNATEUR ET DYNAMO
WASSERPUMPE UND LICHTMASCHINEN
BOMBA PARA AGUA, ALTERNADOR Y DINAMO

121



<u>Ref.</u> <u>No.</u>	<u>Note</u>	<u>Part No.</u>	<u>Description</u>	<u>Designation</u>	<u>Benennung</u>	<u>Description</u>	<u>No.</u> <u>Req.</u>
CODES W.06 AND W.13 (CONTN)							
CODES W.06 ET W.13 (SUITE)							
CODEN W.06 UND W.13 (FORTS)							
CODIGOS W.06 Y W.13 (CONTN)							
1		38161116	BRACKET.....	SUPPORT.....	HALTER.....	SOPORTE.....	1
2		0826492	STUD.....	GOUJON.....	STIFTSCHRAUBE.....	VASTAGO.....	2
3		0576051	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	2
4		0920004	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	2
5		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	2
11		37361313	BRACKET.....	SUPPORT.....	HALTER.....	SOPORTE.....	1
12		0096448	BOLT.....	BOULON.....	BOLZEN.....	PERNO.....	1
13		33283514	BUSH.....	BAGUE.....	BUCHSE.....	BUJE.....	1
14		2211224	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	1
15		0920004	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	2
21		0999412	PULLEY.....	POULIE.....	RIEMENSCHIEBE.....	POLEA.....	1
22			ORDER ASSEMBLY.....	COMMANDER ENSEMBLE...	BESTELLE KOMPLETTEIL..	PEDIR CONJUNTO.....	1
23		0040601	BEARING.....	RROULEMENT.....	KUGELLAGER.....	COJINETE.....	1
24		0190127	COLLAR.....	COLLIER.....	SCHIEBE.....	COLLAR.....	1
25		0096640	BOLT.....	BOULON.....	BOLZEN.....	PERNO.....	1
26		2211305	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	1
27		0920494	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	1
33		36155422	LEVER.....	LEVIER.....	HEBEL.....	PALANCA.....	1
34		33246425	DISTANCE-PIECE.....	ENTRETOISE.....	ABSTANDBUCHSE.....	ESPACIADOR.....	1
35		0746453	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	1
36		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	1
42(A)		2612868	BELT.....	COURROIE.....	KEILRIEMEN.....	CORREA.....	1
42(B)		2612872	BELT.....	COURROIE.....	KEILRIEMEN.....	CORREA.....	1

NOTES:- (A) CODE W.06 ONLY
 NOTE:- CODE W.06 SEULEMENT
 BEMERKUNGEN:- NUR CODE W.06
 NOTAS:- CODIGO W.06 SOLAMENTE
 (B) CODE W.13 ONLY
 CODE W.13 SEULEMENT
 NUR CODE W.13
 CODIGO W.13 SOLAMENTE

WATER PUMP, ALTERNATOR AND DYNAMO
POMPE A EAU, ALTERNATEUR ET DYNAMO
WASSERPUMPE UND LICHTMASCHINEN
BOMBA PARA AGUA ALTERNADOR Y DINAMO



Ref. No.	Note	Part No.	Description	Designation	Benennung	Descripcion	No. Req.
CODES W.14, W.15, W.16, W.17, W.18 AND W.19							
CODES W.14, W.15, W.16, W.17, W.18 ET W.19							
CODEN W.14, W.15, W.16, W.17, W.18 UND W.19							
CODIGOS W.14, W.15, W.16, W.17, W.18 Y W.19							
1(A,Y)		41312554	PUMP.....	POMPE A EAU.....	WASSERPUMPE.....	BOMBA.....	1
1(B,Z)		41312566	PUMP.....	POMPE A EAU.....	WASSERPUMPE.....	BOMBA.....	1
1(C,A1)		41312552	PUMP.....	POMPE A EAU.....	WASSERPUMPE.....	BOMBA.....	1
1(D,B1)		41312567	PUMP.....	POMPE A EAU.....	WASSERPUMPE.....	BOMBA.....	1
1(A,B,C1)		41312911	PUMP.....	POMPE A EAU.....	WASSERPUMPE.....	BOMBA.....	1
1(C,D,D1)		41312908	PUMP.....	POMPE A EAU.....	WASSERPUMPE.....	BOMBA.....	1
1(A,E1)		41312349	PUMP.....	POMPE A EAU.....	WASSERPUMPE.....	BOMBA.....	1
1(B,F1)		41312348	PUMP.....	POMPE A EAU.....	WASSERPUMPE.....	BOMBA.....	1
1(C,J1)		41312251	PUMP.....	POMPE A EAU.....	WASSERPUMPE.....	BOMBA.....	1
1(C,G1)		41312351	PUMP.....	POMPE A EAU.....	WASSERPUMPE.....	BOMBA.....	1
1(D,H1)		41312356	PUMP.....	POMPE A EAU.....	WASSERPUMPE.....	BOMBA.....	1
2		37711632	BODY.....	CORPS.....	GEHAUSE.....	CUERPO.....	1
3(Q)		2431154	PLUG.....	BOUCHON.....	VERSCHLUSSCHRAUBE.....	TAPON.....	1
4(E)		37711661	BODY.....	CORPS.....	GEHAUSE.....	CUERPO.....	1
5(F)		37711671	BODY.....	CORPS.....	GEHAUSE.....	CUERPO.....	1
5(P)		37711711	BODY.....	COURPS.....	GEHAUSE.....	CUERPO.....	1
6(E)		36866724	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
7(R)		36866721	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
8		0826259	STUD.....	GOUJON.....	STIFTSCHRAUBE.....	VASTAGO.....	4
9		0576002	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	4
10		0920053	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	4
11(S)		32764119	SHAFT.....	ARBRE.....	WASSERPUMPENWELLE.....	EJE.....	1
11(T)		32764127	SHAFT.....	ARBRE.....	WASSERPUMPENWELLE.....	EJE.....	1
12		2524406	BEARING.....	ROULEMENT.....	KUGELLAGER.....	COJINETE.....	2
13		33143112	DISTANCE PIECE.....	ENTRETOISE.....	ABSTANDBUCHSE.....	ESPACIADOR.....	1
14		0170040	CIRCLIP.....	CIRCLIP.....	SICHERUNGSRING.....	ARO RETEN.....	1
15		33813313	SEAL.....	JOINT.....	DICHTUNG.....	SELLO.....	1
16		33157109	FLANGE.....	BRIDE.....	DICHTUNG.....	PESTANA.....	1
17		33157108	RETAINER.....	CARTER DE JOINT.....	GEHAUSE.....	RETEN.....	1
18		2415209	SEAL.....	JOINT.....	DICHTUNG.....	SELLO.....	1
(T)		2417208	SEAL.....	JOINT.....	DICHTUNG.....	SELLO.....	1
19(S)		37447602	IMPELLER.....	TURBINE.....	FLUEGELRAD.....	TURBINA.....	1
19(T)		37447603	IMPELLER.....	TURBINE.....	FLUEGELRAD.....	TURBINA.....	1
20(G)		31146941	PULLEY.....	POULIE.....	KEILRIEMENSCHLEIBE.....	POLEA.....	1
20(H)		31147581	PULLEY.....	POULIE.....	KEILRIEMENSCHLEIBE.....	POLEA.....	1
(U)		37483164	HUB.....	MOYEU.....	NABE.....	CUBO.....	1
21		0500006	KEY.....	CLAVETTE.....	SCHLEIBENFEDER.....	CHAVETA.....	1
22(S)		2211306	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	1
22(U)		2211031	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	1
22(V)		0576007	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	1
23(S)		0920007	WASHER.....	RONDELLE.....	SCHLEIBE.....	ARANDELA.....	1
23(T)		0920009	WASHER.....	RONDELLE.....	SCHLEIBE.....	ARANDELA.....	1
(V)		0920058	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	1
24(J)		0096439	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	2
25(J)		0920465	WASHER.....	RONDELLE.....	SCHLEIBE.....	ARANDELA.....	1
26(J)		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	2
27(K)		0096439	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	3
28(K)		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	3
29(K)		0920465	WASHER.....	RONDELLE.....	SCHLEIBE.....	ARANDELA.....	1
30(L)		0096439	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	1
31(L)		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	1
(W)		31146004	PULLEY.....	POULIE.....	KEILRIEMENSCHLEIBE.....	POLEA.....	1
(X)		31147003	PULLEY.....	POULIE.....	KEILRIEMENSCHLEIBE.....	POLEA.....	1
32(E)		36867137	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
33(R)		36867138	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
34(J)		0096433	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	1
35(J)		0096439	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	1
35(U)		0096439	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	2
36(J)		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	2
(U)		0920465	WASHER.....	RONDELLE.....	SCHLEIBE.....	ARANDELA.....	1
37(K)		0096443	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	1
38(K)		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	1
39(M)		0096439	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	2
40(M)		0096434	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	2
41(M)		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	4
42(L)		0096439	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	1
43(L)		0096434	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	2
44(L)		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	3

CPO 3110



WATER PUMP, ALTERNATOR AND DYNAMO
 POMPE A EAU, ALTERNATEUR ET DYNAMO
 WASSERPUMPE UND LICHTMASCHINEN
 BOMBA PARA AGUA, ALTERNADOR Y DINAMO

CPO 3110



WATER PUMP, ALTERNATOR AND DYNAMO
POMPE A EAU, ALTERNATEUR ET DYNAMO
WASSERPUMPE UND LICHTMASCHINEN
BOMBA PARA AGUA, ALTERNADOR Y DINAMO

125

Ref. No.	Note	Part No.	Description	Designation	Benennung	Descripcion	No. Req.
			CODES W.14, W.15, W.16, W.17, W.18 AND W.19				
			CODES W.14, W.15, W.16, W.17, W.18 ET W.19				
			CODEN W.14, W.15, W.16, W.17, W.18 UND W.19				
			CODIGOS W.14, W.15, W.16, W.17, W.18 Y W.19				
50(T)		89012	KIT.....	JEU.....	REPARATURAETZ.....	JUEGO.....	X
50(S)		85800	KIT.....	JEU.....	REPARATURAETZ.....	JUEGO.....	X
51(N)		36867128	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
52(E)		36867137	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
53(R)		36867138	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
53(N)		36867157	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
53(N)		36867156	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
54(N)		36866729	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
55(E)		36866724	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
56(R)		36866721	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
57(S)		32764119	SHAFT.....	ARBRE.....	WASSERPUMPENWELLE.....	EJE.....	1
57(T)		32764127	SHAFT.....	ARBRE.....	WASSERPUMPENWELLE.....	EJE.....	1
58		2524406	BEARING.....	ROULEMENT.....	KUGELLAGER.....	COJINETE.....	2
59		33143112	DISTANCE PIECE.....	ENTRETOISE.....	ABSTANDBUCHSE.....	ESPACIADOR.....	1
60		0170040	CIRCLIP.....	CIRCLIP.....	SICHERUNGSRING.....	ARO RETEN.....	1
61		33813313	SEAL.....	JOINT.....	DICHTUNG.....	SELLO.....	1
62		33157109	FLANGE.....	BRIDE.....	DICHTUNG.....	PESTANA.....	1
63		33157108	RETAINER.....	CARTER DE JOINT.....	GEHAUSE.....	RETEN.....	1
64		2415209	SEAL.....	JOINT.....	DICHTUNG.....		1
(T)		2417208	SEAL.....	JOINT.....	DICHTUNG.....		1
65(S)		37447602	IMPELLER.....	TURBINE.....	FLUEGELRAD.....	TURBINA.....	1
65(T)		37447603	IMPELLER.....	TURBINE.....	FLUEGELRAD.....	TURBINA.....	1
		0500006	KEY.....	CLAVETTE.....	SCHEIBENFEDER.....	CHAVETA.....	1

- NOTES:-
- (A) CODES W.14, W.15 AND W.16 - FOR USE WITH BASE UNIT CODES VA, VB, VC AND VD ONLY
 - (B) CODES W.14, W.15 AND W.16 - FOR USE WITH BASE UNIT CODES VE, VF, VG AND VH ONLY
 - (C) CODES W.17, W.18 AND W.19 - FOR USE WITH BASE UNIT CODES VA, VB, VC AND VD ONLY
 - (D) CODES W.17, W.18 AND W.19 - FOR USE WITH BASE UNIT CODES VE, VF, VG AND VH ONLY
 - (E) USED ONLY WITH 41312349, 41312348, 41312911, 41312554 AND 41312566 PUMP
 - (F) USED ONLY WITH 41312251 AND 41312356 PUMP
 - (G) USED ONLY WITH 41312349, 41312251, 41312351, 41312552 AND 41312554 PUMP
 - (H) USED ONLY WITH 41312348, 41312356, 41312566 AND 41312567 PUMP
 - (J) USED ONLY WITH 41312349, 41312552 AND 41312554 PUMP
 - (K) USED ONLY WITH 41312348 AND 41312566 PUMP
 - (L) USED ONLY WITH 41312356 AND 41312567 PUMP
 - (M) USED ONLY WITH 41312251 AND 41312351 PUMP
 - (N) NOT REQUIRED
 - (P) USED ONLY WITH 41312351, 41312908, 41312552 AND 41312567 PUMP
 - (Q) REPLACES 0650540
 - (R) USED ONLY WITH 41312251, 41312356, 41312351, 41312908, 41312552 AND 41312567 PUMP
 - (S) USED ONLY WITH 41312349, 41312348, 41312356, 41312251 AND 41312351 PUMP
 - (T) USED ONLY WITH 41312908, 41312911, 41312552, 41312554, 41312566 AND 41312567 PUMP
 - (U) USED ONLY WITH 41312908 AND 41312911 PUMP
 - (V) USED ONLY WITH 41312552, 41312554, 41312566 AND 41312567 PUMP
 - (W) CODES W.14, W.15, W.16, W.17, W.18 AND W.19 - FOR USE WITH BASE UNIT CODES VA, VB, VC AND VD ONLY
 - (X) CODES W.14, W.15, W.16, W.17, W.18 AND W.19 - FOR USE WITH BASE UNIT CODES VE, VF, VG AND VH ONLY
 - (Y) FROM ENGINE NO. 236 US 11209
 - (Z) FROM ENGINE NO. 236 US T.B.A.
 - (A1) FROM ENGINE NO. 236 US 10839
 - (B1) FROM ENGINE NO. 236 US T.B.A.
 - (C1) FROM ENGINE NO. 236 US 9922 - UP TO ENGINE NO. 236 US 11209 USE 41312554
FROM ENGINE NO. 236 US 9922 - UP TO ENGINE NO. 236 US T.B.A. USE 41312566
 - (D1) FROM ENGINE NO. 236 US 9922 - UP TO ENGINE NO. 236 US 10839 USE 41312552
FROM ENGINE NO. 236 US 9922 - UP TO ENGINE NO. 236 US T.B.A. USE 41312567
 - (E1) UP TO ENGINE NO. 236 US 9922 USE 41312911/31146004/0920465/0096439 (2 off) AND 0920054 (2 off)
 - (F1) UP TO ENGINE NO. 236 US 9922 USE 41312911/31147003/0920465/0096439 (3 off) AND 0920054 (3 off)
 - (G1) FROM ENGINE NO. 236 US 5395 UP TO ENGINE NO. 236 US 9922 USE 41312908/31146004
 - (H1) UP TO ENGINE NO. 236 US 9922 USE 41312908/31147003/0096439 AND 0920054
 - (J1) UP TO ENGINE NO. 236 US 5395 USE 41312351

WATER PUMP, ALTERNATOR AND DYNAMO
POMPE A EAU, ALTERNATEUR ET DYNAMO
WASSERPUMPE UND LICHTMASCHINEN
BOMBA PARA AGUA, ALTERNADOR Y DINAMO

<u>Ref.</u> <u>No.</u>	<u>Note</u>	<u>Part No.</u>	<u>Description</u>	<u>Designation</u>	<u>Benennung</u>	<u>Descripcion</u>	<u>No.</u> <u>Req.</u>
CODES W.14, W.15, W.16, W.17, W.18 AND W.19 (CONTD)							
CODES W.14, W.15, W.16, W.17, W.18 ET W.19 (SUITE)							
CODEN W.14, W.15, W.16, W.17, W.18 UND W.19 (FORTS)							
CODIGOS W.14, W.15, W.16, W.17, W.18 Y W.19 (CONTN)							
1(AE)		2871708	ALTERNATOR.....	ALTERNATEUR.....	LICHTMASCHINE.....	ALTERNADOR.....	1
1(BE)		2871724	ALTERNATOR.....	ALTERNATEUR.....	LICHTMASCHINE.....	ALTERNADOR.....	1
2		31141675	PULLEY.....	POULIE.....	RIEMENSCHLEIBE.....	POLEA.....	1
3(C)		2612424	BELT.....	COURROIE.....	KEILRIEMEN.....	CORREA.....	1
3(D)		2612430	BELT.....	COURROIE.....	KEILRIEMEN.....	CORREA.....	1
9		38161117	BRACKET.....	SUPPORT.....	HALTER.....	SOPORTE.....	1
10		0826492	STUD.....	GOUJON.....	STIFTSCHRAUBE.....	VASTAGO.....	2
11		0576052	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	2
12		0920004	WASHER.....	RONDELLE.....	SCHLEIBE.....	ARANDELA.....	2
13		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	2
19		0746601	BOLT.....	BOULON.....	BOLZEN.....	PERNO.....	1
20		33283509	BUSH.....	BAGUE.....	BUCHSE.....	BUJE.....	1
21		2211305	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	1
22		0920006	WASHER.....	RONDELLE.....	SCHLEIBE.....	ARANDELA.....	2
28		36178134	LEVER.....	LEVIER.....	HEBEL.....	PALANCA.....	1
29		0096433	BOLT.....	BOULON.....	BOLZEN.....	PERNO.....	1
30		0576051	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	1
31		0920004	WASHER.....	RONDELLE.....	SCHLEIBE.....	ARANDELA.....	1
32		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	1
38		0330831	DISTANCE-PIECE.....	ENTRETOISE.....	ABSTANDBUCHSE.....	ESPACIADOR.....	1
39		0096432	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	1
40		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	1
46(AE)		2872503	CONTROL BOX.....	REGULATEUR.....	REGLER.....	REGULADOR.....	1
46(BE)		2872514	CONTROL BOX.....	REGULATEUR.....	REGLER.....	REGULADOR.....	1
47(AE)		2848608	RELAY.....	RELAJ.....	SCHALTER.....	RELAY.....	1
47(BE)		2848624	RELAY.....	RELAJ.....	SCHALTER.....	RELAY.....	1
48(ABE)		2848181	CONTROL.....	REGULATEUR.....	REGLER.....	REGULADOR.....	1
(B)		2861051	BALLAST RESISTOR.....				1

NOTES:- (A) CODES W.15 AND W.18 ONLY
 NOTER:- CODES W.15 ET W.18 SEULEMENT
 BEMERKUNGEN:- NUR CODEN W.15 UND W.18
 NOTAS:- CODIGOS W.15 Y W.18 SOLAMENTE


(B) CODES W.16 AND W.19 ONLY
 CODES W.16 ET W.19 SEULEMENT
 NUR CODEN W.16 UND W.19
 CODIGOS W.16 Y W.19 SOLAMENTE

(C) CODES W.14, W.15 AND W.16 ONLY
 CODES W.14, W.15 ET W.16 SEULEMENT
 NUR CODEN W.14, W.15 UND W.16
 CODIGOS W.14, W.15 Y W.16 SOLAMENTE


(D) CODES W.17, W.18 AND W.19 ONLY
 CODES W.17, W.18 ET W.19 SEULEMENT
 NUR CODEN W.17, W.18 UND W.19
 CODIGOS W.17, W.18 Y W.19 SOLAMENTE

(E) COMPONENT PARTS SUPPLIED BY J. LUCAS
 PARTIES COMPOSANTES FOURNIES PAR J. LUCAS
 BESTELLE EINZELTEILE BEI J. LUCAS
 PIEZAS COMPONENTES SUMINISTRADOS POR J. LUCAS

CPO 3113



CPO 3114




Ref. No.	Note	Part No.	Description	Designation	Benennung	Descripcion	No. Req.
			CODE A.00 CODE A.00 CODE A.00 CODIGO A.00				
1		2656007	PRE-FILTER.....	PRE-FILTRE.....	VORFILTER.....	PRE-FILTRO.....	1
2		26560059	HEADCASTING.....	TETE DE FILTRE.....	FILTERKOPF.....	CABEZA.....	1
3		26560078	JOINT.....	JOINT.....	DICHTUNG.....	JUNTA.....	1
4		0800059	STRAINER.....	CREPINE.....	SIEB.....	COLADOR.....	1
5		0995458	GLASS BOWL.....	CUVE.....	OELBEHALTER.....	TAZON.....	1
6		0993394	STIRRUP.....	SUPPORT DE CUVE.....	KLEMBUEGEL.....	SUJETADOR.....	1
7		0571346	NUT.....	ECROU.....	UEBERWURFMUTTER.....	TUERCA.....	2
8		0566004	OLIVE.....	OLIVE.....	SCHNEIDRING.....	OLIVA.....	2
			CODE A.25 CODE A.25 CODE A.25 CODIGO A.25				
14(A)		2846121	SWITCH.....	INTERRUPTEUR.....	GLUEHANLASSCHALTER.....	INTERRUPTOR.....	1
15		31812163	PLATE.....	PLAQUE.....	PLATTE.....	PLACA.....	1
16		31812536	TRANSFER.....	DECALCOMANIE.....	ABZIEHBILD.....	CALCOMANIA.....	1
			CODE A.26 CODE A.26 CODE A.26 CODIGO A.26				
22		38615138	BRACKET.....	SUPPORT.....	HALTER.....	SOPORTE.....	1
23		0576002	NUT.....	VIS.....	SECHSKANTSCHRAUBE.....	TOERNILLO.....	1
24		0920053	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	1
30		35701	BALL-JOINT.....	ROTULE.....	KUGELZAPFEN.....	EMBOLA.....	1
31		0576150	NUT.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	1
32		0920052	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	1
38		38613232	ROD.....	TRINGLE.....	STANGE.....	VARILLA.....	1
39		0576150	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	1
40		33511415	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	1
41		0920003	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	1
42		0920053	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	1
48		34111305	ROD.....	TRINGLE.....	STANGE.....	VARILLA.....	1
49		0920024	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	2
50		0610001	SPLIT-PIN.....	GOUPILLE.....	SPLINT.....	PASADOR.....	2
			CODE A.34 CODE A.34 CODE A.34 CODIGO A.34				
56		34127	PUMP.....	POMPE.....	PUMPE.....	BOMBA.....	1
57		34142	NOZZLE.....	NEZ.....	EINSPRITZDUESE.....	TOBERA.....	1

NOTES:- (A) COMPONENT PARTS SUPPLIED BY J. LUCAS
 NOTER:- PARTIES COMPOSANTES FOURNIES PAR J. LUCAS
 BEMERKUNGEN:- BESTELLE EINZELTEILE BEI J. LUCAS
 NOTAS:- PIEZAS COMPONENTES SUMINISTRADOS POR J. LUCAS


ACCESSORIES
EQUIPEMENT
ZUBEHOER
ACCESORIES

Ref. No.	Note	Part No.	Descriptionx	Designation	Benennung	Descripcion	No. Req.
			CODE A.01 CODE A.01 CODE A.01 CODIGO A.01				
1		31147744	ADAPTOR.....	ADAPTATEUR.....	ANSCHLUSSTUECK.....	ADAPTADOR.....	1
2		0096632	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	4
3		0920055	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	4
			CODE A.08 CODE A.08 CODE A.08 CODIGO A.08				
9		38156341	BRACKET, L.H.....	SUPPORT.....	HALTER.....	SOPORTE.....	1
9		38157281	BRACKET, R.H.....	SUPPORT.....	HALTER.....	SOPORTE.....	1
10(A)		36271051	DISTANCE-PIECE.....	ENTRETOISE.....	ABSTANDBUCHSE.....	ESPACIADOR.....	1
11(A)		0826624	STUD.....	GOUJON.....	STIFTSCHRAUBE.....	VASTAGO.....	2
11(B)		0826627	STUD.....	GOUJON.....	STIFTSCHRAUBE.....	VASTAGO.....	2
12(A)		32524139	STUD.....	GOUJON.....	STIFTSCHRAUBE.....	VASTAGO.....	2
12(B)		0826612	STUD.....	GOUJON.....	STIFTSCHRAUBE.....	VASTAGO.....	2
13		0576054	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	8
14		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	8
NOTES:- (A) USED ONLY WITH 38157281							
(B) USED ONLY WITH 38156341							
			CODE A.09 CODE A.09 CODE A.09 CODIGO A.09				
20		38133541	BRACKET.....	SUPPORT.....	HALTER.....	SOPORTE.....	1
21		38133551	BRACKET.....	SUPPORT.....	HALTER.....	SOPORTE.....	1
22		0748661	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	6
23		0920056	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	6
			CODE A.11 CODE A.11 CODE A.11 CODIGO A.11				
30		38313601	BRACKET.....	SUPPORT.....	HALTER.....	SOPORTE.....	1
31		38313591	BRACKET.....	SUPPORT.....	HALTER.....	SOPORTE.....	1
32		0826618	STUD.....	GOUJON.....	STIFTSCHRAUBE.....	TORNILLO.....	8
33		0576054	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	8
34		0920055	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	8
			CODE A.24 CODE A.24 CODE A.24 CODIGO A.24				
40		2581365	COUPLING.....	ACCOUPLEMENT.....	KUPPLUNGSTUECK.....	ACOPLAMIENTO.....	1
41		0746653	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	8
42		0920055	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	8
			CODE A.32 CODE A.32 CODE A.32 CODIGO A.32				
48		31162121	STARTER RING.....	COURONNE DEMARREUR....	STARTERKRANZ.....	CORONA.....	1
			CODE A.33 CODE A.33 CODE A.33 CODIGO A.33				
54		0550053	RUBBER.....	JOINT.....	ABDICHTUNG.....	CAUCHO.....	2
55		0746451	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	4
56		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	4
62		2635116	RUBBER.....	JOINT.....	ABDICHTUNG.....	CAUCHO.....	2
63		0920826	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	2
64		0920445	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	2

CPO 3115



CPO 3116




Ref. No.	Note	Part No.	Description	Designation	Benennung	Descripcion	No. Req.
			CODES A.07 AND A.35 CODES A.07 ET A.35 CODEN A.07 UND A.35 CODIGOS A.07 Y A.35				
1(A)		2485518	RADIATOR.....	RADIATEUR.....	KUEHLER.....	RADIADOR.....	1
2(B)		2485550	RADIATOR.....	RADIATEUR.....	KUEHLER.....	RADIADOR.....	1
8		32003	DRAINCOCK.....	ROBINET.....	ABLASSHALN.....	GRIFO.....	1
9		2211305	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TORNILLO.....	2
15		38158301	BRACKET.....	SUPPORT.....	HALTER.....	SOPORTE.....	1
16		0748524	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	4
17		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	4
23		33546	RUBBER.....	JOINT.....	ABDICHTUNG.....	CAUCHO.....	2
24		33124118	WASHER.....	RONDELLE.....	SCHEIBE.....	ARANDELA.....	2
25		0920471	WASHER.....	RONDELLE.....	SCHEIBE.....	ARANDELA.....	2
26		2175132	SCREW.....	VIS.....	SCHRAUBE.....	TORNILLO.....	4
27		0576002	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	4
28		0920053	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	4
34		36444323	BRACKET.....	SUPPORT.....	HALTER.....	SOPORTE.....	2
35		0096434	SETSCREW.....	VIS.....	SECHSKANTMUTTER.....	TORNILLO.....	2
36		38632132	TIE BAR.....	TRINGLE.....	STANGE.....	VARILLA.....	2
37		0920769	GROMMET.....	PASSE-FIL.....	TUELLE.....	OJAL.....	4
38		33132112	DISTANCE-PIECE.....	ENTRETOISE.....	ABSTANDBUCHSE.....	ESPACIADOR.....	4
39		0920003	WASHER.....	RONDELLE.....	SCHEIBE.....	ARANDELA.....	4
40		0610005	SPLIT PIN.....	GOUVILLE.....	SPLINT.....	PASADOR.....	4
55(A)		35833527	PIPE.....	TUYAU.....	OELLEITUNG.....	TUBO.....	2
56(A)		38361139	BRACKET.....	SUPPORT.....	HALTER.....	SOPORTE.....	1
57(A)		0746454	BOLT.....	BOULON.....	BOLZEN.....	PERNO.....	1
58(A)		0576051	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	1
59(A)		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	1
65(A)		36676128	CLIP.....	COLLIER.....	SCHELLE.....	ABRAZADERA.....	1
66(A)		0726206	BOLT.....	BOULON.....	BOLZEN.....	PERNO.....	1
67(A)		0576301	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	1
73		0200704	HOSE.....	DURIT.....	SCHLAUCH.....	MANGUERA.....	1
74		0180113	CLIP.....	COLLIER.....	SCHELLE.....	ABRAZADERA.....	2
		34621427	HOSE.....	DURIT.....	SCHLAUCH.....	MANGUERA.....	1
76		0180111	CLIP.....	COLLIER.....	SCHELLE.....	ABRAZADERA.....	2
77		34277104	PIPE.....	TUYAU.....	WASSERROHR.....	TUBO.....	1
78		0200037	HOSE.....	DURIT.....	SCHLAUCH.....	MANGUERA.....	1
79		0180112	CLIP.....	COLLIER.....	SCHELLE.....	ABRAZADERA.....	2

NOTES:- (A) CODE A.07 ONLY
 NOTER:- CODE A.07 SEULEMENT
 BEMERKUNGEN:- NUR CODE A.07
 NOTAS:- CODIGO A.07 SOLAMENTE
 (B) CODE A.35 ONLY
 CODE A.35 SEULEMENT
 NUR CODE A.35
 CODIGO A.35 SOLAMENTE


ACCESSORIES
EQUIPEMENT
ZUBEHOER
ACCESORIES

<u>Ref.</u> <u>No.</u>	<u>Note</u>	<u>Part No.</u>	<u>Description</u>	<u>Designation</u>	<u>Benennung</u>	<u>Description</u>	<u>No.</u> <u>Req.</u>
			CODE A.23				
			CODE A.23				
			CODE A.23				
			CODIGO A.23				
1		32602	CLUTCH.....	EMBRAYAGE.....	SCHEIBENKUPPLUNG.....	EMBRAGUE.....	1
2		25875034	PLATE.....	DISQUE.....	PLATTE.....	DISCO.....	1
3		25875054	PLATE.....	DISQUE.....	PLATTE.....	DISCO.....	1
4		25875036	PLATE.....	DISQUE.....	PLATTE.....	DISCO.....	1
5		25875008	RING.....	CIRCLIP.....	SICHERUNGSRING.....	ARO RETEN.....	1
6		25875055	RING.....	CIRCLIP.....	SICHERUNGSRING.....	ARO RETEN.....	1
7		25875059	SLEEVE.....	MANCHON.....	BUCHSE.....	MANGUITO.....	1
8		25875057	SHAFT.....	ARBRE.....	WELLE.....	EJE.....	1
9		25875058	SHAFT.....	SHAFT.....	WELLE.....	EJE.....	1
10		25875006	LEVER.....	LEVIER.....	HEBEL.....	PALANCA.....	1
16		0096433	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	8
17		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	8
18		0748524	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	12
19		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	12

CPO 3117



CPO 3118



ACCESSORIES
EQUIPEMENT
ZUBEHOER
ACCESORIOS


137

Ref. No.	Note	Part No.	Description	Designation	Benennung	Description	No. Req.
		CODE A.31					
		CODE A.31					
		CODE A.31					
		CODIGO A.31					
1		32467	CLUTCH.....	EMBRAYAGE.....	SCHEIBENKUPPLUNG.....	EMBRAGUE.....	1
2		25860032	HOUSING.....	BOITIER.....	GEHAEUSE.....	CARTER.....	1
3		25860038	HOUSING.....	BOITIER.....	GEHAEUSE.....	CARTER.....	1
4		25860035	HOUSING.....	BOITIER.....	GEHAEUSE.....	CARTER.....	1
5		0720755	SCREW.....	VIS.....	SCHRAUBE.....	TORNILLO.....	1
6		0560239	GREASER.....	GRATSSIEB.....	SCHMIERNIPPEL.....	ENGRASADOR.....	2
7		0240526	COVER.....	COR VEHICULE.....	DECKEL.....	TAPA.....	1
8		0720691	SCREW.....	VIS.....	SCHRAUBE.....	TORNILLO.....	2
9		0050223	BEARING.....	ROULEMENT.....	LAGER.....	COJINETE.....	2
10		0050221	RETAINER.....	FIXATION.....	HALTER.....	RETEN.....	1
11		0180858	TABWASHER.....	BRIN DE VIS.....	SICHERUNGSBLECH.....	ARANDELA.....	1
12		0745117	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	1
13		0920969	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	1
14		25860039	SHAFT.....	ARBRE.....	WELLE.....	EJE.....	1
15		25860033	SHAFT.....	ARBRE.....	WELLE.....	EJE.....	1
16		0720694	SCREW.....	VIS.....	SCHRAUBE.....	TORNILLO.....	1
17		0560239	GREASER.....	GRATSSIEB.....	SCHMIERNIPPEL.....	ENGRASADOR.....	2
18		0500524	KEY.....	CLAVETTE.....	PASSFEDER.....	CHAVETA.....	1
19		25860034	KEY.....	CLAVETTE.....	PASSFEDER.....	CHAVETA.....	1
20		0571133	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	1
21		0920706	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	1
22		32440	TUBE.....	TUBE.....	LEITUNG.....	TUBO.....	1
23		0170126	CIRCLIP.....	CIRCLIP.....	SICHERUNGSRING.....	ARO RETEN.....	1
24		0921114	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	1
30		32442	CLUTCH.....	EMBRAYAGE.....	SCHEIBENKUPPLUNG.....	EMBRAGUE.....	1
31		32401	PLATE.....	DISCO.....	PLATTE.....	DISCO.....	1
32		0940826	PLATE.....	DISQUE.....	PLATTE.....	DISCO.....	1
33		0520342	LEVER.....	LEVIER.....	HEBEL.....	PALANCA.....	3
34		0780199	SPRING.....	RESSORT.....	FEDER.....	RESORTE.....	3
35		0995469	CLIP.....	COLLIER.....	SCHELLE.....	CLIP.....	6
36		0920974	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	6
37		0520347	PIN.....	AXE.....	SPLINT.....	PASADOR.....	3
38		32432	RING.....	CECROU.....	SICHERUNGSRING.....	ARO RETEN.....	1
39		25860028	RING.....	CECROU.....	SICHERUNGSRING.....	ARO RETEN.....	1
40		25860029	PLATE.....	DISCO.....	PLATTE.....	DISCO.....	1
41		25860037	SCREW.....	VIS.....	SCHRAUBE.....	TORNILLO.....	4
42		25860026	LOCKNUT.....	ECROU.....	MUTTER.....	TUERCA.....	1
43		25860027	PIN.....	AXE.....	SPLINT.....	PASADOR.....	1
44		25860030	SPRING.....	RESSORT.....	FEDER.....	RESORTE.....	1
45		25860031	SCREW.....	VIS.....	SCHRAUBE.....	TORNILLO.....	1
46		25860036	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	1
47		32441	BEARING & SLEEVE.....	ROULEMENT ET MANCHON	LAGER UND BUCHSE.....	COJINETE Y MANGUITO.....	1
48		32408	BEARING.....	ROULEMENT.....	LAGER.....	COJINETE.....	1
49		0095237	BOLT.....	BOULON.....	BOLZEN.....	PERNO.....	2
50		0571133	NUT.....	ECROU.....	SECHSKANTMUTTER.....	TUERCA.....	2
51		0720694	SLEEVE.....	MANCHON.....	BUCHSE.....	MANGUITO.....	1
52		0520344	LINK.....	CHARNIERE.....	GELENK.....	BISAGRA.....	6
53		0520348	PIN.....	AXL.....	BOLZEN.....	PASADOR.....	6
54		0440421	BODY.....	CORPS.....	GEHAEUSE.....	CUERPO.....	1
55		0780201	SPRING.....	RESSORT.....	FEDER.....	RESORTE.....	4
56		0995488	PLATE.....	PLAQUE.....	PLATTE.....	PLACA.....	1
57		0640078	RING.....	CIRCLIP.....	SICHERUNGSRING.....	ARO RETEN.....	1
58		0995468	CLIP.....	COLLIER.....	SCHELLE.....	CLIP.....	12
59		0920973	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	12
60		32415	GEAR.....	PIGNON.....	ZAHNRAD.....	ENCRANAJE.....	1
61		31891	YONE.....	CHAFE.....	GABELKOPF.....	YUGO.....	1
62		0995484	YONE.....	CHAFE.....	GABELKOPF.....	YUGO.....	1
63		0095228	BOLT.....	BOULON.....	BOLZEN.....	PERNO.....	2
64		0920970	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	2
65		0500523	KEY.....	GOUILLE.....	KEIL.....	CHAVETA.....	2
66		31893	LEVER.....	LEVIER.....	HEBEL.....	PALANCA.....	1
67		0520341	LEVER.....	LEVIER.....	HEBEL.....	PALANCA.....	1
68		0095229	BOLT.....	BOULON.....	BOLZEN.....	PERNO.....	1
69		0920970	WASHER.....	RONDELLE.....	SCHIEBE.....	ARANDELA.....	1
70		0750293	SHAFT.....	ARBRE.....	WELLE.....	EJE.....	1
76		0040060	BEARING.....	ROULEMENT.....	LAGER.....	COJINETE.....	1
77		0096433	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	8
78		0920054	WASHER.....	RONDELLE.....	FEDERING.....	ARANDELA.....	8
79		0748524	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	12
80		0920054	WASHER.....	RONDELLE.....	FEDERING.....	ARANDELA.....	12

ACCESSORIES
EQUIPEMENT
ZUBEHOER
ACCESORIES

<u>Ref.</u> <u>No.</u>	<u>Note</u>	<u>Part No.</u>	<u>Description</u>	<u>Designation</u>	<u>Benennung</u>	<u>Description</u>	<u>No.</u> <u>Req.</u>
		CODE A.36					
		CODE A.36					
		CODE A.36					
		CODIGO A.36					
1		35700	CLUTCH.....	EMBRAYAGE.....	SCHEIBENKUPPLUNG.....	EMBRAGUE.....	1
2		0040060	BEARING.....	ROULEMENT.....	LAGER.....	COJINETE.....	1
3		0096433	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	8
4		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	8
5		0748524	SETSCREW.....	VIS.....	SECHSKANTSCHRAUBE.....	TORNILLO.....	12
6		0920054	WASHER.....	RONDELLE.....	FEDERRING.....	ARANDELA.....	12

CPO 3119



ADDENDUM TO THE
STANDARD OPTION SCHEME

ENGINE TYPE: 4.236

PUBLICATION NO: 3251

PLEASE INSERT THE ATTACHED SUMMARY OF ADDITIONAL
CODES INTO THE BACK OF THE ABOVE PARTS BOOK.

JANUARY 1972

STANDARD OPTION SCHEME

1

ADDITIONAL CODES
ENGINE TYPE 4.236

PART NO.	DESCRIPTION	QTY.	REMARKS
<u>LUBRICATING OIL SUMP</u>			
<u>CODE B.06.</u>			
37173782	Sump Lubricating Oil	1	
36815708	Joint Lubricating oil Sump to Block	1	
0746255	Setscrew lubricating oil Sump to Block	12	
0096244	Setscrew lubricating oil Sump to Block	6	
0920053	Washer Spring	18	
32517128	Stud Bridge Piece to lub. oil Sump	2	
0576002	Nut lub. oil Sump retaining	2	
0920053	Washer spring	2	
0650540	Plug lub. oil Sump	2	
35772624	Tube lub. oil dipstick	1	
31787435	Dipstick lub. oil Sump	1	For use with Base Codes VA to VH.
31787445	Dipstick lub. oil Sump	1	For use with Base Code VJ only.
33812108	Washer dipstick sealing (Inc. in 31787445)	1	)
35745826	Pipe lub. oil Suction	1	)
36832122	Joint Suction Pipe flange to Pump Body	1	)
0746254	Setscrew Suction Pipe flange to Pump Body	2	) For use with Base
0920053	Washer Spring	2	) Codes VA to VH only.
0746253	Setscrew suction Pipe Clip to Bearing Cap	1	)
0920003	Washer plain	1	)
0920053	Washer spring	1	)
35721703	Pipe lub. oil Suction	1	)
36832409	Joint Suction Pipe flange to Pump Body	1	) For use with Base
0096237	Setscrew Pump Body to Balance weight frame	2	) Code VJ only.
0920053	Washer spring	2	)
<u>PULLEY CRANKSHAFT AND ADAPTOR</u>			
<u>CODE C.02</u>			
31148861	Pulley Crankshaft (Cast Iron)	1	
31147744	Adaptor Crankshaft Pulley	1	
0096632	Setscrew Adaptor Pulley to Crankshaft Pulley	4	
0920055	Washer spring	4	
<u>PULLEY CRANKSHAFT AND ADAPTOR</u>			
<u>CODE C.03</u>			
31148901	Pulley Crankshaft (Spheroidal Graphite Iron)	1	
31147744	Adaptor Crankshaft Pulley	1	
0096632	Setscrew Adaptor Pulley to Crankshaft Pulley	4	
0920055	Washer Spring	4	

PART NO.	DESCRIPTION	QTY.	REMARKS
<u>FILTER LUB. OIL, ADAPTOR HOUSING LUB. OIL DELIVERY</u> <u>CODE D.04.</u>			
35714103	Pipe Lub. oil delivery	1	
0490355	Joint delivery Pipe flange to Housing	1	
0746052	Setscrew delivery Pipe flange to Housing	2	
0920052	Washer Spring	2	
41371077	Housing lub. oil delivery Assembly	1	
32712715	Plunger delivery Housing relief valve	1	
31742128	Spring relief valve	1	
33157122	Cap relief valve	1	
0610012	Splitpin relief valve Cap retaining	1	
0870001	Thimble Cylinder Block to delivery Housing	1	
0096438	Setscrew delivery Housing to Cylinder Block	1	
0920054	Washer spring	1	
2654154	Filter lubricating oil	1	
26540123	Headcasting lub. oil Filter	1	
0095292	Bolt Headcasting to Container	1	
0921079	Washer Headcasting Bolt	1	
26560090	Element lub. oil Filter	1	
0490520	Joint lub. oil Filter Headcasting	1	Inc. in 26560090
26540127	Container lub. oil Filter	1	
0941138	Retainer Filter Element	1	
26540022	Spring Filter Element	1	
36862517	Joint lub. oil Filter to adaptor	1	
37763763	Adaptor lub. oil Filter	1	
36862517	Joint adaptor lub. oil Filter to Block	2	
0826627	Stud adaptor lub. oil Filter to Block	2	
0576054	Nut adaptor lub. oil Filter to Block	2	
0920055	Washer spring	2	
0746610	Setscrew lub. oil Filter to adaptor	2	
0920055	Washer spring	2	
<u>COVER CYLINDER HEAD REAR END</u> <u>CODE G.01.</u>			
37532112	Cover Cylinder Head rear end	1	
36851409	Joint Cylinder Head rear end Cover	1	
2431154	Plug Cylinder Head rear end Cover	1	
0746254	Setscrew rear end Cover to Cylinder Head	6	
0920053	Washer spring	6	
<u>AIR FILTER HEAVY DUTY. INDUCTION MANIFOLD AND CYLINDER HEAD COVER</u> <u>CODES J.49 TO J.72.</u>			
2651708	Filter Air	1	J.49 To J.72 Inc.
26510122	Body Air Filter	1	
26510148	Element Air Filter	1	
26510141	But and Gasket Assembly	1	
26510130	Clamp Assembly	1	
26510133	Baffle Air Filter	1	
26510149	Cup Assembly	1	
26510147	Vacuating Valve	1	
26510150	Cap Air Filter	1	
2651092	Stackpipe Air Filter	1	
2651851	Restriction Indicator Air Filter	1	

PART NO.	DESCRIPTION	QTY.	REMARKS
<u>CODES J.49 TO J.72 Continued</u>			
37787441	Manifold Induction - Centre Top Inlet	1	Codes J.49,50,51,52.
37786651	Manifold Induction - Centre Side Inlet	1	Codes J.53,54.
37787681	Manifold Induction - Rear Bottom Inlet	1	Codes J.55,56,71,72.
37787371	Manifold Induction - Front Top Inlet	1	Codes J.57,58,59,70
36862131	Joint Induction Manifold to Head - Rear	1	
36862132	Joint Induction Manifold to Head - Front	1	
36862133	Joint Induction Manifold to Head - Centre	1	
0096439	Setscrew Induction Manifold to Head	1	) Codes J.49,50,51,52,
0746424	Setscrew Induction Manifold to Head	5	) J.57,58,59,70.
0096443	Setscrew Induction Manifold to Head - Top	2	)
0096432	Setscrew Induction Manifold to Head - Bottom	2	) Codes J.53,54,55,56.
0096434	Setscrew Induction Manifold to Head - Centre	2	)
0746451	Plug Induction Manifold	1	)
0920155	Washer Induction Manifold Plug	1	)
0826403	Stud Induction Manifold to Head	1	) Codes J.57,58,59,70.
0576051	Nut Induction Manifold Stud	1	
0920054	Washer spring	6	
33534122	Adaptor Induction Manifold (Heater Boss)	1	Codes J.53,54.
37188141	Cover Cylinder Head - Front Filler	1	Codes J.49,51,53,55, 57,59,71.
37188144	Cover Cylinder Head - Rear Filler	1	Codes J.50,52,54,56, 58,70,72.
36811122	Joint Cylinder Head Cover	1	
2487845	Cap Lub. oil Filler	1	
24870002	Joint lub. oil Filler Cap. (inc. in 2487845)	1	
2174018	Screw Cylinder Head Cover to Head	4	
0920002	Washer Plain	4	
0920052	Washer Spring	4	
34831308	Hose Air Inlet Pipe	1	)
0180117	Clip Air Inlet Pipe Hose	1	) Codes J.51,52,57, 58,71,72.
0180120	Clip Air Inlet Pipe Hose	1	)
<u>PUMP FUEL INJECTION - 2500 R.P.M.</u>			
<u>CODE K.07.</u>			
36547	Pump Fuel Injection - CAV.3248440	1	
0490685	Joint Fuel Injection Pump to Timing Case	1	
<u>START PILOT EQUIPMENT</u>			
<u>CODE L.05.</u>			
2666614	Pump Start Pilot	1	
2666606	Nozzle Start Pilot Injector	1	
2666607	Reservoir Start Pilot	1	
33536444	Adaptor Start Pilot	1	
<u>FILTER FUEL OIL AND BRACKET (HYDRAULIC GOVERNOR)</u>			
<u>CODE N.01.</u>			
2656615	Filter Fuel oil	1	
26560017	Element Fuel oil Filter	1	Inc. in 2656615.
0650204	Plug Fuel oil Filter	1	
0920112	Washer Fuel oil Filter Plug	1	

For Use With Base Codes
VE,VF,VG AND VH.

PART NO.	DESCRIPTION	QTY.	REMARKS
<u>CODE N.01 Continued</u>			
2658201	Valve Fuel oil Filter Non Return	1	
0920112	Washer non return valve	1	
36474136	Heat Shield Fuel oil Filter	1	
36538136	Bracket Fuel oil Filter	1	
0746424	Bolt Fuel oil Filter to Bracket	2	
0576051	Nut Fuel Filter Bracket retaining	2	
0920054	Washer Spring	2	
0746451	Setscrew Fuel Filter Bracket to Block	3	
0920054	Washer Spring	3	
41374009	Bolt Fuel oil Filter Pipe Banjo	1	To Filter Overflow Port.
31723253	Connection overflow pipe Banjo	1	
0920155	Washer spring	1	
0201091	Connection Fuel oil Filter Banjo	3	
0095332	Bolt Banjo Connection	3	
0920127	Washer Banjo Bolt	3	
0920154	Washer Banjo Bolt	3	
35841078	Pipe Fuel oil Lift Pump to Filter	1	
33225413	Nut Fuel oil Pipe	1	
33811115	Olive Fuel oil Pipe	1	
41223227	Pipe Fuel oil Filter to Fuel Pump	1	
33225413	Nut Fuel oil Pipe	1	
33811115	Olive Fuel oil Pipe	1	
35843044	Pipe Fuel oil-Fuel Pump to Filter return	1	
33225413	Nut Fuel oil Pipe	1	
33811115	Olive Fuel oil Pipe	1	
36516118	Clip Filter to Fuel Pump Pipes - Clamping	2	
0746264	Bolt Filter Pipes Clip Clamping	1	
0571350	Nut Filter Pipes Clip Clamping Bolt	1	
41222063	Pipe atomiser leak off to Filter overflow	1	
33225412	Nut atomiser leak off to Filter Pipe	2	
33811112	Olive atomiser leak off to Filter Pipe	2	

GAUGE LUB. OIL PRESSURE AND PIPINGCODE P.03.

30493	Gauge lub. oil pressure	1	
0620244	Pipe lub. oil pressure gauge - 6'0" Long	1	
0206002	Connection lub. oil pressure gauge Pipe	1	
0576111	Nut lub. oil Pressure Gauge Pipe	1	
0566002	Olive lub. oil Pressure Gauge Pipe	1	

GAUGE LUB. OIL PRESSURE (ELECTRICAL) AND SENDER UNIT - 12 VOLTCODE P.04.

2755353	Gauge lub. oil Pressure - Engine	1	
2846067	Unit, lub. oil Pressure Sender - Engine	1	

GAUGE LUB. OIL PRESSURE (ELECTRICAL) AND SENDER UNIT - 24 VOLTCODE P.05.

2755354	Gauge lub. oil Pressure - Engine	1	
2846067	Unit lub. oil Pressure Sender - Engine	1	

PART NO.	DESCRIPTION	QTY.	REMARKS
<u>EXHAUSTER VACUUM TANK GAUGE AND PIPING</u>			
<u>CODE Q.07.</u>			
30148	Tank Vacuum	1	
30149	Valve Non Return	1	
0490310	Joint Non Return Valve to tank	1	
0740243	Setscrew Non Return Valve to tank	2	
0920053	Washer Spring	2	
0650002	Plug Vacuum Tank	1	
0920154	Washer Vacuum tank plug	1	
0810003	Strap vacuum tank	2	
0746453	Bolt vacuum tank strap clamping	2	
0746407	Bolt vacuum tank strap to frame	2	
0576051	Nut vacuum tank securing	4	
0920054	Washer spring	4	
31428	Cock vacuum tank	1	
0570410	Locknut vacuum tank	1	
0920155	Washer vacuum tank Cock	1	
0200161	Union vacuum tank	1	
0920153	Washer vacuum tank union	1	
0620033	Pipe Exhauster to vacuum tank	1	
0570312	Nut vacuum Pipe	1	
0560008	Olive vacuum pipe	1	
30105	Gauge vacuum	1	
0620034	Pipe vacuum Gauge to tank	1	
0570301	Nut vacuum Gauge Pipe	1	
0560002	Olive vacuum Gauge Pipe	1	
2488811	Exhauster Assembly (See Parts Book 3251)	1	
36243117	Plate Exhauster drum thrust	2	
0746051	Setscrew thrust plate to Exhauster	4	
0920052	Washer spring	4	
31171711	Gear Exhauster	1	
0206002	Union Exhauster lub. oil feed pipe	1	
2441307	Elbow Exhauster Pipe	1	
0576117	Nut Exhauster Pipe	1	
0566008	Olive Exhauster Pipe	1	
35568315	Pipe Exhauster lub. oil feed	1	
0576111	Nut Exhauster lub. oil feed pipe	1	
0566002	Olive Exhauster lub. oil feed pipe	1	
0095350	Bolt Exhauster feed pipe Banjo (In Block)	1	
0920126	Washer Banjo Bolt	2	
35587346	Pipe lub. oil Feed to Exhauster and Fuel Pump Gear	1	) For Use With) Base Code V.G.
0571424	Nut lub. oil feed Pipe) Gear Carrier End	1	
0566001	Olive lub. oil feed Pipe)	1	
36862523	Joint Cylinder Block Blanking Plate	1	) For Use With Base) Codes VB And VC.
36231412	Plate Cylinder Block Blanking	1	
0746651	Setscrew Blanking Plate to Block	2	
0920055	Washer Spring	2	)
41115023	Gear Idler Assembly	1	
0050345	Bush Idler Gear (Inc. In 41115023)	2	
0941082	Plate Idler Gear retaining	1	
0096439	Setscrew Idler Gear Plate to Block	3	
0921246	Tabwasher Idler Gear retaining Plate	1	
0826287	Stud Timing Case to Exhauster	4	
0576002	Nut Exhauster retaining	4	

PART NO.	DESCRIPTION	QTY.	REMARKS
<u>CODE Q.07 Continued</u>			
0920053	Washer Spring	4	
36865511	Joint Timing Case to Exh. Adaptor Plate	1	
37513551	Plate Exhauster Adaptor	1	
36866416	Joint Adaptor Plate to Exhauster	1	
<u>ADAPTOR HYDRAULIC PUMP</u>			
<u>CODES Q.08, Q.09.</u>			
31171095	Gear Hydraulic Pump Driving	1	
37514591	Adaptor Hydraulic Pump	1	
2415868	'O' Ring Hydraulic Pump Adaptor	1	
2557339	Bearing Hydraulic Pump drive Gear	1	
33146112	Spacer, Hydraulic Pump drive Gear Bearing	1	
0040040	Bearing Hydraulic Pump drive Gear	1	
0170050	Circlip drive Gear Bearing retaining	1	
2726011	Circlip drive Gear locating	1	
0826454	Stud Hydraulic Pump Adaptor to Pump	2	
2211224	Nut Hydraulic Pump retaining	2	
0826218	Stud Timing Case to Hydraulic Pump Adaptor	4	
0576002	Nut Hydraulic Pump Adaptor retaining	4	
0920053	Washer spring	4	
41115043	Gear Idler Assembly C/W Bush	1	
33152143	Bush Idler Gear	1	
32413416	Plate Idler Gear retaining	1	
33177302	Washer Idler Gear thrust	2	
0096439	Setscrew Idler Gear retaining Plate to Block	3	
35521181	Pipe Hydraulic Pump lub. oil feed	1	
0571424	Nut lub. oil feed Pipe	1	
0566001	Olive lub. oil feed Pipe	1	
0095350	Bolt lub. oil pipe Banjo	1	
0920126	Washer lub. oil Pipe Banjo Bolt	2	
36231412	Plate Cylinder Block Blanking	1	
36862523	Joint Cylinder Block Blanking Plate	1	
0746651	Setscrew Blanking Plate to Cylinder Block	2	
0920055	Washer Spring	2	
<u>HOUSING FLYWHEEL No. 3 SAE 3-5/16" OIL SEALED</u>			
<u>CODE R.060</u>			
37134852	Housing Flywheel	1	
32114441	Plug Flywheel Housing	6	
0650203	Plug Flywheel Housing	1	
2411157	Washer Flywheel Housing Plug	1	
32712723	Plug Flywheel Housing	1	
36817411	Joint Flywheel Housing to Block	1	
0350025	Dowel Flywheel Housing to Block	2	
2185051	Setscrew Flywheel Housing to Block	2	
0746431	Setscrew Flywheel Housing to Block	4	
0920004	Washer plain	6	
36817145	Joint Flywheel Housing to sump	1	
0748523	Setscrew Sump to Flywheel Housing	3	
0920054	Washer Spring	3	

PART NO.	DESCRIPTION	QTY.	REMARKS
<u>STARTER MOTOR (M.50) AND DISTANCE PIECE ETC.</u>			
<u>CODES S.05,S.011.</u>			
37444693	Distance Piece starter Motor	1	)
0827802	Stud Flywheel Housing to Starter Motor	3	) Code S.05.
0827818	Stud Flywheel Housing to Starter Motor	3	)
2873001	Starter Motor 10 Tooth Pinion (Lucas M50-26294A)	1	) Code S.11.
0576051	Nut Starter Motor retaining	3	
0920054	Washer Spring	3	
<u>FLYWHEEL AND STARTER RING</u>			
<u>CODES U.01,02,03,04,05,06,07,08,09,11,12,13.</u>			
41112405	Flywheel and Starter Ring	1	Code U.01.
41112695	Flywheel and Starter Ring	1	Code U.02.
41112403	Flywheel and Starter Ring	1	Code U.03.
41112401	Flywheel and Starter Ring	1	Code U.04.
41112707	Flywheel and Starter Ring	1	Code U.05.
41112406	Flywheel and Starter Ring	1	Code U.06.
0999987	Flywheel and Starter Ring	1	Code U.07.
41112682	Flywheel and Starter Ring	1	Code U.08.
41112442	Flywheel and Starter Ring	1	Code U.09.
41112618	Flywheel and Starter Ring	1	Code U.11.
41112733	Flywheel and Starter Ring	1	Code U.13.
31162121	Ring Starter (Inc. In Flywheel Assys.)	1	Also Code U.12 - Ring Only.
0440280	Housing Pilot Bearing	1	Code U.02.
37423493	Housing Pilot Bearing	1	Code U.06.
33147123	Bush Flywheel Pilot	1	Code U.13
0746454	Setscrew Pilot Bearing Housing to Flywheel	4	)
0921063	Tabwasher Pilot Bearing Housing Setscrew	4	) Codes U.02, U.06.
32162203	Setscrew Flywheel to Crankshaft	6	Codes U.01,02,03,04, 06,09.
0746851	Setscrew Flywheel to Crankshaft	6	Codes U.05,07,08, U.11,U.13.
0921062	Tabwasher Flywheel to Crankshaft Setscrew	3	Codes U.01,03,04,05,07 08,09,11,13.
0921064	Tabwasher Flywheel to Crankshaft Setscrew	3	Code U.02.
2172703	Screw Flywheel to torque converter	8	)
33115126	Washer plain	8	) Code U.01
<u>POWER TAKE OFF-ANDERTON CLUTCH TYPE P11-H3</u>			
<u>HOUSING, FLYWHEEL AND RING</u>			
<u>CODE V.01.</u>			
35770	Clutch Assembly C/W operating lever	1	
25872033	Housing Clutch	1	
25872010	Ring External	1	
25872011	Centre Clutch	1	
25872022	Plate Front	1	
25872001	Disc Fibre	1	
25872025	Link Toggle	6	
25872002	Pin Toggle	3	
25872028	Lever Toggle	3	
25872014	Link Pin	6	

PART NO.	DESCRIPTION	QTY.	REMARKS
<u>CODE V.01 Continued</u>			
2724109	Circlip	18	
25872003	Plate Contact	1	
25872020	Ring Adjusting	1	
25872004	Pin driving	3	
25872013	Spring release	3	
25872009	Spider	1	
2484307	Nipple Grease	3	
25872029	Yoke	1	
25872015	Screw Locking	1	
0920053	Washer spring	1	
2556143	Bearing	2	
25872030	Shaft Main	1	
25872012	Lever Fork	1	
25872016	Cross Shaft	1	
25872031	Key	1	
2724141	Circlip	1	
25872005	Pipe Flexible	1	
2576632	Key	1	
25872019	Ring Adjusting	1	
25872006	Plate Locking	1	
0742228	Screw	2	
25872021	Handlever	1	
25872024	Collar	2	
0560108	Nipple Grease	2	
25872027	Screw	2	
25872032	Key	2	
25872033	Screw	3	
0920054	Washer Spring	3	
2421202	Plug	1	
0560109	Nipple Grease	1	
0920052	Washer Plain	2	
0180583	Clip	2	
25872026	Washer	4	
0040060	Bearing Clutch Shaft Pilot	1	
0096433	Setscrew Clutch to Flywheel	8	
0920054	Washer Spring	8	
37135311	Housing Flywheel	1	
32114441	Plug Flywheel Housing - Bearer Facings	10	
0650203	Plug Flywheel Housing	1	
2411157	Washer Flywheel Housing Plug	1	
32815118	Plug Flywheel Housing	1	
0350025	Dowel Flywheel Housing to Block	2	
0746431	Setscrew Flywheel Housing to Block	6	
0920004	Washer Plain	6	
36212132	Plate Flywheel Housing Bottom Cover	1	
0748411	Setscrew Cover plate to Flywheel Housing	2	
0920003	Washer plain	2	
0920053	Washer spring	2	
36125304	Cover Flywheel Housing dust	1	
0748351	Setscrew dust Cover to Flywheel Housing	3	
0920002	Washer plain	3	
0920052	Washer spring	3	
0748523	Setscrew lub. oil Sump to Flywheel Housing	3	

PART NO.	DESCRIPTION	QTY.	REMARKS
<u>CODE V.01 Continued</u>			
0920054	Washer spring	3	
0748524	Setscrew Flywheel Housing to Clutch Housing	12	
0920054	Washer spring	12	
41112695	Flywheel and Starter Ring Assembly	1	
31162121	Ring Starter	1	Inc. In 41112695
32162203	Setscrew Flywheel to crankshaft	6	
0921064	Tabwasher Flywheel to crankshaft setscrew	3	
0440280	Housing Pilot Bearing	1	
0746454	Setscrew Pilot Bearing Housing to Flywheel	4	
0921063	Tabwasher Pilot Bearing Housing setscrew	4	
<u>TURNER T5-300 GEARBOX FLYWHEEL HOUSING FLYWHEEL AND STARTER RING</u>			
<u>CODE V.02.</u>			
2586077	Clutch Assembly	1	
31828	Plate Clutch pressure	1	) Inc. In 2586077
31829	Plate Clutch driving	1	
0040043	Bearing Clutch shaft Pilot	1	
0746453	Setscrew Clutch to Flywheel	8	
0920054	Washer spring	8	
0350520	Dowel Flywheel to clutch	1	
0350521	Dowel Flywheel to clutch	1	
2627342	Gearbox 5 speed Type T5-300	1	(Breakdown to be Included)
0748523	Setscrew Gearbox to Flywheel Housing	12	
0920054	Washer spring	12	
37134661	Housing Flywheel	1	
32114441	Plug Flywheel Housing (Bearer Facings)	10	
0350025	Dowel Flywheel Housing to Block	2	
0746431	Setscrew Flywheel Housing to Block	6	
0920004	Washer plain	6	
36212132	Plate Flywheel Housing Bottom Cover	1	
0748411	Setscrew Cover plate to Flywheel Housing	2	
0920003	Washer plain	2	
0920053	Washer spring	2	
36125304	Cover Flywheel Housing dust	1	
0748351	Setscrew dust Cover to Flywheel Housing	3	
0920002	Washer plain	3	
0920052	Washer spring	3	
0748523	Setscrew Sump to Flywheel Housing	3	
0920054	Washer Spring	3	
41112618	Flywheel and Starter Ring	1	
31162121	Ring Starter	1	Inc. In 41112618
0746851	Setscrew Flywheel to crankshaft	6	
0921062	Tabwasher Flywheel to Crankshaft setscrew	3	
<u>FLEXIBLE COUPLING, HOUSING FLYWHEEL AND FLYWHEEL AND STARTER RING</u>			
<u>CODES V.03,04,05,06,07,08.</u>			
2581365	Coupling Flexible	1	
0746653	Setscrew Coupling to Flywheel	8	
0920055	Washer Spring	8	
41112401	Flywheel and Starter Ring	1	Codes V.03,05,07.

PART NO.	DESCRIPTION	QTY.	REMARKS
<u>CODES V.03,04,05,06,07,08 Continued</u>			
41112403	Flywheel and Starter Ring	1	Codes V.04,06,08.
31162121	Ring Starter	1	Inc. In Flywheel Assys.
32162203	Setscrew Flywheel to Crankshaft	6	
0921062	Tabwasher Flywheel to Crankshaft setscrew	3	
37135311	Housing Flywheel	1	Codes V.03,04.
37134661	Housing Flywheel	1	Codes V.05,06.
37134852	Housing Flywheel	1	Codes V.07,08.
32114441	Plug Flywheel Housing	10	6 Only - Codes V.07,08.
0650203	Plug Flywheel Housing	1	)
2411157	Washer Flywheel Housing Plug	1	) Codes V.03,04,07,08.
32815118	Plug Flywheel Housing	1	Codes V.03,04.
32712723	Plug Flywheel Housing	1	Codes V.07,08.
36817411	Joint Cylinder Block to Flywheel Housing	1	Codes V.07,08.
0350025	Dowel Cylinder Block to Flywheel Housing	2	
0746431	Setscrew Flywheel Housing to Block	6	4 Only - Codes V.07,08.
2185051	Setscrew Flywheel Housing to Block	2	Codes V.07,08.
0920004	Washer Plain	6	
36212132	Plate Flywheel Housing Bottom Cover	1	)
0748411	Setscrew Cover plate to Flywheel Housing	2	)
0920003	Washer plain	2	)
0920053	Washer spring	2	)
36125304	Cover Flywheel Housing dust	1	) Codes V.03,04,05,06.
0748351	Setscrew dust Cover to Flywheel Housing	3	)
0920002	Washer plain	3	)
0920052	Washer spring	3	)
36817145	Joint Flywheel Housing to Sump	1	Code V.07,08.
0748523	Setscrew lub. oil Sump to Flywheel Housing	3	
0920054	Washer spring	3	
<u>MOUNTING RUBBER - PEDESTAL MOUNTED</u>			
<u>CODE A.38.</u>			
2635154	Mounting Rubber	4	
2184504	Bolt Mounting Rubber to Bracket	4	
0576008	Nut Mounting Rubber retaining	4	
0920060	Washer Spring	4	
<u>ACCESSORIES - MISCELLANEOUS</u>			
<u>CODES A.42,43,44,45,46,47,48,49,50.</u>			
2755901	Gauge Water Temperature - 12 volt	1	Code A.42.
2755902	Gauge Water Temperature - 24 volt	1	Code A.43.
2755879	Temperature Sender Unit	1	Codes A.42,43.
2757185	Ammeter - 30-0-30. 12 volt	1	Code A.44.
2757184	Ammeter - 30-0-30. 24 volt	1	Code A.45.
2757183	Ammeter - 60-0-60. 12 volt	1	Code A.50.
41418202	Tool Kit	1	Code A.47.
2656081	Pre-Filter Fuel oil (Check Breakdown)	1	)
0571346	Nut Fuel oil Pre-Filter	2	) Code A.48.
0566004	Olive Fuel oil Pre-Filter	2	)
41811019	Badge Radiator	1	Code A.49.