

Model 25S34 Axle Parts List

Item No.	Description	Qty.	Item No.	Description	Qty.
1	Carrier Sub-Assy	1	44	Yoke-Center	2
2	Bearing Cup-Roller	1	45	Cross-U Joint	4
3	Bearing Cone-Roller	1	46	Seal Assy	16
4	Shim-ADJ	1	47	Bearing Race Assy-U Joint	16
5	Gear & Pinion Assy-Spiral Bevel	1	48	Ring-Snap	12
6	Spacer-Collapsible	1	49	Housing-Axle	2
7	Bearing Cup-Roller	1	50	Tilt Eye Bushing	A/R
8	Bearing Cone-Roller	1	51	Bushing-Spindle	2
9	Thrustwasher-Brg	1	52	Seal-Oil	2
10	Seal-Oil	1	53	Seal-Oil	2
11	Deflector-Seal	1	54	Shaft-Inner Yoke	2
12	End Yoke	1	55	Ring-O	2
13	Washer-Pinion Nut	1	56	Bushing-Flange	2
14	Nut-Pinion	1	57	Coupling-Splined	2
15	Case (Diff Std)	1	58	Ring-O Outer	2
16	Thrustwasher-Differential Gear	2	59	Glyd Ring Outer	2
17	Gear-Differential	2	60	Piston-Service	2
18	Thrustwasher-Differential Pinion	2	61	Ring-O Inner	2
19	Pinion-Differential	2	62	Glyd Ring Inner	2
20	Shaft-Differential Std & T/L	1	63	Plate-Lining Stop	10
21	Pin-Roll	1	64	Disc Assy-Friction	8
22	Bearing Cone-Roller	2	65A	Shaft-Axle Right	1
23	Gear & Pinion Assy-Spiral Bevel	1	65B	Shaft-Axle Left	1
24	Screw-Drive Gear	12	66	Washer-Flat	32
25	Bearing Cup-Roller	2	67	Bolt-Hex	32
26	Cap-Differential Brg (Part of Item1)	2	68	Seat-Insert	4
27	Bolt-Hex	4	69	Screw-Bleeder	4
28	Ring-Adjusting	2	70	Fitting-Hyd Brake	4
29	Clip-Adjusting Ring	2	71	Strap-Bearing	4
30	Washer-Flat	2	72	Screw-Flange 12 Point	8
31	Bolt-Hex	2	73	Ring-Snap	2
32	Cover-Carrier	1	74	Spacer	2
33	Washer-Flat	12	75	Ring-O	2
34	Bolt-Hex	12	76	End Yoke	2
35	Plug-Pipe (Internal Drive)	1	77	Seal-Oil	2
36	Plug-Pipe (Internal Drive)	1	78	Seal-Oil	2
37	Plate-Spring Backing	2	79	Bushing-Spindle	2
38	Spring-Compression	20	80	Knuckle-Steering LH	1
39	Glyd Ring Inner	2	81	Knuckle-Steering RH	1
40	Ring-O Inner	2	82	Retainer-Grease	4
41	Piston-Park	2	83	Bearing Cup-Roller	4
42	Ring-O Outer	2	84	Bearing Cone-Roller	4
43	Glyd Ring Outer	2	85	Seal-Oil	4